


zenon driver manual





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



Contents

1.	Welc	ome to	COPA-DATA help	5		
2.	SYSD	SYSDRV5				
3.	SYSDRV - Data sheet					
4.	Drive	r history	y	7		
5.	Confi	guration	n	7		
	5.1	Creating	g a driver	8		
6.	Creat	ing vari	ables	s		
	6.1	Creating	g system driver variables	10		
	6.2	General	l notes	14		
	6.3	Topic - /	Alarms	15		
	6.4	Topic - I	Historian	15		
	6.5	Topic - I	Batch Control	15		
	6.6	Topic - 0	Command	16		
	6.7	Topic - I	User-defined	18		
	6.8	Topic - I	User administration	18		
	6.9	Topic - I	Printer	20		
	6.10	Topic - I	Hardware resources	21		
	6.11	Topic - I	Network	22		
	6.12	Topic - I	Folder	26		
	6.13	Topic - I	Performance Statistics Network	27		
	6.14	Topic - I	Performance Statistics Driver	30		
	6.15	Topic - I	Project information	33		
	6.16	Topic - s	standard recipes and Recipe Group Manager	36		
	6.17	Topic - S	System information	47		
	6.18	Creating	g variables by importing	48		
		6.18.1	XML import of variables from another zenon project	49		
		6.18.2	DBF Import/Export	49		
7	Drive	r-snacifi	ic functions	55		



8.	Drive	r commands 5	5
9.	Error	analysis5	7
	9 1	Analysis tool 5	7



1. Welcome to COPA-DATA help

GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

2. SYSDRV

zenon system driver for reading out internal project information, network information, hardware information of the PC etc. The driver does not use up any licensed tags.



3. SYSDRV - Data sheet

General:	
Driver file name	SYSDRV.exe
Driver description	Driver for system variables
PLC types	-
PLC manufacturer	zenon system driver; Internal driver;

Driver supports:	
Protocol	unknown;
Addressing: address based	-
Addressing: name based	х
Spontaneous communication	-
Polling communication	х
Online browsing	-
Offline browsing	-
Real-time capable	-
Blockwrite	-
Modem capable	-
Serial logging	-
RDA numerical	-
RDA String	-



Prerequisites:	
Hardware PC	-
Software PC	-
Hardware PLC	-
Software PLC	-
Requires v-dll	х

Platforms:	
Operating systems	Windows CE 5.0, CE 6.0; Windows XP, Vista, 7, Server 2003, Server 2008/R2;
CE platforms	x86; ARM; Pocket-PC;

4. Driver history

Date	Driver version	Change	
07.07.08	600	Created driver documentation	

5. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.





Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.

5.1 Creating a driver

In order to create a new driver:

- ▶ Right-click on Driver in the Project Manage and select Driver new in the context menu.
- ▶ In the following dialog the control system offers a list of all available drivers.



- Select the desired driver and give it a name:
 - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.



- The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore ().
- Attention: This name cannot be changed later on.
- ► Confirm the dialog with ox. In the following dialog the single configurations of the drivers are defined.
- ▶ Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.



6. Creating variables


This is how you can create variables in the zenon Editor:

9



6.1 Creating system driver variables

In the Project manager right-click on variable and select New variable... in the context menu.






In the following dialog select as Driver SYSDRV - Driver for system variables and as
Driver object type System driver variable.



Click on Next.





The following settings are available.



Parameters	Description
Topic	Select the subject area from which you want to create system driver variables. As long as you edit an existing variable, the selection is disabled.
Available variables	All system driver variables which are still available for the selected subject area. Already created variables or variables which are displayed in list Variables to be created are not displayed.
Add	Adds the currently selected variables to the list of the variables to be created.
Add all	Adds all variables which are displayed in list Available variables to the list of the variables to be created.
Remove	Removes all selected variables from the list of the variables to be created.
Remove all	Removes all variables from the list of the variables to be created.
Variables to be created	All system driver variables which you have selected and created with the help of button Finish. If you select one variable, you can edit it under Options.
Options	
Name	Edit the name of the selected variable. Note: Only possible if you have selected only one variable. This variable must be a user-defined variable.
Identification	Edit the identification of the selected variable. Note: Only possible if you have selected only one variable.
Data type	Edit the data type of the selected variable. Note: Only possible if you have selected only one variable. This variable must be a user-defined variable.
Unit	Edit the measuring unit of the selected variable. Note: Only possible if you have selected only one variable.
Accept	Left-click this button in order to apply the changed settings to the selected variable.



Note: If you select another variable before you click on Apply, all changes are canceled. Only valid changes can be applied.
applied.

If you have selected and edited all system driver variables which you want to create, you can create them by left-clicking Finish.



In the lists Available variables and Variables to be created several entries can be selected at once. This happens with:

- Ctrl+left-click: You can select a number of entries by pressing and holding the Ctrl key.
- ▶ Shift+left-click: All entries that are between the two selected entries are selected.
- If Ctrl and Shift are held down at the same time, all entries between the two are selected. Entries already selected are retained.
- ▶ Ctrl+A: All entries are selected.

CHANGING THE NAME OF A SYSTEM DRIVER VARIABLE

If you want to change the pre-defined names of the system driver variables, you can do this as follows: Export the desired variables to XML, change the name of the variables in the XML file (property Name) and import the file.

6.2 General notes

VARIABLES IN THE NETWORK

Variables that contain a reference (global/local) at the end of the name can be created in either the global or local version. All other variables are always local.

- ▶ All local variables are saved locally on the respective workstation (client/server/standby). The behavior of the variable can change, according to the position of the computer in the network topology.
- ► All global variables are depicted on the server (standby) and distributed to the network (clients). Changes to these variable values are always applicable throughout the network.



RELOAD

The values of all system driver variables remain unchanged after reloading.

6.3 Topic - Alarms

The following system driver variables are available for this subject area:

Name	Data type	Comment
Alarms not acknowledged	UDINT	Shows the number of not acknowleged alarms in the memory
Alarm Message List active/inactive	BOOL	Displays the status of the Alarm Message List: 0 = inactive 1 = active
Alarms acknowledged	UDINT	Shows the number of acknowleged alarms in the memory
Number of alarms	UDINT	Shows the number of alarms in memory.

6.4 Topic - Historian

The following system driver variables are available for this subject area:

Name	Data type	Comment
Memory (Archives)	UDINT	Shows the amount of memory reserved for archive data processing (e.g. in the Extended Trend).

6.5 Topic - Batch Control



Name	Data type	Comment
Recipe terminated because of an error	BOOL	Is set to 1 if a recipe cannot be restarted. Before the image creation, the variable is set to 0 .
		This variable is distributed in the network.

Topic - Command 6.6

The following system driver variables are available for this subject area:



Info

The system driver variables of the subject area Command are only available in the Energy Edition.



Name	Data type	Comment
Screen name	STRING	Name of the current screen of the type Command
Screen step	DINT	Number of the current step of the command input 0 = Initialization 1 = Step 1 2 = Unlock 3 = Step 2 4 = Lock 5 = Execution
Identification of the action variable	DINT	Identifies the type of the currently active action 0 = Single command 1 = Double command 2 = Setpoint input 3 = Status input 4 = Replace 5 = Manual correction 6 = Block 7 = Release 8 = Lock 9 = Revision 1000 = Not defined
Name of the action variable	STRING	Name of the data point on which the current action is executed.
Name of the response variable	STRING	Shows the name of the response variable.
Name of the interlocking	STRING	Shows the name of the command group.
Parameter of the action	UDINT	Parameter of the current action. In case of a single command, the command input status will be displayed; otherwise, the current switching direction will be displayed
Update	BOOL	This variable is set to 1 if the listed variables are consistent.
Interlocking code	UDINT	Status of the current interlocking. 0 = Not checked 1 = No active interlocking 2 = Value already set 3 = Not used 4 = Not used 5 = Write failure 6 = Internal Error 7 = Not used 8 = Data point type invalid



Interlocking message	STRING	9 = Not used 10 = Command group does not exist 11 = Action does not exist 12 = Not used 13 = Not used 14 = Value missing 15 = Invalid value 16 = Topology unlockable 17 = Topology not unlockable 18 = Not used 20 = Interlocking of the action unlockable 21 = Interlocking of the action not unlockable 22 = Not used 23 = Locked against command input 24 = Locking administration invalid 25 = SBO expired 26 = Timeout for SBO activation 27 = Timeout for SBO Deactivation 28 = Timeout for Action execution 29 = SBO expired
Interlocking message	STRING	Shows the text of the active interlocking message.

6.7 Topic - User-defined

The following system driver variables are available for this subject area:

Name	Data type	Comment
User-defined1000	BOOL, INT, LREAL, REAL, SINT, STRING, UDINT, UINT, USINT	These are local variables that are not updated in the network. You can enter any name, identification, data type and unit.

6.8 Topic - User administration



Name	Data type	Comment
Current authorization group 1	UDINT	Available authorization level for the user currently logged in to zenon. This information is displayed according to the bit encoding system of the user groups. Authorization level 0 corresponds to decimal value 2^0 = 1 Authorization level 1 corresponds to decimal value 2^1 = 2 Authorization level 0 and 1 corresponds to decimal value 2^0 and 2^1 = 3 etc. The 128 possible authorization levels are distributed to 4 double words (authorization groups 1-4) with increasing value. Indicates authorization level 0 - 31.
Current authorization group 2	UDINT	Available authorization level for the user currently logged in to zenon. This information is displayed according to the bit encoding system of the user groups. Authorization level 0 corresponds to decimal value 2^0 = 1 Authorization level 1 corresponds to decimal value 2^1 = 2 Authorization level 0 and 1 corresponds to decimal value 2^0 and 2^1 = 3 etc. The 128 possible authorization levels are distributed to 4 double words (authorization groups 1-4) with increasing value. Indicates authorization level 32 - 63.
Current authorization group 3	UDINT	Available authorization level for the user currently logged in to zenon. This information is displayed according to the bit encoding system of the user groups. Authorization level 0 corresponds to decimal value 2^0 = 1 Authorization level 1 corresponds to decimal value 2^1 = 2 Authorization level 0 and 1 corresponds to decimal value 2^0 and 2^1 = 3 etc. The 128 possible authorization levels are distributed to 4 double words (authorization groups 1-4) with increasing value. Indicates authorization level 64 - 95.
Current authorization group 4	UDINT	Available authorization level for the user currently logged in to zenon. This information is displayed according to the bit encoding system of the user groups. Authorization level 0 corresponds to decimal value 2^0 = 1 Authorization level 1 corresponds to decimal value 2^1 = 2 Authorization level 0 and 1 corresponds to decimal value 2^0 and 2^1 = 3 etc.



		The 128 possible authorization levels are distributed to 4 double words (authorization groups 1-4) with increasing value. Indicates authorization level 96 - 127.
User - full name	STRING	Displays the full name of the user currently logged in in zenon.
Username	STRING	Displays the user name of the user currently logged in in zenon.
Days until password expires	DINT	Displays the number of days until the password of the user currently logged in becomes invalid. The variable has days as a time format. The time duration can be defined in zenon with the Password – period of validity [d] property. Note: If the Password never expires option is activated in Active Directory or, in zenon, the Password – period of validity [d] property is set to 0, then the value 2147483647 is written to the variable.
Invalid user name	BOOL	If the value of this variable is 1, the login failed either because of wrong user name or because of a wrong password.

6.9 Topic - Printer



Name	Data type	Comment
List printer - Number of print jobs	UDINT	Current number of waiting print jobs for the configured list printer.
List printer – Name	STRING	Name of the currently set list printer.
List printer – Status	UDINT	Shows the current status of the list printer. Printer_Status_Paused = 0x00000001, Printer_Status_Pending_Deletion=0x00000004
Offline printer AML/CEL - Number of print jobs	UDINT	Current number of print jobs waiting for the configured offline printer AML/CEL.
Offline printer AML/CEL - Name	STRING	Name of the currently configured offline printer AML/CEL.
Offline printer AML/CEL - Status	UDINT	Shows the current status of the offline printer AML/CEL. Printer_Status_Paused = 0x00000001, Printer_Status_Pending_Deletion=0x00000004
Online printing on/off	BOOL	Status of the online print administration of the Alarm Message List or the Chronological Event List. 0= off 1 = on
Screenshot printer - Number of print jobs		Current number of waiting print jobs for the configured screenshot printer.
Screenshot printer - Name		Name of the currently configured screenshot printer.
Screenshot printer - Status		Shows the current status of the screenshot printer. Printer_Status_Paused = 0x00000001, Printer_Status_Pending_Deletion=0x00000004
Who is printing online? AML / CEL	BOOL	Shows for which module the online print is active. 0 = Alarm Message List 1 = Chronological Event List

6.10 Topic - Hardware resources



Name	Data type	Comment
Free memory (%)	UDINT	Shows the available memory of the current workstation in %.
Free memory (%) – SB	UDINT	Shows the available memory of the standby server in %.
Free memory (kB)	UDINT	Shows the available memory of the current workstation in kilobytes.
Free memory (kB) – SB	UDINT	Shows the available memory of the standby server in kilobytes.
Free disk space – database (%)	UDINT	Shows the available disk space of the current workstation in %. This value always refers to the partition on which the Runtime folder of the project is located.
Free disk space – database (%) - SB	UDINT	Shows the available disk space of the standby server in %. This value always refers to the partition on which the Runtime folder of the project is located.
Free disk space – database (kB)	UDINT	Shows the available disk space of the current workstation in kilobytes. This value always refers to the partition on which the Runtime folder of the project is located.
Free disk space – database (kB) - SB	UDINT	Shows the available disk space of the standby server in kilobytes. This value always refers to the partition on which the Runtime folder of the project is located.
Free disk space – Export (%)	UDINT	Shows the amount of free disk space of the export folder configured in the project configuration in %.
Free disk space – export (%) – SB	UDINT	Shows the amount of free disk space of the export folder of the standby server configured in the project configuration in %.
Free disk space – export (kB)	UDINT	Shows the amount of free disk space of the export folder configured in the project configuration in kilobytes.
Free disk space – export (kB) – SB	UDINT	Shows the amount of free disk space of the export folder of the standby server configured in the project configuration in kilobytes.

6.11 Topic - Network



Name	Data type	Comment
Current server	STRING	Computer name of the server that is currently handling the process If the name was acquired from the hosts file, this is the name entered there. For DNS, this is the Fully Qualified Doman Name.
		Note: If the network is deactivated, the variable sends the status INVALID. The Current standby server remains empty in contrast.
Current standby server	STRING	Computer name of the server which is currently not handling processes. If the name was acquired from the hosts file, this is the name entered there. For DNS, this is the Fully Qualified Doman Name.
Number of connected clients	UDINT	Delivers the number of clients currently connected to the server. This number also includes the standby server, if there is one.
Authorization: not granted	BOOL	Shows whether a requested authorization is denied in the network. The value of this variable is changed only for a short time and then changed back to the initial state. 0 = Request for Authorization granted 1 = Request for Authorization denied
Authorization exists (yes(1)(no(0))	BOOL	Shows whether there is an authorization for the current project on the local computer. 0 = no 1 = yes
Authorization: Computer that owns it.	STRING	Shows the name of the computer that has the authorization for the currently loaded project.
Names of connected clients	STRING	Delivers the names of the clients currently connected to the server. The standby server, if there is one, is also included.
Network timeout [milliseconds]	UDINT	Shows the timeout in milliseconds for the zenon network as configured in the project configuration.
Redundancy switch	BOOL	A binary variable that takes the value 1 for a short time when the system performs a redundancy switch between server and standby server. 0 = No redundancy switch 1 = Redundancy switch
Server offline	BOOL	Indicates that the connection to the process handling server



		was lost. Depending on the network position of the computer, this
	local	means:
		Dominant Server: While it is not yet the process handling server, the value changes to TRUE if the connection to the process handling server is lost. Always FALSE after synchronization.
		Non-dominant Server: Changes to TRUE if the connection to the dominant server, which was the process handling server, is lost. Changes back to FALSE if the StandBy was promoted to be the process handling server.
		EVALUATION: Preferably via a REMA, as the Alarm Management is also swapped and taken over by the SB at that time. The Online Container is also not suitable because the variables are re-initialized during redundancy switching.
		Client: Changes to TRUE if the connection to the process handling server is lost. Changes back to FALSE if the client connects to the SB computer that is now the process handling server.
Server stop	BOOL	Indicates the regular stop of the process handling server. The value changes to TRUE if the process handling server was stopped properly. FALSE if there is a process handling server in the net.
		Depending on the network position of the computer, this means:
		Dominant Server: While it is not yet the process handling server, the value changes to TRUE if the process handling server has stopped.
		Non-dominant Server: Changes to TRUE if the dominant server, which was the process handling server, has stopped. Changes back to FALSE if the StandBy was promoted to be the process handling server.
		EVALUATION: Preferably via a REMA, as the Alarm Management is also swapped and taken over by the SB at that time. The Online Container is also not suitable because the variables are re-initialized during redundancy switching.
		Client: Changes to TRUE if the dominant server has stopped. Changes back to FALSE if the client connects to the SB computer that is now the process handling server. Is also TRUE while the process handling non-dominant server



Server-Standby in data update BOOL A binary variable that takes on the value 1 if the server and the standby server are synchronizing files after a redundancy switch. 0 = No file synchronization 1 = File synchronization active			changes back to be the non-process handling server.
y-Server/Client 1 = Single user 0 = Client 1 = Server 2 = Standby Server Standby-Server offline BOOL Changes to TRUE if the connection to the currently non-process handling server is terminated unexpectedly. If there is a connection, the value is FALSE. Depending on the network position of the computer, this means: • Dominant Server: The variable only acts as described from the time when the standby became the server handling the process. • Non-dominant Server: If, during file synchronization, the connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE. Always FALSE if not the server handling the process. • Client: As per server handling the process. • Client: As per server handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.		BOOL	the standby server are synchronizing files after a redundancy switch. 0 = No file synchronization
process handling server is terminated unexpectedly. If there is a connection, the value is FALSE. Depending on the network position of the computer, this means: • Dominant Server: The variable only acts as described from the time when the standby became the server handling the process. • Non-dominant Server: If, during file synchronization, the connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE. Always FALSE if not the server handling the process. • Client: As per server handling the process. • Client: As per server handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.	, ,	DINT	-1 = Single user 0 = Client 1 = Server
means: • Dominant Server: The variable only acts as described from the time when the standby became the server handling the process. • Non-dominant Server: If, during file synchronization, the connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE. Always FALSE if not the server handling the process. • Client: As per server handling the process. Standby-Server stop BOOL Is TRUE on the process handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.	Standby-Server offline	BOOL	process handling server is terminated unexpectedly. If there
the time when the standby became the server handling the process. • Non-dominant Server: If, during file synchronization, the connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE. Always FALSE if not the server handling the process. • Client: As per server handling the process. BOOL Is TRUE on the process handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.			
connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE. Always FALSE if not the server handling the process. • Client: As per server handling the process. Is TRUE on the process handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.			the time when the standby became the server handling the
BOOL Is TRUE on the process handling server, if the non-process handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.			connection to a server that is dominant but is not handling the process is interrupted, the value changes to TRUE.
handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.			Client: As per server handling the process.
 Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process. 	Standby-Server stop	BOOL	handling server was stopped properly and if there is no connection anymore. Changes to FALSE if the non-process handling server has registered at the process handling server.
 became the server handling the process does the variable act as described. Non-dominant Server: If this is ended during file synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process. 			means:
synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always FALSE if not the server handling the process.			became the server handling the process does the variable act
Client: As per server handling the process.			synchronization with a server that is dominant but is not handling the process, the value changes to TRUE. Always
			Client: As per server handling the process.



Standby-Server start	BOOL	TRUE if the non-process handling server has registered at the process-handling server and if the data update was performed and the connection between the two computers is active. Depending on the network position of the computer, this means: • Dominant Server: Only from the time when the standby became the server handling the process does the variable act as described. • Non-dominant Server: Becomes TRUE if the dominant server not handling the process starts. Changes to FALSE if the computer is the server handling the process. • Client: As per server handling the process.
Switch from Server to Standby	BOOL	A binary variable that takes on the value 1 if the server becomes the standby server during a redundancy switch. 0 = registered server is available as server in the network. 1 = registered server is available as standby server in the network.
Switch from Standby to Server	BOOL	A binary variable that takes on the value 1 if the standby server becomes the server during a redundancy switch. 0 = registered standby server is available as standby server in the network. 1 = registered standby server is available as server in the network.

6.12 Topic - Folder



Name	Data type	Comment
Bitmap folder	STRING	Shows the folder for the graphics of the active project that were inserted via the project tree. You can edit the folder settings in the project administration.
Database folder	STRING	Shows the working folder of the active project.
List folder	STRING	Shows the folder for the lists of the active project that were inserted via the project tree.
Report folder	STRING	Shows the folder for the report files created in zenon.
Video folder	STRING	Shows the folder for the multimedia files of the active project that were inserted via the project tree.

6.13 Topic - Performance Statistics Network



Name	Data type	Comment
Pending messages (total)	UDINT	Shows the currently pending messages in the Windows Message Queue for the total application.
Pending messages (project)	UDINT	Shows the currently pending messages in the Windows Message Queue for the current project.
Received packets count	UDINT	Cumulated number of received network packets. Write set value initializes the counter.
Received packets count / s current	UDINT	Current number of received network packets per second. Set value function initializes Min and Max.
Received packets count / s current local	UDINT	Current number of locally received network packets per second. Set value function initializes Min and Max.
Received packets count / s maximum	UDINT	Current maximum number of received network packets per second.
Received packets count / s maximum local	UDINT	Current maximum number of locally received network packets per second.
Received packets count / s minimum	UDINT	Current minimum number of received network packets per second.
Received packets count / s minimum local	UDINT	Current minimum number of locally received network packets per second.
Received packets count local	UDINT	Cumulated number of locally received network packets. Write set value initializes the counter.
Received packets processing duration maximum [µs]	UDINT	Maximum processing duration for received network packets.
Received packets processing duration maximum [µs] local	UDINT	Maximum processing duration for locally received network packets.
Received packets processing duration minimum [µs]	UDINT	Minimum of the processing duration for received network packets.
Received packets processing duration minimum [µs] local	UDINT	Minimum of the processing duration for locally received network packets.
Received packets processing duration	UDINT	Average of the processing duration for received network packets. Set value function initializes Counter, Min and Max.



average [μs]		
Received packets processing duration average [µs] local	UDINT	Average of the processing duration for locally received network packets. Set value function initializes Counter, Min and Max.
Received packets size / s current [byte]	UDINT	Current size of received network packets per second. Set value function initializes Min and Max.
Received packets size / s current [byte] local	UDINT	Current size of locally received network packets per second. Set value function initializes Min and Max.
Received packets size / s maximum [byte]	UDINT	Current maximum size of received network packets per second.
Received packets size / s maximum [byte] local	UDINT	Current maximum size of locally received network packets per second.
Received packets size / s minimum [byte]	UDINT	Current minimum size of received network packets per second.
Received packets size / s minimum [byte] local	UDINT	Current minimum size of locally received network packets per second.
Received packets size [byte]	UDINT	Accumulated size of received network packets. Set value function initializes the counter.
Received packets size [byte] local	UDINT	Accumulated size of locally received network packets. Set value function initializes the counter.
Sent packets count	UDINT	Accumulated number of sent network packets. Set value function initializes the counter.
Sent packets count / s current	UDINT	Current number of sent network packets per second. Set value function initializes Min and Max.
Sent packets count / s current local	UDINT	Current number of locally sent network packets per second. Set value function initializes Min and Max.
Sent packets count / s maximum	UDINT	Current maximum number of sent network packets per second.
Sent packets count / s maximum local	UDINT	Current maximum number of locally sent network packets per second.
Sent packets count / s minimum	UDINT	Current minimum number of sent network packets per second.
Sent packets count / s minimum local	UDINT	Current minimum number of locally sent network packets per second.



Sent packets count local	UDINT	Accumulated number of locally sent network packets. Set value function initializes the counter.
Sent packets size / s current [byte]	UDINT	Current size of sent network packets per second. Set value function initializes Min and Max.
Sent packets size / s current [byte] local	UDINT	Current size of locally sent network packets per second. Set value function initializes Min and Max.
Sent packets size / s maximum [byte]	UDINT	Current maximum size of sent network packets per second.
Sent packets size / s maximum [byte] local	UDINT	Current maximum size of locally sent network packets per second.
Sent packets size / s minimum [byte]	UDINT	Current minimum size of sent network packets per second.
Sent packets size / s minimum [byte] local	UDINT	Current minimum size of locally sent network packets per second.
Sent packets size [byte]	UDINT	Accumulated size of sent network packets. Set value function initializes the counter.
Sent packets size [byte] local	UDINT	Accumulated size of locally sent network packets. Set value function initializes the counter.

6.14 Topic - Performance Statistics Driver



Name	Data type	Comment
Received values count / s current	UDINT	Current number of received values per second. Set value function initializes Min and Max.
Received values count / s current local	UDINT	Current number of locally received values per second. Set value function initializes Min and Max.
Received values count / s maximum	UDINT	Current maximum number of received values per second.
Received values count / s maximum local	UDINT	Current maximum number of locally received values per second.
Received values count / s minimum	UDINT	Current minimum number of received values per second.
Received values count / s minimum local	UDINT	Current minimum number of locally received values per second.
Received values processing duration maximum [μs]	UDINT	Maximum value of processing duration for received values.
Received values processing duration maximum [µs] local	UDINT	Maximum value of processing duration for locally received values.
Received values processing duration minimum [µs]	UDINT	Minimum value of processing duration for received values.
Received values processing duration minimum [µs] local	UDINT	Minimum value of processing duration for locally received values.
Received values processing duration average [µs]	UDINT	Average of the processing duration for received values. Set value function initializes Counter, Min and Max.
Received values processing duration average [µs] local	UDINT	Average of the processing duration for locally received values. Set value function initializes Counter, Min and Max.
Received value lists count / s current	UDINT	Current number of received value lists per second. Set value function initializes Min and Max.
Received value lists count / s current local	UDINT	Current number of locally received value lists per second. Set value function initializes Min and Max.



Received value lists count / s maximum	UDINT	Current maximum number of received value lists per second.
Received value lists count / s maximum local	UDINT	Current maximum number of locally received value lists per second.
Received value lists count / s minimum	UDINT	Current minimum number of received value lists per second.
Received value lists count / s minimum local	UDINT	Current minimum number of locally received value lists per second.
Received value lists processing duration maximum [µs]	UDINT	Maximum value of the processing duration for received value lists.
Received value lists processing duration maximum [µs] local	UDINT	Maximum value of processing duration for locally received value lists.
Received value lists processing duration minimum [µs]	UDINT	Minimum value of the processing duration for received values.
Received value lists processing duration minimum [µs] local	UDINT	Minimum value of processing duration for locally received value lists.
Received value lists processing duration average [µs]	UDINT	Average of the processing duration for received value lists. Set value function initializes Counter, Min and Max.
Received value lists processing duration average [µs] local	UDINT	Average of the processing duration for locally received value lists. Set value function initializes Counter, Min and Max.
Number of sent requests	UDINT	Cumulated number of sent requests. Set value function initializes the counter.
Number of sent requests local	UDINT	Cumulated number of locally sent requests. Set value function initializes the counter.
Sent set-values count	UDINT	Accumulated number of sent set-values. Set value function initializes the counter.
Sent set-values count local	UDINT	Cumulated number of sent set-values. Set value function initializes the counter.



6.15 Topic - Project information



Name	Data type	Comment
Number of screen-back actions	UDINT	Displays the number of possible "Screen back" actions. These actions can be configured in the zenon Editor.
Number of reports in memory	UDINT	Shows how many reports are currently executed in the memory of zenon. The reports are initiated via the function administration.
Save resolution-dependent screens active/inactive	BOOL	Status of the option SERIALIZE in the zenon6.ini file 0 = Entry SERIALIZE = 0 1 = Entry SERIALIZE = 1
Flash rate [milliseconds]	UDINT	Shows the currently configured time for the blink frequency for displaying limit violations.
wrong value for set value	BOOL	Display whether the set value input fails due to an invalid value. 0 = Set value executed 1 = Set value failed
		The change to 1 only happens for a short moment and can be used for a reaction matrix, as a trigger for a function, to trigger an alarm or to color certain elements.
		The value changes if a value higher or lower than the one set by an element or a screen of type Keyboard is entered. If the value is changed successfully by dialog Write set value, no value change tales place and the user is informed about the invalid value change via a popup.
Functions on/off	BOOL	Shows the current status of the zenon function administration. 0 = Function administration inactive 1 = Function administration active
Function logging active/inactive	BOOL	Displays whether function logging is activated for the current project. All locally executed functions are written into a log file. 0 = Function logging deactivated 1 = Function logging activated
no authorization to execute function	BOOL	Indicates whether the execution of an action (Set value, Execute function) is tried for which the current user does not have the required authorization. 0 = Action execution allowed 1 = Action execution not allowed
Type of control system (SICAM 230/zenon)	UDINT	Shows the currently used zenon version. 3 = zenon



		1 = SICAM 230
Project name	STRING	Shows the name of the active project in zenon.
Editor version	STRING	Shows the zenon version, for which the current project was created.
Send Message active	BOOL	Displays whether function Send message is active. 0 = Function Send message is inactive 1 = Function Send message is active
Input set value: Current set point input	STRING	Displays the current value of the set value input in screen Keyboard. With this you can check while screen Keyboard is open whether the entered value lies within the limits or whether the value is correct which was entered via screen specific function Display value as text or the function Set point input for keyboard screen.
Set value: Limit for maximum	STRING	Upper limit for set value input for the currently selected variable
Set value: Limit for minimum	STRING	Lower limit for set value input for the currently selected variable.
Serial Number	STRING	Shows the zenon serial number.
Driver queue overflow	BOOL	Displays whether a queue overflow occurs for a driver which is available in zenon. 0 = No queue overflow occurred 1 = Queue overflow occurred
Driver queue overflow (name)	STRING	Displays the name of the driver for which the queue overflow occurred. Variable is updated when system variable causes "driver queue overflow".
Variable for last set value input	STRING	Displays the name of the variable with the last successful set value action.
Variable for set value	STRING	Displays the name of the variable that is currently open for the set value action.
Screen opened last	STRING	Shows the name of the last open screen in zenon. The selection of the frames which are considered at this takes place in property Main frames in the project manager (Graphical design, Runtime general).



6.16 Topic - standard recipes and Recipe Group Manager



RGM GENERAL INFORMATION

Variable	Data type	Description
RGM recipe function in progress (global/local)	DINT	States that an RGM function (including RGM screen functions) is being executed or has been ended: -1: at work Concluded successfully 1: Error: No user rights 2: Error: No authorization in the network 3: Error: Cancellation by the user 4: Error: Undefined 5: Error: Error when saving the recipe file Function cancelled via VBA
Last used filter (global/local)	STRING	Saves the last filter used for the recipe value value list.
XML import result (global/local)	DINT	Displays if the import is currently active and whether the import was concluded with or without errors. The variable is assigned at the start and the end of the import. In the event of an error occurring, the error number of the first error that occurred is set after the import has ended. In addition, all errors that have occurred can be viewed in the CEL with additional information, such as the recipe concerned. These error numbers also apply for the RGM feedback variable Result of the import. The values are written to the defined variables at the start and end of the import of the respective recipe groups. General messages: D: Undefined status (no import has been carried out yet) 1: Import was started and is currently in progress 2: Import was concluded without an error General error:



	3: No file selected.
	▶ 4: Unknown XML structure.
	> 5: Import file is not present.
	(6 - 19: are not currently used)
	RGM-specific error:
	▶ 20: A new recipe could not be created.
	▶ 21: The settings of a recipe cannot be imported (for example,
	time-out for synchronous writing,).
	▶ 22: The RGM data could not be accessed.
	▶ 23: A new recipe group could not be created.
	▶ 24: The variables or recipes of a recipe group cannot be imported
	correctly.
	▶ 25: Group selection is missing for the import of an individual
	recipe.
	▶ 26: The recipe group selected for the import of individual recipes
	is not present.
	▶ 27: Error when creating variables in the group.
	▶ 28: Error when importing the recipe group settings (comments,
	for example).
	▶ 29: Error when importing the variable settings (the minimum and

LAST RECIPE WRITTEN

In addition to the normal RGM actions, there are separate system driver variables for reading and writing for the shadow variables (main.chm::/32418.htm). These system variables contain identical

maximum value, for example).

30: The recipe group could not be imported.

individual recipes could not be loaded.

31: The data of the selected recipe group for the import of



values to last recipe written (write shadow variable) and last recipe read (read shadow variable).



Variable	Data type	Description
Standard recipe/ RGM completely written (global/local) RGM write shadow variables - result	UDINT	Variable receives the value 0 as long as a recipe is written locally. Value becomes 1 if the recipe has been completely written. The variable also has the value 0 once Runtime is started. Values for write operation: O: Send initialization value before the recipe. 1: Writing was completed successfully and has ended. 2: Writing was not carried out due to a general error (parameter). 3: Writing was completed successfully and has ended. 4: Timeout occurred. 5: Write terminated, for example because RT is being ended. 6: time expired (time-out).
Last standard recipe/ RGM recipe name (global/local) RGM write shadow variables - recipe name	STRING	Displays the name of the last standard recipe/RGM recipe sent globally or locally.
Last recipe group sent (globally/locally) RGM write shadow variables - recipe group name	STRING	Displays the name of the last recipe group sent of the last recipe sent.
Last RGM recipe number sent (globally/locally) RGM write shadow variables - recipe number	UDINT	Shows the recipe number of the last RGM recipe sent, globally or locally
RGM last recipe sent - authorization (global/local)	DINT	Authorization level of the last recipe written.



RGM write shadow variables - authorization		
RGM last recipe sent - last user change (global/local)	STRING	Name of the user who was logged in when the last change was made to the last recipe written.
RGM write shadow variables - last user change		
RGM last recipe sent - comment 1 to 8 (global/local) RGM write shadow variables - comment 1 to 8	STRING	Eight comments can be added to a recipe. The variable contains the comment of the respective number for the last recipe sent.
RGM last recipe sent - recipe status (global/local) RGM write shadow variables - recipe status	DINT	Status of the last recipe written as a number.
RGM last recipe sent - recipe status text (global/local) RGM write shadow variables - recipe status text	STRING	Status of the last recipe sent as text in 1 - @Text format.
RGM last recipe sent - recipe version (global/local) RGM write shadow variables - recipe version	DINT	Version of the last recipe written.
RGM last recipe sent - time of last change (global/local)	STRING	Time of the last recipe change of the last recipe written.

LAST RECIPE READ



In addition to the normal RGM actions, there are separate system driver variables for reading and writing for the shadow variables (main.chm::/32418.htm). These system variables contain identical values to last recipe written (write shadow variable) and last recipe read (read shadow variable).

Variable	Data type	Description
RGM recipe of all values that have been read completely (global/local) RGM read shadow variables - result	UDINT	After the recipe has been written, this variable contains the result of the writing operation. Possible variable values: O: Set before the reading and only changes when the reading process is done. 1: Finished reading successfully. 2: During reading an error not defined in greater detail has occurred. 3: When reading, at least one variable hat status INVALID (main.chm::/24148.htm). 4: At least on value is not within the min-max limits. 5: During reading a timeout (30000 + 100*VarCount in [ms]) occurred.
RGM last recipe read - authorization (global/local) RGM read shadow variables - authorization	DINT	Level of authorization of the last recipe read.
RGM last recipe read - last user change (global/local) RGM read shadow variables - last user change	STRING	Name of the user who was logged in when the last change was made to the last recipe read.
RGM last recipe read - comment 1 to 8 (global/local)	STRING	Eight comments can be added to a recipe. The variable contains the comment of the respective number for the last recipe read.



RGM read shadow		
variables - comment 1 to 8		
0		
RGM last recipe read -	STRING	Name of the recipe group name of the recipe read last.
recipe group name		
(global/local)		
RGM read shadow		
variables - recipe group		
name		
RGM last recipe read -	STRING	Name of the recipe read last.
recipe name (global/local)		
RGM read shadow variables		
- recipe name		
RGM last recipe read -	STRING	Number of the recipe read last.
recipe number		
(global/local)		
RGM read shadow		
variables - recipe number		
RGM last recipe read -	DINT	Status of the last recipe read as a number.
recipe status		
(global/local)		
RGM read shadow		
variables - recipe status		
RGM last recipe read -	STRING	Status of the last recipe read as text in 1- Text format.
recipe status text		
(global/local)		
	I .	



RGM read shadow variables - recipe status text		
RGM last recipe read - recipe version (global/local)	DINT	Version of the last recipe read.
RGM read shadow variables - recipe version		
RGM last recipe read - time of last change (global/local)	STRING	Time of the last recipe change of the last recipe read.
RGM read shadow variables - time of last change		

LAST RECIPE SELECTED

If several RGM screens are opened at the same time, the values of the last recipe selection are always taken.



Variable	Data type	Description
RGM last selected recipe - authorization	DINT	Contains the level of authorization of the last selected recipe as a number.
RGM last selected recipe - last user change	STRING	Contains the name of the user that made the last change to the last selected recipe.
RGM last selected recipe - group name	STRING	Contains the name of the group recipe of the last selected recipe.
RGM last selected recipe - comment 1 to 8	STRING	Eight comments can be added to a recipe. The variable contains the comment of the respective number for the last recipe selected.
RGM last selected recipe - recipe name	STRING	Contains the name of the last selected recipe.
RGM last selected recipe - recipe number	DINT	Contains the recipe number of the last selected recipe.
RGM last selected recipe - recipe status	DINT	Contains the status of the last selected recipe as a number.
RGM last selected recipe - recipe status text	STRING	Contains the status of the last selected recipe as text. Example: 1 - newly created
RGM last selected recipe - recipe version	DINT	Contains the recipe version of the last selected recipe.
RGM last selected recipe - time of last change	STRING	Contains the time at which the last selected recipe was last changed.

CHECK RECIPE VALUES

Variable	Data type	Description
RGM recipe values check -	STRING	List all variable differences in the following order:
deviations (global/local)		[Variable name; recipe value; variable value; unit]
		each entry is written in a new line.
		Requirement: Variable RGM recipe value check - result has the value 1.
		Attention: Variable can either be created and evaluated globally or locally.



Check RGM recipe values - authorization (global/local)	DINT	Authorization level of the last recipe checked.
Check RGM recipe values - last user change (global/local)	STRING	Name of the user who was logged in when the last change was made to the last recipe checked.
RGM recipe values check - result (global/local)	DINT	Result of the check: O: All value match. 1: At least one variable value deviates from the recipe value. 2: At least one variable is faulty (INVALID). Error messages: -1: En error while reading the variable value occurred. -2: The recipe group could not be opened. -3: The recipe could not be opened. Attention: Variable can either be created and evaluated globally or locally.
Check RGM recipe values - comment 1 to 8 (global/local)	STRING	Eight comments can be added to a recipe. The variable contains the comment of the respective number for the last recipe checked.
Check RGM recipe values - recipe group name (global/local)	STRING	Name of the recipe group of the recipe checked last. Requirement: Variable RGM recipe value check - result has a value >= -1. Attention: Variable can either be created and evaluated globally or locally.
RGM recipe values check - recipe name (global/local)	STRING	Name of the recipe checked last. Requirement: Variable RGM recipe value check - result has a value >= -1. Attention: Variable can either be created and evaluated globally or locally.
RGM recipe values check - recipe number (global/local)	UDINT	Number of the recipe checked last. Requirement: Variable RGM recipe value check - result has a value >= -1.



		Attention: Variable can either be created and evaluated globally or locally.
Check RGM recipe values - recipe status (global/local)	DINT	Status of the last recipe checked as a number.
Check RGM recipe values - recipe status text (global/local)	STRING	Status of the last recipe checked as text in the format: 1 - @Text
Check RGM recipe values - recipe version (global/local)	DINT	Version of the last recipe checked.
Check RGM recipe values - time of last user change (global/local)	STRING	Time of the last recipe change of the last recipe checked.

RGM BEHAVIOR

All variables are saved locally on the client and assigned data at the time a recipe is selected. If values are changed after values have been selected, for example the recipe number or a comment, then this data is not displayed for the variables. This means: The variables represent a snapshot at the time the recipe is selected. It is therefore possible to establish what was changed after saving.

6.17 Topic - System information

The following system driver variables are available for this subject area:



Name	Data type	Comment
Hard disk data storage active/inactive	BOOL	Display whether the hard disk data storage of the variables is active in zenon. 0 = HDD administration is inactive 1 = HDD administration is active
Local system variable: DWORD 1-4	UDINT	These are local variables that are not updated in the network. The values for these variables can be configured in the zenon6.ini file, which means they can be used as constants for the local computer
Computer name	STRING	Shows the name of the local computer.
Runtime data directory not available	BOOL	Checks whether the data directory of the Runtime is available. Upon a negative result, the Runtime will no longer try to perform read or write access on the directory. The ring buffers of the AML/CEL/HDD management will not be closed. The Runtime will no longer check the availability of the folder. As soon as the directory is available again, the Runtime will have to be restarted again.
Runtime status (simulation)	DINT	Displays the current status of the Runtime. The following values are available for the variable: 0: Process connection 1: Switch to process connection in simulation 2: Change to simulation with process connection 3: In simulation 4: Change the simulation image during simulation
Project version string	STRING	Displays project version (main.chm::/32632.htm).
Time without operation	UDINT	Displays for how long no operation has been carried out in the Runtime. The time is displayed in seconds. The variable is updated cyclically. You can define the cycle time in the file project.ini. For example in order to update the variable every 5 seconds add UPDATE_SEK=5 in the are [Systemtreiber].

6.18 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



6.18.1 XML import of variables from another zenon project

For the import/export of variables the following is true:

- The import/export must not be started from the global project.
- The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type INT with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type STRING. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer INT variables, but STRING variables.

6.18.2 **DBF Import/Export**

Data can be exported to and imported from dBase.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... Select the Import dBase command
- 3. follow the import assistant



The format of the file is described in the chapter File structure.



Info

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... Select the Export dBase command
- 3. follow the export assistant



Attention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.

e.g. the path C:\users\John.Smith\test.dbf is invalid.

Valid: C:\users\JohnSmith\test.dbf

must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



Info

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- ▶ correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ Be stored close to the root directory (Root)

DESIGN

Description	Туре	Field size	Comment
KANALNAME	Char	128	Variable name.
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually).
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_D	Log	1	The variable is deleted with the $1\ \rm entry$ (field/column has to be created by hand).
TAGNR	С	128	Identification.
			The length can be limited using the MAX_LAENGE entry in project.ini .
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset



DIMADD	l NI	2	Fou his variables, his address
BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte
			For string variables: Length of string (max. 63 characters)
			Tot string variables. Length of string (max. os characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables
			ATTENTION: Only the first variable is fully available. All others
			are only available for VBA or the Recipe Group Manager
LES SCHR	R	1	Write-Read-Authorization
_			0: Not allowed to set value.
			1: Allowed to set value.
			<u> </u>
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)
OBJEKT	N	2	Driver-specific ID number of the primitive object
			comprises KANALTYP and DATENART
CICMIN	Floor	16	Non-linearized sizual prinippure (sizual pasalution)
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZPILIN	'	10	reclinical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	N	1	Number of decimal places for the display of the values
			(measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal
OIDAILIMIL	'		possible)
			not used for all other variables
MEMTIEFE	N	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	N	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal
			possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST MINUS	F	16	Negative hysteresis, from measuring range
_			
PRIOR	N	16	Priority of the variable
REAMATRIZE	С	32	Allocated reaction matrix



ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks
RESOURCE	С	128	Resource label. Free string for export and display in lists.
			The length can be limited using the MAX_LAENGE entry in project.ini .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: non linear value adaption is not used
ADJZENON	С	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	С	128	Linked VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.
			·

△ Attention.

When importing, the driver object type and data type must be amended to the target ${\it driver in the DBF file in order for variables to be imported.}$

LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 to 4:



Description	Туре	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1 , the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Hysteresis in %
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Function linking
ASK_FUNC1	R	1	With interrogation before execution
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	С	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	С	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.



7. Driver-specific functions

This driver supports the following functions:

ZENON6.INI ENTRIES

Parameters	Description
[SYSTEMTREIBER]	
UPDATE_SEK =	Cycle time of the system driver in seconds
[LOCAL_VAR]	
ID_DWORD_1 = <value> ID_DWORD_2 = <value> ID_DWORD_3 = <value> ID_DWORD_4 = <value></value></value></value></value>	These entries deliver the values for the system driver variables "System info -> Local system variable: DWORD1-4". These variables are intended for the identification of a single computer in the network. This means the values are always managed locally in the zenon.ini file. By default, limits can be defined for each of these variables. If there are no entries in the zenon.ini file, the values of these variables will be set to 0 in zenon in Runtime.

8. Driver commands


This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function <code>Driver</code> commands. To do this:

- create a new function
- ▶ select Variables -> Driver commands



▶ The dialog for configuration is opened



Parameters	Description
Drivers	Drop-down list with all drivers which are loaded in the project.
Current state	Fixed entry which has no function in the current version.
Driver commands	Drop-down list for the selection of the command.
<pre>Start driver (online mode)</pre>	Driver is reinitialized and started.
<pre>> Stop driver (offline mode)</pre>	Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20).
Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Activate driver write set value	Write set value to a driver is allowed.
▶ Deactivate driver	Write set value to a driver is prohibited.



write set value	
▶ Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
Show this dialog in the Runtime	The dialog is shown in Runtime so that changes can be made.

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the driver command function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

9. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

9.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under Start/All programs/zenon/Tools 7.00 -> Diagviewer.

zenon driver log all errors in the log files. The default folder for the log files is subfolder <u>rog</u> in directory ProgramData, example: C:\ProgramData\zenon \zenon700\LOG for zenon version 7.00 SPO. Log files are text files with a special structure.



Attention: With the default settings, a driver only logs error information. With the <code>piagnosis</code> <code>viewer</code> you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- customize the logging settings
- change the folder in which the log files are saved

Hints:

- 1. In Windows CE even errors are not logged per default due to performance reasons.
- 2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- 3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property Add all columns with entry in the context menu of the column header.
- 4. If you only use Error logging, the problem description is in column Error text. For other diagnosis level the description is in column General text.
- 5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in Error text and/or Error code and/or Driver error parameter (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 6. At the end of your test set back the diagnosis level from Debug Or Deep Debug. At Debug and Deep Debug there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.



You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.

