


zenon driver manual





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



Contents

1.	Welc	Welcome to COPA-DATA help5		
2.	Tren	rendNG5		
3.	TREN	RENDNG - Data sheet5		
4.	Drive	river history7		
5. Requirements			7	
	5.1	PC		8
	5.2	PLC		8
6.	Confi	iguratio	on	8
	6.1	Creatir	ng a driver	9
	6.2	Setting	gs in the driver dialog	10
		6.2.1	General	10
		6.2.2	Site configuration	13
		6.2.3	Driver dialog addressing	14
7.	Creat	ting var	riables	15
	7.1 Creating variables in the Editor		15	
	7.2	Addressing		19
	7.3			20
		7.3.1	Driver objects	20
		7.3.2	Mapping of the datatypes	22
	7.4	Creatir	ng variables by importing	23
		7.4.1	XML import of variables from another zenon project	24
		7.4.2	DBF Import/Export	24
		7.4.3	Online import	30
	7.5	Driver	variables	31
8.	Driver-specific functions3		37	
9.	. Driver commands 4			



10. Error analysis				
10.1	Analysis tool	.46		
10.2	Check list	.48		



1. Welcome to COPA-DATA help

GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

2. TrendNG

3. TRENDNG - Data sheet



General:	
Driver file name	TRENDNG.exe
Driver description	Trend NG driver
PLC types	IQ xxx
PLC manufacturer	Trend;

Driver supports:	
Protocol	unknown;
Addressing: address based	х
Addressing: name based	х
Spontaneous communication	x
Polling communication	х
Online browsing	х
Offline browsing	-
Real-time capable	х
Blockwrite	-
Modem capable	х
Serial logging	х
RDA numerical	х
RDA String	-



Prerequisites:	
Hardware PC	-
Software PC	Trend TCC-Suite
Hardware PLC	-
Software PLC	-
Requires v-dll	-

Platforms:	
Operating systems	Windows XP, Vista, 7, Server 2003, Server 2008/R2;
CE platforms	-;

4. Driver history

Date	Driver version	Change
17.05.10	0100	Created driver documentation

5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.



5.1 PC

HARDWARE

Serial interface RS232 or Ethernet network card.

SOFTWARE

The TCC Suite from Trend is necessary if you want to use the driver.

If drivers are not available in zenon: Copy file TrendNG.exe in the zenon folder.

5.2 PLC

HARDWARE

IQxxx

SOFTWARE

For Alarms: Text communication On

6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.




Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.



6.1 Creating a driver


In order to create a new driver:

- ▶ Right-click on Driver in the Project Manage and select Driver new in the context menu.
- ▶ In the following dialog the control system offers a list of all available drivers.



- Select the desired driver and give it a name:
 - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.
 - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore ().
 - Attention: This name cannot be changed later on.
- ► Confirm the dialog with ox. In the following dialog the single configurations of the drivers are defined.
- Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.






6.2 Settings in the driver dialog

You can change the following settings of the driver:

6.2.1 General





Parameters	Description
Mode	Allows to switch between hardware mode and simulation mode Hardware: A connection to the control is established. Simulation static No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area, e.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver. Simulation - counting
	No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically. Simulation - programmed N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).
Keep update list in the memory	Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.
Output can be written	Active: Outputs can be written. Inactive: Writing of outputs is prevented. Note: Not available for every driver.



Variable image	This option saves and restores the current value, time stamp and the states
remanent	of a data point.
	Fundamental requirement: The variable must have a valid value and time stamp.
	The variable image is saved in mode hardware if:
	one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active
	The variable image is always saved if:
	▶ the variable is of the object type Driver variable
	the driver runs in simulation mode. (not programmed simulation)
	The following states are not restored at the start of the Runtime:
	▶ SELECT(8)
	▶ WR-ACK(40)
	▶ WR-SUC(41)
	The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image.
Stop at the Standby Server	Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.
	Attention: If this option is active, the gapless archiving is no longer guaranteed.
	Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (statusverarbeitung.chm::/24150.htm) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.
Global Update time	Active: The set Global update time in ms is used for all variables in the project. The priority set at the variables is not used. Inactive: The set priorities are used for the individual variables.
Priority	Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken




place for each variable separately in the settings of the variable properties. The communication of the individual variables are graduated in respect of
importance or necessary topicality using the priorities. Thus the communication load is distributed better.

UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For Set value, Advising of variables and Requests, a read cycle is immediately triggered for all drivers regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

6.2.2 Site configuration




Parameters	Description
Site configuration	Configuration of the site connection.
Open TUA String Editor	Opens the Trend TCC Suite dialog for configuring.



6.2.3 Driver dialog addressing

Configuration of the connections to the PLCs.



Parameters	Description
Connections	Contains the configured connections. Select a connection to display the connection settings on the right side.
Connection name	Freely definable name for the distinction of connections.
Net address	The net address identifies the connection. Therefore, every connection must have a unique net address. Variables are assigned to a connection via the net address.
LAN number	Trend LAN address.
Outstation address	Trend Outstation address.
Outstation Pin	Trend Outstation Pin.





CREATE NEW CONNECTION

- 1. click on the button New
- 2. Enter the connection details.
- 3. click on save

EDIT CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Edit
- 3. change the connection parameters
- 4. finish with save

DELETE CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Delete
- 3. the connection will be removed from the list

7. Creating variables

This is how you can create variables in the zenon Editor:

7.1 Creating variables in the Editor

Variables can be created:

- ▶ as simple variables
- ▶ in arrays main.chm::/15262.htm




▶ as structure variables main.chm::/15278.htm

VARIABLE DIALOG

To create a new variable, regardless of which type:

1. Select the New variable command in the Variables node in the context menu



- 2. The dialog for configuring variables is opened
- 3. configure the variable



4. The settings that are possible depends on the type of variables



Property	Description
Name	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.
	Attention: The # character is not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive.
Drivers	Select the desired driver from the drop-down list. Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.
Driver object type (cti.chm::/28685.h tm)	Select the appropriate driver object type from the drop-down list.



Data type	Select the desired data type. Click on the button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- ▶ Automatically adapted if the data type is changed

Note for signal range: If a change is made to a data type that does not support the set signal range, the signal range is amended automatically. For example, for a change from INT to SINT, the signal range is changed to 127. The amendment is also carried out if the signal range was not inherited from the data type. In this case, the measuring range must be adapted manually.



7.2 Addressing

Property	Description	
Name	Depended on the driver object type freely definable name or part of the name; it is used for addressing (see driver specific functions)	
	Attention: the name must be unique within each control system project.	
Identification	Any text can be entered here, e.g. for resource labels, comments	
Net address	Bus address or net address of the variable.	
	This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides.	
Data block	For variables of object type Extended data block, enter the datablock number here.	
	Configurable [0 4294967295] . Please look up the exact maximum range for data blocks in the manual of the PLC.	
Offset	Offset of the variable; the memory address of the variable in the PLC. Configurable [0 4294967295].	
Alignment	not used for this driver	
Bit number	Number of the bit within the configured offset.	
	Valid input [0 65535], Working range [07]	
String length	Only available for String variables: Maximum number of characters that the variable can take.	
Driver object type	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.	
Data type	Data type of the variable, which is selected during the creation of the variable; the type can be changed here later.	
	ATTENTION: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.	



7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

7.3.1 Driver objects

The following object types are available in this driver:



Driver object type	Channel type	Read / Write	Supported data types	Comment
Alarm variable	9	R/W	UINT	
Analog output	67	R/W	REAL	
analog joint	66	R/W	REAL	
Bit	71	R/W	BOOL	
Digital output	69	R/W	BOOL	
Digital input	68	R/W	BOOL	
Button	65	R/W	REAL	
Multivariable Bit	8	R/W	REAL, BOOL	
Multivariable Float	8	R/W	REAL, BOOL	
Multivariable String	72	R/W	STRING	
Switch	70	R/W	BOOL	
Sensor	64	R/W	REAL	
Trigger variable	21	R/W	BOOL, UINT	
Driver variable	35	R/W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the statistical analysis of communication. Find out more in the chapter about the Driver variables (on page 31)

OBJECTS FOR VARIABLES IN ZENON

Object	Read	Write	Comment
Configuration	Υ	Υ	
Sensor	Υ	Υ	V-Parameter is read/written.
Button	Υ	Υ	V-Parameter is read/written.



analog joint	Υ	Υ	V-Parameter is read/written.
Analog output	Υ	Υ	V-Parameter is read/written.
Digital input	Υ	Υ	S-Parameter is read/written.
Digital output	Υ	Υ	V-Parameter is read/written.
Switch	Υ	Υ	S-Parameter is read/written.
Bit	Υ	Υ	Sx-parameter is read/written.(x=Bitnr.)
Multivariable Type Float	Y	Υ	Parameter defined in name is read/written.
Multivarialbe Type Bit	Υ	Υ	Parameter defined in name is read/written.
Alarm variable	Υ	N	
Trigger variable	Υ	Υ	

7.3.2 Mapping of the datatypes

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.



PLC	zenon	Data type
BOOL	BOOL	8
USINT	USINT	9
SINT	SINT	10
UINT	UINT	2
INT	INT	1
UDINT	UDINT	4
DINT	DINT	3
ULINT	ULINT	27
LINT	LINT	26
REAL	REAL	5
LREAL	LREAL	6
STRING	STRING	12
WSTRING	WSTRING	21
DATE	DATE	18
TIME	TIME	17
DATE_AND_TIME	DATE_AND_TIME	20
TOD (Time of Day)	TOD (Time of Day)	19

Data type: The property Data type is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



7.4.1 XML import of variables from another zenon project

For the import/export of variables the following is true:

- The import/export must not be started from the global project.
- The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type INT with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type STRING. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer INT variables, but STRING variables.

7.4.2 **DBF Import/Export**

Data can be exported to and imported from dBase.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... select the Import dBase command
- 3. follow the import assistant



The format of the file is described in the chapter File structure.



Info

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... Select the Export dBase command
- 3. follow the export assistant



Attention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.

e.g. the path C:\users\John.Smith\test.dbf is invalid.

Valid: C:\users\JohnSmith\test.dbf

must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



Info

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- ▶ correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ Be stored close to the root directory (Root)

DESIGN

Description	Туре	Field size	Comment
KANALNAME	Char	128	Variable name.
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually).
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	С	128	Identification.
			The length can be limited using the MAX_LAENGE entry in project.ini .
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset



BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)	
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipe Group Manager	
LES_SCHR	R	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.	
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)	
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises KANALTYP and DATENART	
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)	
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)	
ANZMIN	F	16	Technical value - minimum (measuring range)	
ANZMAX	F	16	Technical value - maximum (measuring range)	
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)	
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables	
MEMTIEFE	N	7	Only for compatibility reasons	
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)	
HDTIEFE	N	7	HD entry depth for historical values (number)	
NACHSORT	R	1	HD data as postsorted values	
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decima possible)	
HYST_PLUS	F	16	Positive hysteresis, from measuring range	
HYST_MINUS	F	16	Negative hysteresis, from measuring range	
PRIOR	N	16	Priority of the variable	
REAMATRIZE	С	32	Allocated reaction matrix	
	1	1	I .	



=	16	Substitute value, from measuring range
		, 5 - 5 -
=	16	Minimum for set value actions, from measuring range
=	16	Maximum for set value actions, from measuring range
3	1	Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks
2	128	Resource label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini .
3	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: non linear value adaption is not used
	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
	128	Linked VBA macro for writing the variable value for non-linear value adjustment.
V	16	Linked counter REMA.
N	16	Gradient overflow for counter REMA.
= R		16 1 1 128 128 128 128

△ Attention.

When importing, the driver object type and data type must be amended to the target ${\it driver in the DBF file in order for variables to be imported.}$

LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 to 4:



Description	Туре	Field size	Comment	
AKTIV1	R	1	Limit value active (per limit value available)	
GRENZWERT1	F	20	Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1 , the existing variable linkage is not overwritten)	
SCHWWERT1	F	16	Threshold value for limit	
HYSTERESE1	F	14	Hysteresis in %	
BLINKEN1	R	1	Set blink attribute	
BTB1	R	1	Logging in CEL	
ALARM1	R	1	Alarm	
DRUCKEN1	R	1	Printer output (for CEL or Alarm)	
QUITTIER1	R	1	Must be acknowledged	
LOESCHE1	R	1	Must be deleted	
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).	
FUNC1	R	1	Function linking	
ASK_FUNC1	R	1	With interrogation before execution	
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)	
A_GRUPPE1	N	10	Alarm/event group	
A_KLASSE1	N	10	Alarm/event class	
MIN_MAX1	С	3	Minimum, Maximum	
FARBE1	N	10	Color as Windows coding	
GRENZTXT1	С	66	Limit value text	
A_DELAY1	N	10	Time delay	
INVISIBLE1	R	1	Invisible	

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.




7.4.3 Online import

ONLINE IMPORT OF VARIABLES


To import variables automatically from the control:

- 1. select Import variables from driver from the context menu of the driver
- 2. the dialog for the configuration is opened
- 3. select which kind of variables from which control should be imported





After confirming the configuration with ox all variables which correspond to the selected type and are available on the control are read in and presented in a list for selection.



Select the desired variables. After you confirm it with ox, the variables are created in the zenon project.


7.5 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- ▶ Information
- ▶ Configuration
- Statistics and
- ▶ Error messages

The definitions of the variables defined in the driver kit are available in the import file drvvar.dbf (on the CD in the directory: CD Drive:/Predefined/Variables) and can be imported from there.

Hint: Variable names must be unique in zenon. If driver variables are to be imported from drvvar.dbf again, the variables that were imported beforehand must be renamed.





- Variables for modem information are only supported by modem-compatible drivers
- Driver variables for the polling cycle only for pure polling drivers
- Connection-related information such as ErrorMSG only for drivers that only edit one connection at a a time



INFORMATION

Name from import	Туре	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon service pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection stopped
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped



			For driver stop, the variable has the value TRUE and an OFF bit. After the driver has started, the variable has the value FALSE and no OFF bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

CONFIGURATION

Name from import	Туре	Offset	Description
ReconnectInRead	BOOL	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet.
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver



Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	SINT	14	Number of bits per character of the serial interface
			Value = 0 if the driver cannot establish any serial connection.
StopBit	SINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UDINT	54	Time in seconds (s) to establish a connection.



STATISTICS

Name from import	Туре	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group High in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).



PokeFinish BOOL 55	Goes to 1 for a query, if all current pokes were executed	
--------------------	---	--

ERROR MESSAGES

Name from import	Туре	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	UDINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	SINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

8. Driver-specific functions

This driver supports the following functions:

RECONNECT

If the driver loses the connection, it attempts to reconnect three times by default:



- ► For a non-ADL connection (autodialed link): after 5 seconds
- ► For ADL connections (autodialed link): after 15 seconds

these settings can be modified in the TUA dialog.

"DEFAULT" VARIABLES

Driver object type

- ▶ Sensor
- ▶ Button
- analog joint
- ► Analog output
- ▶ Digital output
- ▶ Switch
- ▶ Bit

The value entered at property Offset is used as index.

EXAMPLE FOR CREATING A SENSOR VARIABLE

For sensor 2 (S2) a new variable of type "Sensor" with he following entries is created:

Offset: 2

Net address: the connection number set in the driver configuration

Identification: freely selectable description

Name: freely selectable description

MULTI VARIABLES

In order to read other parameters, it is possible to create a variable of the type "multi variable". The following is available:

Multivariable Bit



- ▶ Multivariable Float
- ► Multivariable String

EXAMPLE FOR CREATING A MULTI VARIABLE

To read parameter "#" from sensor 1:

- ▶ create a variable of type Multi variable float
- ► Name: desired name followed by a colon and the description of the parameter which should be read out;

for example: MyName:S1(H).

ALARMS

The PLC will send alarm telegrams if an alarm occurs. zenon will only react to alarms for which there is an alarm variable. All received alarms are acknowledged automatically.

CREATING AN ALARM VARIABLE

Just like creating other variable, station number, identification and name (description) must be entered.

The name must be complemented by a string in accordance with the following:



Parameters	Description
Character 1-2	:0
Character 2-4	Station number: 024
Character 5	Item Type according to Trend Documentation ("S")
	▶ S - Sensor
	▶ L-Loop
	▶ H - Schedule
	D - Driver
	▶ I – Digital Input
	▶ G – General Alarms
Character 6-8	Item number: 001

So that alarms can also be received in zenon, for each station from which alarms should be received alarm routing must be configured in the control. The Alarm destination must be configured in a way that the alarms are sent to the station to which the zenon driver is connected.

Attention: For the reception of the alarms you must activate property Number for LAN 0 in the driver configuration in tab Connections (on page 14).

Depending on the alarm code, the alarm variable gets a value, that for example is analyzed with a reaction matrix.



Paramete rs	Value
HIGH	1
LOW	2
OUTL	3
READ	4
SDEV	5
PVFL	6
SDGT	7
MINT	8
DI=0	9
DI=1	10
CONL	11
HELP	12
FPIA	13
FRTC	14
FRAM	15
FDRT	16
FPRM	17
FSWR	18
FTKP	19
FTKA	20
NKCH	21
NKBK	22
DVDD	23
AONL	24
MONR	25



BTNR	26
LINR	27
PGNR	28
AANR	29
СНІН	30
CLOW	31
COUT	32
О/К	33
CSDV	34
CPVF	35
CDGT	36
CMNT	37
CDI0	38
CDI1	39
NKOK	40
DVOK	41

READING LOGS

To be able to evaluate logs from the trend control, you must create a trigger variable and an RDA variable.

CREATING A TRIGGER VARIABLE

Under "offset", enter the sensor that shall request the values. The entered "name" requires a string as described below:

Parameters	Description
Character 1-3	:l=
Character 4-	Interval

Example: :I=3; means interval 3.



The intervals are defined as followed:

Parameters	Length of time
0	1 hour
1	15 minutes
2	24 hours
3	1 minute
4	5 minutes
5	10 minutes
6	20 minutes
7	30 minutes
8	6 hours
9	1 second

Recording is not carried out if an invalid parameter is entered (<> 0-9).

Attention

The interval of the variables must be the same in zenon and in the PLC, otherwise the values are not inserted into the archive.

As the driver supports two types of loggings, you must define whether Compact Logging or Full-Precision Logging should be used. This is defined with an additional parameter in the variable name.

- ► Full Precision::C=0;
- ► Compact::C=1;



Attention

Differences Compact Logging and Full-Precision:

- Compact: Much faster.
- ▶ Full Precision: Precision of the values much higher.

With compact logging, data for e.g. 1000 values are packed into 12 telegrams; with full precision the same data amount is sent in 200 telegrams.

As data type you can set either BOOL or UINT. If UNIT is used as data type, you can define via the set value how many values can be maximally read. At that you can only choose between 96 (non-extended log retrieval) and 1000 (extended log retrieval). If you use BOOL as data type, a maximum of 1000 values is read.

CREATING AN RDA VARIABLE

In addition to a trigger variable, an RDA-variable also has to be defined. Creating an RDA variable works in exactly the same way as the creation of a normal sensor variable (sensor number is set via the offset). In addition RDA must be activated:

- navigate to node Harddisk data storage
- ▶ Activate the Harddisk data storage active property
- ▶ at property Recording type select value Re-sorted values (RDA)

9. Driver commands


This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function Driver commands. To do this:

create a new function



- ▶ select Variables -> Driver commands
- ► The dialog for configuration is opened



Parameters	Description
Drivers	Drop-down list with all drivers which are loaded in the project.
Current state	Fixed entry which has no function in the current version.
Driver commands	Drop-down list for the selection of the command.
<pre>Start driver (online mode)</pre>	Driver is reinitialized and started.
<pre>> Stop driver (offline mode)</pre>	Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20).
Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Activate driver write set value	Write set value to a driver is allowed.



•	Deactivate driver write set value	Write set value to a driver is prohibited.
•	Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
•	Disconnect from modem	Terminate connection (for modem drivers)
	ow this dialog in the	The dialog is shown in Runtime so that changes can be made.

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the driver command function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.00 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder <u>rog</u> in directory ProgramData, example: C:\ProgramData\zenon \zenon700\LOG for zenon version 7.00 SPO. Log files are text files with a special structure.



Attention: With the default settings, a driver only logs error information. With the <code>piagnosis</code> <code>viewer</code> you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- customize the logging settings
- change the folder in which the log files are saved

Hints:

- 1. In Windows CE even errors are not logged per default due to performance reasons.
- 2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- 3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property Add all columns with entry in the context menu of the column header.
- 4. If you only use Error logging, the problem description is in column Error text. For other diagnosis level the description is in column General text.
- 5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in Error text and/or Error code and/or Driver error parameter (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 6. At the end of your test set back the diagnosis level from Debug Or Deep Debug. At Debug and Deep Debug there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.



You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.



10.2 Check list

- ▶ Is the PLC connected to the power supply?
- ► Are the participants available in the TCP/IP network?
- ► Can the PLC be reached via the PING command?
- Can the PLC be reached via TELNET?
- ► Are the PLC and the PC connected with the right cable?
- ▶ Did you select the right COM port?
- ▶ Do the communication parameters match (Baud rate, parity, start/stop bits,...)?
- ► Is the COM port blocked by another application?
- ▶ Did you configure the net address correctly, both in the driver dialog and in the address properties of the variable?
- ▶ Did you use the right object type for the variable?
- ▶ Does the offset addressing of the variable match the one in the PLC?
- ▶ Use the DiagViewer for further analysis -> Which messages does it show?