


# zenon manual





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



# **Contents**

1.	Welcome to COPA-DATA help	4
	Unit conversion	
	Units detail view of toolbar and context menu	
	Engineer units	
	Allocate a base unit to a variable	
	Function unit conversion	
7.	Runtime	. 11



# 1. Welcome to COPA-DATA help

#### **GENERAL HELP**

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

#### **PROJECT SUPPORT**

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

#### LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

# 2. Unit conversion

Unit conversion enables conversion and switching of base units into converstion units, for example meters into yards or meters into decimeters, centimeters and millimeters. A base unit contains the initial value for a conversion. The conversion unit contains the converted value in relation to the base value. Both have a unit name. A Factor, a Offset and a Shift of the decimal point can be defined for conversion units, based in the relevant base unit.

A base unit can be selected when setting parameters for a variable. It is possible to switch between the different units during runtime using the Unit switching (on page 10) function.



# License information

Part of the standard license of the Editor and Runtime.

### PROJECT MANAGER CONTEXT MENU

Menu item	Action
New base unit	Creates a new base unit.
Export XML all	Exports all entries as an XML file.
Import XML	Imports units from an XML file.
Help	Opens online help.



You must not use the unit conversion together with the report function variablerw. This report function provides a unit conversion for older projects. If the unit defined in the unit conversion of a variable is changed by the report function in the Runtime, you must carry out the configuration in the unit conversion again.



# 3. Units detail view of toolbar and context menu

#### **CONTEXT MENU UNITS DETAIL VIEW**

Menu item	Action
New base unit	Creates a new base unit.
Export XML all	Exports all entries as an XML file.
Import XML	Imports units from an XML file.
Help	Opens online help.

### CONTEXT MENU AND TOOL BAR BASE UNIT/CONVERSION UNIT





Menu item	Action
New base unit	Creates a new base unit.
New conversion unit	Creates a new conversion unit for the superordinate base unit.
Linked elements:  Jump back to starting element	Drop-down list with link back to the element from which you can reach the unit.  Only available if units are linked with other elements.
Rename	Makes it possible to rename the unit.  Attention: If units are renamed, all units linked to variables or used in functions must then be manually adapted for the respective variable or function. See also: Allocate a base unit to a variable (on page 9) and Unit conversion function (on page 10).
Export XML all	Exports all entries as an XML file.
Import XML	Imports units from an XML file.
Сору	Copies selected entries to the clipboard.
Paste	Pastes the contents of the clipboard. If an entry with the same name already exists, the content is pasted as "Copy of".
Delete	Deletes selected entries.
Help	Opens online help.

# 4. Engineer units


You must create a base unit and a conversion unit for the conversion, as well as defining the parameters for conversion. The conversion is carried out using the formula y=kx+d (Austria) or y=mx+b (Germany). Each base unit can be allocated to a variable (on page 9) as a unit.

#### TO CREATE A NEW BASE UNIT:

- ▶ select the Units node in Project Manager
- right-click on Units
- select the New base unit command from the context menu




- a new entry is created in the list
- ▶ give the unit a name
- create the conversion unit



#### TO CREATE A NEW CONVERSION UNIT:


- right-click on a base unit
- ▶ select the Conversion unit command from the context menu
- a new entry is created in the list
- give the unit a name
- ▶ define a Factor for the conversion
- ▶ define a value for the Shift of the decimal point
- ▶ define a value for the Offset





### 5. Allocate a base unit to a variable


You allocate a variable to base units in the Measuring unit (nodes General) property.



You are free to name units as you wish here. If the unit conversion is used during runtime, select a predefined basis unit from the drop-down list.

Hint: If you give it a name of your choice, it is best to create a link with the same name straight away in Node units - the basic unit (on page 7).

You must create a Unit conversion function (on page 10) in order to be able to convert during runtime.






# 6. Function unit conversion

In order to carry out unit conversion in the Runtime, create function unit conversion:

- select the Functions node in Project Manager
- ▶ in the context menu, select the command New function...
- ► navigate to the variable
- Select the unit conversion function

Note: The execution of function Unit conversion triggers a refresh of the report if it is displayed at the moment.

► The dialog for the definition of the Unit conversion opens.





Property	Description
Unit conversion	Dialog for the allocation of conversion units to basic units.
Basic unit	List of the created basic units.
Convert to	Drop-down list for the selection of the conversion unit. You can either select a conversion unit or the basic unit.
	Engineered conversion unit: In the Runtime the basic unit is converted to the conversion unit.
	<basic unit="">: The basic unit is still active in the Runtime.</basic>



# Info

The units are not exported with the XML export of this function. You must export the units separately.

#### Attention

If a unit is renamed afterwards, the renamed basic unit is automatically taken into consideration in the function. However you must change the conversion units manually.

# 7. Runtime

Each variable value for each input or output in addition to those used as standard when converting signal units to measuring range units is converted in runtime.

- Output: A conversion unit for a variable is activated with the Unit switch function (on page 10). The value in measuring units is subject to the pre-defined offset and factor. In addition, to convert the value into a string, the number of decimals set for a variable is corrected accordingly.
- Input The conversion is carried out along the lines of output in the other direction.



#### LIMITATIONS:

- ▶ At the export the new units are exported.
- ▶ Values that are saved as a string are not recalculated for output. These values remain in the unit that ws active at the time of creating the string. This particularly affects all values inserted into the text of a CEL entry, such as "Target value changed from OLD to NEW" etc.
- ► Operating hours and operations counters in Industrial Maintenance Manager are always displayed in base units here.
- ▶ Outputs in the EMS window are always displayed in the base unit.

#### **VBA**

Values above VBA are always accessed in base units. For example, **variable.value** does not provide a value with units switched, because it is not a value output. 4 new functions have been incorporated into **variable**. so that unit switching can also be used above VBA:

Keyword	Description
SecondaryUnitName	gives the name of the conversion unit set
SecondaryUnitDigits	gives the decimals for the conversion unit set
CalcSecondaryUnitValue	converts the value of the base unit into the value of the conversion unit
CalcPrimaryUnitValue	converts the value of the conversion unit into the value of the base unit