


zenon driver manual





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



Contents

| 1. | Welc | elcome to COPA-DATA help5 | | |
|----|-------|---------------------------|----------------------------------------------------|----|
| 2. | FRAP | -RAPORT | | |
| 3. | FRAP | ORT - D | Data sheet | 6 |
| 4 | Drive | r histor | ry | 7 |
| | | | | |
| 5. | Confi | guratio | on | |
| | 5.1 | Creatin | ng a driver | 8 |
| | 5.2 | Setting | gs in the driver dialog | 9 |
| | | 5.2.1 | General | |
| | | 5.2.2 | Settings | 12 |
| | | 5.2.3 | Connections | 13 |
| 6. | Creat | ing vari | iables | 16 |
| | 6.1 | Creatin | ng variables in the Editor | 16 |
| | 6.2 | Addres | ssing | 19 |
| | | 6.2.1 | Flight display for target tracks | 20 |
| | | 6.2.2 | Process variables | 20 |
| | | 6.2.3 | Status | 22 |
| | 6.3 | Driver | objects and datatypes | 26 |
| | | 6.3.1 | Driver objects | 26 |
| | | 6.3.2 | Mapping of the data types | 27 |
| | 6.4 | Creatin | ng variables by importing | 28 |
| | | 6.4.1 | XML import of variables from another zenon project | 28 |
| | | 6.4.2 | DBF Import/Export | 29 |
| | 6.5 | Driver | variables | 35 |
| 7. | Drive | r-specif | fic functions | 40 |
| 8. | Drive | r comm | nands | 42 |
| 9. | Error | analysi | is | 43 |
| | 0.1 | Analysi | is tool | 1/ |



| 9.2 | Check list4 | 5 |
|-----|-------------|---|
| | | _ |



1. Welcome to COPA-DATA help

GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

2. FRAPORT

The FRAPORT driver makes it possible to dispaly all mesages and displays in the zenon interconnected baggage system (IBS) and to be able to control the system.



3. FRAPORT - Data sheet

| General: | |
|--------------------|------------------------|
| Driver file name | FRAPORT.exe |
| Driver description | FRAPORT Driver |
| PLC types | FRAPORT baggage system |
| PLC manufacturer | Fraport AG; |

| Driver supports: | |
|---------------------------|--------------|
| Protocol | proprietary; |
| Addressing: address based | - |
| Addressing: name based | х |
| Spontaneous communication | х |
| Polling communication | - |
| Online browsing | - |
| Offline browsing | - |
| Real-time capable | - |
| Blockwrite | - |
| Modem capable | - |
| Serial logging | - |
| RDA numerical | - |
| RDA String | - |



| Prerequisites: | |
|----------------|--------------------------|
| Hardware PC | Standard Network Adapter |
| Software PC | - |
| Hardware PLC | - |
| Software PLC | - |
| Requires v-dll | - |

| Platforms: | |
|-------------------|----------------------------------------------------|
| Operating systems | Windows XP, Vista, 7, Server 2003, Server 2008/R2; |
| CE platforms | -; |

4. Driver history

| Date | Driver version | Change |
|----------|----------------|------------------------------|
| 16.03.11 | 100 | Created driver documentation |

5. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.

Info

Find out more about further settings for zenon variables in the chapter Variables

7




(main.chm::/15247.htm) of the online manual.

5.1 Creating a driver

In order to create a new driver:


- ▶ Right-click on Driver in the Project Manage and select Driver new in the context menu.
- ▶ In the following dialog the control system offers a list of all available drivers.



- Select the desired driver and give it a name:
 - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.
 - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore ().
 - Attention: This name cannot be changed later on.




- ► Confirm the dialog with ox. In the following dialog the single configurations of the drivers are defined.
- ▶ Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.



5.2 Settings in the driver dialog

You can change the following settings of the driver:

5.2.1 General





| Parameters | Description |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode | Allows to switch between hardware mode and simulation mode |
| | ▶ Hardware: |
| | A connection to the control is established. |
| | ▶ Simulation static |
| | No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area, e.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver. |
| | ▶ Simulation - counting |
| | No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically. |
| | ▶ Simulation - programmed |
| | N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm). |
| Keep update list in the memory | Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control. |
| Output can be | Active: Outputs can be written. |
| written | Inactive: Writing of outputs is prevented. |
| | Note: Not available for every driver. |



| Variable image | This option saves and restores the current value, time stamp and the states |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| remanent | of a data point. |
| | Fundamental requirement: The variable must have a valid value and time stamp. |
| | The variable image is saved in mode hardware if: |
| | one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active |
| | The variable image is always saved if: |
| | ▶ the variable is of the object type Driver variable |
| | the driver runs in simulation mode. (not programmed simulation) |
| | The following states are not restored at the start of the Runtime: |
| | ▶ SELECT(8) |
| | ▶ WR-ACK(40) |
| | ▶ WR-SUC(41) |
| | The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image. |
| Stop at the Standby Server | Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade. |
| | Attention: If this option is active, the gapless archiving is no longer guaranteed. |
| | Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (statusverarbeitung.chm::/24150.htm) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian. |
| Global Update time | Active: The set Global update time in ms is used for all variables in the project. The priority set at the variables is not used. Inactive: The set priorities are used for the individual variables. |
| Priority | Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken |



place for each variable separately in the settings of the variable properties.

The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities. Thus the communication load is distributed better.


UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For Set value, Advising of variables and Requests, a read cycle is immediately triggered for all drivers regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

5.2.2 Settings

General settings for communication are carried out in this tab. These settings apply to all connections (on page 13) that have been created in the driver.






| Property | Description |
|--------------------------------------------|---------------------------------------------------------------------------------|
| Station number (server): | Station number of the zenon server. |
| Station number (standby): | Station number of the zenon standby server. |
| Use variable identification for addressing | Active: The identification instead of the name is used for symbolic addressing. |

5.2.3 Connections

On this tab you carry out the settings for the connection. You can create any number of connections in the driver. All connections use the global settings, which are defined in the Settings (on page 12) tab.





| Property | Description |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Connections | List of the connections created and their net addresses. |
| Connection name | Name of connection. |
| New | Adds new entry to the list. Settings are carried out in the field to the right of the list. |
| Delete | Deletes selected entry from the list. |
| Edit | Makes it possible to configure the selected entry. The area to the right of the list for editing the connection is activated. |
| | Attention! The driver dialog cannot be closed in editing mode. Only once the editing mode has been left using Save or Cancel can you close the driver dialog. |
| Edit connection | Connection settings for a new connection or the connection selected under connection. |
| Net address | The net address identifies the connection. Therefore, every connection must have a unique net address. Variables are assigned to a connection via the net address. |
| | Attention! If you change the net address here, you must also change the net address of all other variables of the connection. Otherwise the allocation is no longer correct and variables cannot communicate in the Runtime! |
| Connection name | Connection name. |
| | Freely definable name. |
| Interface | Selection of the connection from the drop-down list: |
| | ► Control computer (LR) |
| | ► Cell controller (CC) |
| | ► Head computer (head) |
| Station number | Station number of the remote station. |
| Address (LAN-A) | IP address or DNS name of the remote station in the LAN-A. |



| Port (LAN-A) | TCP port of the remote station in the LAN-A. |
|-----------------|------------------------------------------------------------|
| Address (LAN-B) | IP address or DNS name of the remote station in the LAN-B. |
| Port (LAN-B) | TCP port of the remote station in the LAN-B. |
| Save | Saves changes. |
| Cancel | Discards changes. |

Hint: Driver messages can be read with the Diagnosis Viewer (main.chm::/12464.htm).

CREATE NEW CONNECTION

- 1. click on the button New
- 2. Enter the connection details.
- 3. Click on save

EDIT CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Edit
- 3. change the connection parameters
- 4. finish with save

DELETE CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Delete
- 3. the connection will be removed from the list



6. Creating variables

This is how you can create variables in the zenon Editor:

6.1 Creating variables in the Editor


Variables can be created:

- as simple variables
- ▶ in arrays main.chm::/15262.htm
- ▶ as structure variables main.chm::/15278.htm

VARIABLE DIALOG

To create a new variable, regardless of which type:

1. Select the New variable command in the Variables node in the context menu



2. The dialog for configuring variables is opened



- 3. configure the variable
- 4. The settings that are possible depends on the type of variables



| Property | Description |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Name | Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name. Attention: The # character is not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive. |
| Drivers | Select the desired driver from the drop-down list. Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded. |
| Driver object type (cti.chm::/28685.h tm) | Select the appropriate driver object type from the drop-down list. |



| Data type | Select the desired data type. Click on the button to open the selection dialog. |
|------------------------------|-------------------------------------------------------------------------------------------------------|
| Array settings | Expanded settings for array variables. You can find details in the Arrays chapter. |
| Addressing options | Expanded settings for arrays and structure variables. You can find details in the respective section. |
| Automatic element activation | Expanded settings for arrays and structure variables. You can find details in the respective section. |

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- Automatically adapted if the data type is changed

Note for signal range: If a change is made to a data type that does not support the set signal range, the signal range is amended automatically. For example, for a change from INT to SINT, the signal range is changed to 127. The amendment is also carried out if the signal range was not inherited from the data type. In this case, the measuring range must be adapted manually.



6.2 Addressing

| Group/Property | Description | | | |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|
| General | | | | |
| Name | Variable name. ATTENTION: For every zenon project the name must be unambiguous. Depending on the settings of Use identification as external name in the Settings (on page 12) dialog, the variable is addressed using its name or the identification set for it. | | | |
| Identification | Variable name. ATTENTION: For every zenon project the name must be unambiguous. Depending on the settings of Use identification as external name in the Settings (on page 12) dialog, the variable is addressed using its name or the identification set for it. | | | |
| Addressing | | | | |
| Net address | Bus address or net address of the variable. | | | |
| | This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides. | | | |
| Data block | not used for this driver | | | |
| Offset | not used for this driver | | | |
| Alignment | not used for this driver | | | |
| Bit number | Number of the bit within the configured offset. | | | |
| | Possible entries: 0 65535 | | | |
| String length | Only available for String variables: Maximum number of characters that the variable can take. | | | |
| Driver connection/Driv er object type | Object type of the variables. Depending on the driver used, is selected when the variable is created and can be changed here. | | | |
| Driver connection/Data | Data type of the variable. Is selected during the creation of the variable; the type can be changed here. | | | |
| type | ATTENTION: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary. | | | |


ADDRESSING



Detailed information for addressing is available for the object types:

- ► Flight display for the target tracks (on page 20)
- Process variables (on page 20)
- ► Status (on page 22)

The following object types (on page 26) are generally available:



6.2.1 Flight display for target tracks

Flight displays are addressed using the target number in the system.

The complete address comprises:

- ► Any desired prefix
- ► An exclamation mark (!) as a separator
- ► The string FLUG
- ► The target number

Example: wEO52!FLUG 1234

6.2.2 Process variables

The addressing of process variables is different on the control computer and on the cell controller.



If a variable is written that only displays part of a process variable, all other bits are set to 0.



CONTROL COMPUTER (LR)

The address comprises:

- ► Any desired prefix
- ► An exclamation mark (!) as a separator
- ▶ The Area identification
- ► An underscore (_) as a separator
- ▶ The actual process variable names
- ► A period (.) as a separator
- ► A suffix

Info: Prefix and suffix are optional

Example:

With prefix and suffix: weo52!w_pvxx1.Qword Or weo52!w_pvxx1._[0] In short: w_pvxx1

CELL CONTROLLER (CC)

The address comprises:

- ► Any desired prefix
- ► An exclamation mark (!) as a separator
- ▶ The actual process variable names
- ► A period (.) as a separator
- ► A suffix

Info: Prefix and suffix are optional

Example:

With prefix and suffix: weo52!pvxx1.Qword Or weo52!pvxx1._[0] In short: pvxx1



SUFFIXES

A part of the 64 bit process variable can be addressed using the suffix. The following suffixes can be used for the control computer and cell controller:

- ▶ QWord (64 bit)
- ▶ _[0], _[1] (32 bit, double word)
- ▶ Word_[0] ... Word_[3] (16 bit, word)
- ▶ Byte [0] ... Byte [7] (8 bit, byte)
- ▶ Bit [0] ... Bit [63] (bit)

6.2.3 Status

The address comprises:

- ► Any desired prefix
- ► An exclamation mark (!) as a separator
- ▶ The identifications for status information stated below

CONTROL COMPUTER (LR), HEAD COMPUTER (HEAD)

▶ LEITRECHNERKENNUNG

Addressing example: weo52!LEITRECHNERKENNUNG

The control computer is set as follows:

- 'H', 72 ... HAUS
- 'O', 79 ... STO
- 'V', 86 ... V3
- 'W', 87 ... A-Plus
- 'K', 75 ... Head computer
- ▶ BETRIEBSZUSTAND

Addressing example: weo52!BETRIEBSZUSTAND

The following control computer states are possible:



- '1', 31 ... Ready for operation
- '2', 32 ... Not ready for operation
- ► LOG_LINKZUSTAND[0] ... LOG_LINKZUSTAND[6]

Addressing example: weo52!log LINKZUSTAND[2]

The logical link state displays whether data exchange is permitted with a computer or not. Only the local connection state (local perspective) can be changed by command in the dialog. The character array contains a corresponding letter for each system. The letter of its own system is always set.

- 'H', 72 ... HAUS
- 'O', 79 ... STO
- 'V', 86 ... V3
- 'W', 87 ... A-Plus
- 'K', 75 ... Head computer
- 'I', 73 ... Info-Plus computer
- 'Z', 90 ... Visualization server
- '_', 95 ... Connection inactive
- PHYS_LINKZUSTAND[0] ... PHYS_LINKZUSTAND[6]

Addressing example: weo52! PHYS LINKZUSTAND[6]

The physical connection status is kept internally in the PROCOM and cannot be influenced. Provides information on whether data exchange with a computer is technically possible.

- 'H', 72 ... HAUS
- 'O', 79 ... STO
- 'V', 86 ... V3
- 'W', 87 ... A-Plus
- 'K', 75 ... Head computer
- 'I', 73 ... Info-Plus computer
- 'Z', 90 ... Visualization server
- '_', 95 ... Connection inactive
- STATUS_NODE_A

Addressing example: weo52! STATUS NODE A

- 'M', 77 ... Node A in the master status
- 'S', 83 ... Node A in standby status



► STATUS NODE B

Addressing example: weo52! STATUS NODE B

- 'M', 77 ... Node A in the master status
- 'S', 83 ... Node A in standby status

GSV_MODE_NODE_A

Addressing example: weo52!gsv mode node a

- 'N', 78 ... Node A in restart status
- GSV_MODE_NODE_B

Addressing example: weo52!gsv_mode_node_B

- 'N', 78 ... Node A in restart status
- ► REPL NODE A

Addressing example: weo52!REPL NODE A

- 'H', 72 ... Replication active on node A (hot)
- 'C', 67 ... Replication inactive on node A (cold)

▶ REPL NODE B

Addressing example: WEO52!REPL_NODE_B

- 'H', 72 ... Replication active on node A (hot)
- 'C', 67 ... Replication inactive on node A (cold)

► AKTUELLE_ZEIT

Addressing example: Addressing example: weo52!AKTUELLE_ZEIT Current time on the system

► VERBINDUNGS_STATUS

Addressing example: Addressing example: weo52!verbindungs status

This variable provides the drive connection status to the control computer or head computer

- 0 ... No action
- 1 ... General query after new connection active
- 2 ... General query initiated by user active
- 3 ... Balance query active

► VERBINDUNGS_ZUSTAND:

Addressing example: Addressing example: weo52!verbindungs_zustand

This variable provides the connection status of the driver to the control computer or head computer



- 3 ... Unknown
- 2 ... Both faulty
- 1 ... One faulty
- 0 ... Both connected

CELL CONTROLLER (CC)

▶ BETRIEBSZUSTAND

Addressing example: Addressing example: weo52!verbindungs_zustand
The following control computer states are possible:

- '1', 31 ... Ready for operation
- '2', 32 ... Not ready for operation
- '3', 33 ... Initialization active
- ► BETRIEBSZUSTAND_WEXPERTE[0] ... BETRIEBSZUSTAND_WEXPERTE[99]

Addressing example: Addressing example: weo52!BETRIEBSZUSTAND_WEXPERTE[0]

- '1', 31 ... Ready for operation
- '2', 32 ... Not ready for operation

▶ LOG LINKZUSTAND

Addressing example: Addressing example: wEo52!Log LINKZUSTAND

The logical link state displays whether data exchange is permitted with a computer or not. Only the local connection state (local perspective) can be changed by command in the dialog. The character array contains a corresponding letter for each system. The letter of its own system is always set.

- 'L', 76 ... Connection active
- '?', 63... Connection state unknown
- '_', 95 ... Connection inactive

PHYS LINKZUSTAND

Addressing example: Addressing example: weo52! PHYS LINKZUSTAND

The physical connection status is kept internally in the PROCOM and cannot be influenced. Provides information on whether data exchange with a computer is technically possible.

- 'L', 76 ... Connection active
- '?', 63... Connection state unknown
- '_', 95 ... Connection inactive



► AKTUELLE_ZEIT

Addressing example: Addressing example: weo52!AKTUELLE_ZEIT Current time on the system

► VERBINDUNGS_STATUS

Addressing example: Addressing example: weo52!verbindungs_status

This variable provides the drive connection status to the control computer or head computer

- 0 ... No action
- 1 ... General query after new connection active
- 2 ... General query initiated by user active

► VERBINDUNGS_ZUSTAND:

Addressing example: Addressing example: weo52!verbindungs_zustand
This variable provides the driver connection status to the cell controller.

- 3 ... Unknown
- 2 ... Both faulty
- 1 ... One faulty
- 0 ... Both connected

6.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

6.3.1 Driver objects

The following object types are available in this driver:



| Driver object type | Channel type | Read / Write | Supported data types | Description |
|--------------------------------------|--------------|-----------------|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Process variable | 8 | R/W | BOOL, SINT, USINT, INT, UINT, DINT, UDINT, LINT, LWORD | Process variables. |
| Status | 64 | R | USINT, STRING, DATE_AND_TIME | Status. |
| Flight display for the target tracks | 65 | R | STRING | Flight display for the target tracks. |
| Balancing | 66 | R | STRING | Balancing the head computer |
| Trigger | 67 | S | UINT | Trigger for manual execution of a general query or head query (balance query). |
| Driver variable | 35 | R/W | BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING | Variable for the static analysis of the communication; is transferred between driver and Runtime (not to the PLC). Note: The addressing and the behavior is the same for most zenon drivers. |
| | | | | Find out more in the chapter about the Driver variables (on page 35) |

6.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.



| PLC | zenon | Data type |
|-------|-------------------|-----------|
| ULINT | BOOL | 8 |
| ULINT | USINT | 9 |
| ULINT | SINT | 10 |
| ULINT | UINT | 2 |
| ULINT | INT | 1 |
| ULINT | UDINT | 4 |
| ULINT | DINT | 3 |
| ULINT | ULINT | 27 |
| ULINT | LINT | 26 |
| - | REAL | 5 |
| - | LREAL | 6 |
| - | STRING | 12 |
| - | WSTRING | 21 |
| - | DATE | 18 |
| - | TIME | 17 |
| - | DATE_AND_TIME | 20 |
| - | TOD (Time of Day) | 19 |

Data type: The property Data type is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

6.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.

6.4.1 XML import of variables from another zenon project

For the import/export of variables the following is true:



- The import/export must not be started from the global project.
- The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type INT with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type STRING. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer INT variables, but STRING variables.

6.4.2 **DBF Import/Export**

Data can be exported to and imported from dBase.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... select the Import dBase command
- 3. follow the import assistant



The format of the file is described in the chapter File structure.



Info

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... Select the Export dBase command
- 3. follow the export assistant



Attention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.

e.g. the path C:\users\John.Smith\test.dbf is invalid.

Valid: C:\users\JohnSmith\test.dbf

must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



Info

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- ▶ correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ Be stored close to the root directory (Root)

DESIGN

| Description | Туре | Field size | Comment |
|-------------|------|------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| KANALNAME | Char | 128 | Variable name. |
| | | | The length can be limited using the MAX_LAENGE entry in project.ini . |
| KANAL_R | С | 128 | The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually). |
| | | | The length can be limited using the MAX_LAENGE entry in project.ini . |
| KANAL_D | Log | 1 | The variable is deleted with the $1\ \rm entry$ (field/column has to be created by hand). |
| TAGNR | С | 128 | Identification. |
| | | | The length can be limited using the MAX_LAENGE entry in project.ini . |
| EINHEIT | С | 11 | Technical unit |
| DATENART | С | 3 | Data type (e.g. bit, byte, word,) corresponds to the data type. |
| KANALTYP | С | 3 | Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type. |
| HWKANAL | Num | 3 | Bus address |
| BAUSTEIN | N | 3 | Datablock address (only for variables from the data area of the PLC) |
| ADRESSE | N | 5 | Offset |



| BITADR | N | 2 | For bit variables: bit address | |
|------------|-------|----|---------------------------------------------------------------------|--|
| DIIVDV | IN | | For byte variables: 0=lower, 8=higher byte | |
| | | | For string variables: Length of string (max. 63 characters) | |
| ARRAYSIZE | N | 16 | Number of variables in the array for index variables | |
| | | | ATTENTION: Only the first variable is fully available. All others | |
| | | | are only available for VBA or the Recipe Group Manager | |
| LES_SCHR | R | 1 | Write-Read-Authorization | |
| | | | 0: Not allowed to set value. | |
| | | | 1: Allowed to set value. | |
| MIT_ZEIT | R | 1 | time stamp in zenon (only if supported by the driver) | |
| OBJEKT | N | 2 | Driver-specific ID number of the primitive object | |
| | | | comprises KANALTYP and DATENART | |
| SIGMIN | Float | 16 | Non-linearized signal - minimum (signal resolution) | |
| SIGMAX | F | 16 | Non-linearized signal - maximum (signal resolution) | |
| ANZMIN | F | 16 | Technical value - minimum (measuring range) | |
| ANZMAX | F | 16 | Technical value - maximum (measuring range) | |
| ANZKOMMA | N | 1 | Number of decimal places for the display of the values | |
| | | | (measuring range) | |
| UPDATERATE | F | 19 | Update rate for mathematics variables (in sec, one decimal | |
| | | | possible) | |
| | | | not used for all other variables | |
| MEMTIEFE | N | 7 | Only for compatibility reasons | |
| HDRATE | F | 19 | HD update rate for historical values (in sec, one decimal possible) | |
| HDTIEFE | N | 7 | HD entry depth for historical values (number) | |
| NACHSORT | R | 1 | HD data as postsorted values | |
| DRRATE | F | 19 | Updating to the output (for zenon DDE server, in [s], one decimal | |
| | | | possible) | |
| HYST_PLUS | F | 16 | Positive hysteresis, from measuring range | |
| HYST_MINUS | F | 16 | Negative hysteresis, from measuring range | |
| PRIOR | N | 16 | Priority of the variable | |
| REAMATRIZE | С | 32 | Allocated reaction matrix | |
| | | | · | |



| ERSATZWERT | F | 16 | Substitute value, from measuring range |
|------------|---|-----|---------------------------------------------------------------------------------------------------------------------------------------------|
| SOLLMIN | F | 16 | Minimum for set value actions, from measuring range |
| SOLLMAX | F | 16 | Maximum for set value actions, from measuring range |
| VOMSTANDBY | R | 1 | Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks |
| RESOURCE | С | 128 | Resource label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini. |
| ADJWVBA | R | 1 | Non-linear value adaption: 0: Non-linear value adaption is used 1: non linear value adaption is not used |
| ADJZENON | С | 128 | Linked VBA macro for reading the variable value for non-linear value adjustment. |
| ADJWVBA | С | 128 | Linked VBA macro for writing the variable value for non-linear value adjustment. |
| ZWREMA | N | 16 | Linked counter REMA. |
| MAXGRAD | N | 16 | Gradient overflow for counter REMA. |
| | | | |

△ Attention.

When importing, the driver object type and data type must be amended to the target ${\it driver in the DBF file in order for variables to be imported.}$

LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 to 4:



| Description | Туре | Field size | Comment | |
|-------------|------|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| AKTIV1 | R | 1 | Limit value active (per limit value available) | |
| GRENZWERT1 | F | 20 | Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1 , the existing variable linkage is not overwritten) | |
| SCHWWERT1 | F | 16 | Threshold value for limit | |
| HYSTERESE1 | F | 14 | Hysteresis in % | |
| BLINKEN1 | R | 1 | Set blink attribute | |
| BTB1 | R | 1 | Logging in CEL | |
| ALARM1 | R | 1 | Alarm | |
| DRUCKEN1 | R | 1 | Printer output (for CEL or Alarm) | |
| QUITTIER1 | R | 1 | Must be acknowledged | |
| LOESCHE1 | R | 1 | Must be deleted | |
| VARIABLE1 | R | 1 | Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx) | |
| FUNC1 | R | 1 | Function linking | |
| ASK_FUNC1 | R | 1 | With interrogation before execution | |
| FUNC_NR1 | N | 10 | ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import) | |
| A_GRUPPE1 | N | 10 | Alarm/event group | |
| A_KLASSE1 | N | 10 | Alarm/event class | |
| MIN_MAX1 | С | 3 | Minimum, Maximum | |
| FARBE1 | N | 10 | Color as Windows coding | |
| GRENZTXT1 | С | 66 | Limit value text | |
| A_DELAY1 | N | 10 | Time delay | |
| INVISIBLE1 | R | 1 | Invisible | |

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.



6.5 **Driver variables**

The driver kit implements a number of driver variables. These are divided into:

- Information
- Configuration
- Statistics and
- **Error** messages

The definitions of the variables defined in the driver kit are available in the import file drvvar.dbf (on the CD in the directory: CD Drive:/Predefined/Variables) and can be imported from there.

Hint: Variable names must be unique in zenon. If driver variables are to be imported from drvvar.dbf again, the variables that were imported beforehand must be renamed.



Info

Not every driver supports all driver variants.

For example:

- Variables for modem information are only supported by modem-compatible drivers
- Driver variables for the polling cycle only for pure polling drivers
- Connection-related information such as ErrorMSG only for drivers that only edit one connection at a a time



INFORMATION

| Name from import | Туре | Offset | Description |
|-----------------------------|-------|--------|---------------------------------------|
| MainVersion | UINT | 0 | Main version number of the driver. |
| SubVersion | UINT | 1 | Sub version number of the driver. |
| BuildVersion | UINT | 29 | Build version number of the driver. |
| RTMajor | UINT | 49 | zenon main version number |
| RTMinor | UINT | 50 | zenon sub version number |
| RTSp | UINT | 51 | zenon service pack number |
| RTBuild | UINT | 52 | zenon build number |
| LineStateIdle | BOOL | 24.0 | TRUE, if the modem connection is idle |
| LineStateOffering | BOOL | 24.1 | TRUE, if a call is received |
| LineStateAccepted | BOOL | 24.2 | The call is accepted |
| LineStateDialtone | BOOL | 24.3 | Dialtone recognized |
| LineStateDialing | BOOL | 24.4 | Dialing active |
| LineStateRingBack | BOOL | 24.5 | While establishing the connection |
| LineStateBusy | BOOL | 24.6 | Target station is busy |
| LineStateSpecialInfo | BOOL | 24.7 | Special status information received |
| LineStateConnected | BOOL | 24.8 | Connection established |
| LineStateProceeding | BOOL | 24.9 | Dialing completed |
| LineStateOnHold | BOOL | 24.10 | Connection in hold |
| LineStateConferenced | BOOL | 24.11 | Connection in conference mode. |
| LineStateOnHoldPendConf | BOOL | 24.12 | Connection in hold for conference |
| LineStateOnHoldPendTransfer | BOOL | 24.13 | Connection in hold for transfer |
| LineStateDisconnected | BOOL | 24.14 | Connection stopped |
| LineStateUnknow | BOOL | 24.15 | Connection status unknown |
| ModemStatus | UDINT | 24 | Current modem status |
| TreiberStop | BOOL | 28 | Driver stopped |



| | | | For driver stop, the variable has the value TRUE and an OFF bit. After the driver has started, the variable has the value FALSE and no OFF bit. |
|--------------|-------|----|-------------------------------------------------------------------------------------------------------------------------------------------------|
| SimulRTState | UDINT | 60 | Informs the status of Runtime for driver simulation. |

CONFIGURATION

| Name from import | Туре | Offset | Description |
|------------------|--------|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ReconnectInRead | BOOL | 27 | If TRUE, the modem is automatically reconnected for reading |
| ApplyCom | BOOL | 36 | Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function). |
| ApplyModem | BOOL | 37 | Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet. |
| PhoneNumberSet | STRING | 38 | Telephone number, that should be used |
| ModemHwAdrSet | DINT | 39 | Hardware address for the telephone number |
| GlobalUpdate | UDINT | 3 | Update time in milliseconds (ms). |
| BGlobalUpdaten | BOOL | 4 | TRUE, if update time is global |
| TreiberSimul | BOOL | 5 | TRUE, if driver in sin simulation mode |
| TreiberProzab | BOOL | 6 | TRUE, if the variables update list should be kept in the memory |
| ModemActive | BOOL | 7 | TRUE, if the modem is active for the driver |



| Device | STRING | 8 | Name of the serial interface or name of the modem |
|----------------|--------|----|---------------------------------------------------------------------------------------|
| ComPort | UINT | 9 | Number of the serial interface. |
| Baud rate | UDINT | 10 | Baud rate of the serial interface. |
| Parity | SINT | 11 | Parity of the serial interface |
| ByteSize | SINT | 14 | Number of bits per character of the serial interface |
| | | | Value = 0 if the driver cannot establish any serial connection. |
| StopBit | SINT | 13 | Number of stop bits of the serial interface. |
| Autoconnect | BOOL | 16 | TRUE, if the modem connection should be established automatically for reading/writing |
| PhoneNumber | STRING | 17 | Current telephone number |
| ModemHwAdr | DINT | 21 | Hardware address of current telephone number |
| RxIdleTime | UINT | 18 | Modem is disconnected, if no data transfer occurs for this time in seconds (s) |
| WriteTimeout | UDINT | 19 | Maximum write duration for a modem connection in milliseconds (ms). |
| RingCountSet | UDINT | 20 | Number of ringing tones before a call is accepted |
| ReCallIdleTime | UINT | 53 | Waiting time between calls in seconds (s). |
| ConnectTimeout | UDINT | 54 | Time in seconds (s) to establish a connection. |



STATISTICS

| Name from import | Туре | Offset | Description |
|----------------------|-------|--------|--------------------------------------------------------------------------------|
| MaxWriteTime | UDINT | 31 | The longest time in milliseconds (ms) that is required for writing. |
| MinWriteTime | UDINT | 32 | The shortest time in milliseconds (ms) that is required for writing. |
| MaxBlkReadTime | UDINT | 40 | Longest time in milliseconds (ms) that is required to read a data block. |
| MinBlkReadTime | UDINT | 41 | Shortest time in milliseconds (ms) that is required to read a data block. |
| WriteErrorCount | UDINT | 33 | Number of writing errors |
| ReadSucceedCount | UDINT | 35 | Number of successful reading attempts |
| MaxCycleTime | UDINT | 22 | Longest time in milliseconds (ms) required to read all requested data. |
| MinCycleTime | UDINT | 23 | Shortest time in milliseconds (ms) required to read all requested data. |
| WriteCount | UDINT | 26 | Number of writing attempts |
| ReadErrorCount | UDINT | 34 | Number of reading errors |
| MaxUpdateTimeNormal | UDINT | 56 | Time since the last update of the priority group Normal in milliseconds (ms). |
| MaxUpdateTimeHigher | UDINT | 57 | Time since the last update of the priority group Higher in milliseconds (ms). |
| MaxUpdateTimeHigh | UDINT | 58 | Time since the last update of the priority group High in milliseconds (ms). |
| MaxUpdateTimeHighest | UDINT | 59 | Time since the last update of the priority group Highest in milliseconds (ms). |



| PokeFinish BOOL 55 | Goes to 1 for a query, if all current pokes were executed | |
|--------------------|-----------------------------------------------------------|--|
|--------------------|-----------------------------------------------------------|--|

ERROR MESSAGES

| Name from import | Туре | Offset | Description |
|-------------------|--------|--------|-----------------------------------------------------------------|
| ErrorTimeDW | UDINT | 2 | Time (in seconds since 1.1.1970), when the last error occurred. |
| ErrorTimeS | STRING | 2 | Time (in seconds since 1.1.1970), when the last error occurred. |
| RdErrPrimObj | UDINT | 42 | Number of the PrimObject, when the last reading error occurred. |
| RdErrStationsName | STRING | 43 | Name of the station, when the last reading error occurred. |
| RdErrBlockCount | UINT | 44 | Number of blocks to read when the last reading error occurred. |
| RdErrHwAdresse | UDINT | 45 | Hardware address when the last reading error occurred. |
| RdErrDatablockNo | UDINT | 46 | Block number when the last reading error occurred. |
| RdErrMarkerNo | UDINT | 47 | Marker number when the last reading error occurred. |
| RdErrSize | UDINT | 48 | Block size when the last reading error occurred. |
| DrvError | SINT | 25 | Error message as number |
| DrvErrorMsg | STRING | 30 | Error message as text |
| ErrorFile | STRING | 15 | Name of error log file |

7. Driver-specific functions

This driver supports the following functions:



MANUAL INITIATION OF A GENERAL QUERY

▶ Creation of a trigger driver object variable and the name or identification consisting of an optional prefix and the character sequence GA.

For example: MyPrefix!GA or GA

- ▶ Assignment to a connection is carried out using the network address.
- A general query is triggered by writing a value to a variable. In doing so, the value written is used as a GA type.
 - GA type: 1 ... All PVs
 - GA type: 2 ... Only special PVs



Info

The status of the general query can be queried using the VERBINDUNGS STATUS status variable.

INITIATION OF A BALANCE QUERY FROM THE HEAD COMPUTER

- ▶ Creation of a balances driver object string variable.
- ▶ Creation of a trigger driver object variable and the name or identification consisting of an optional prefix and the character sequence BILANZEN.

For example: MyPrefix!BILANZEN or BILANZEN

- Assignment of variables to a connection is carried out using the network address.
- A head query is triggered by writing a value to a variable. In doing so, the value written is used as a statistic type.
 - Statistic type: 1 ... statistic for live operation
 - Statistic type: 2 ... operational transmission statistics



Info

The status of the head query can be queried using the VERBINDUNGS_STATUS status variable.

The balance information is stored in a balance driver object string variable. Assignment to a connection is carried out using the network address.




8. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function <code>Driver</code> commands. To do this:

- create a new function
- select Variables -> Driver commands
- ▶ The dialog for configuration is opened



| Parameters | Description |
|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Drivers | Drop-down list with all drivers which are loaded in the project. |
| Current state | Fixed entry which has no function in the current version. |
| Driver commands | Drop-down list for the selection of the command. |
| <pre>Start driver (online mode)</pre> | Driver is reinitialized and started. |
| <pre>> Stop driver (offline mode)</pre> | Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20). |



| Driver in simulation mode | Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed. |
|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Driver in hardware mode | Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed. |
| <pre>Driver-specific command</pre> | Enter driver-specific commands. Opens input field in order to enter a command. |
| ▶ Activate driver write set value | Write set value to a driver is allowed. |
| <pre>Deactivate driver write set value</pre> | Write set value to a driver is prohibited. |
| ▶ Establish connection with modem | Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number. |
| ▶ Disconnect from modem | Terminate connection (for modem drivers) |
| Show this dialog in the Runtime | The dialog is shown in Runtime so that changes can be made. |

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the driver command function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

9. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.



9.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under Start/All programs/zenon/Tools 7.00 -> Diagviewer.

zenon driver log all errors in the log files. The default folder for the log files is subfolder <u>log</u> in directory ProgramData, example: C:\ProgramData\zenon \zenon700\LOG for zenon version 7.00 SPO. Log files are text files with a special structure.

Attention: With the default settings, a driver only logs error information. With the <code>piagnosis</code> viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- customize the logging settings
- change the folder in which the log files are saved

Hints:

- 1. In Windows CE even errors are not logged per default due to performance reasons.
- 2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- 3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property Add all columns with entry in the context menu of the column header.
- 4. If you only use Error logging, the problem description is in column Error text. For other diagnosis level the description is in column General text.
- 5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in Error text and/or Error code and/or Driver error parameter (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.



6. At the end of your test set back the diagnosis level from pebug or peep pebug. At pebug and Deep Debug there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.



Info

You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.

9.2 Check list

Questions and hints for fault isolation:

GENERAL TROUBLESHOOTING

- Analysis with the Diagnosis Viewer (on page 44):
 - -> Which messages are displayed?
- ► Are the participants available in the TCP/IP network?
- ► Can the PLC be reached via the Ping command?

Ping: Open command line -> ping < IP address> (e.g. ping 192.168.0.100) -> press Enter.

Do you receive an answer with a time or a time-out?

▶ Can the PLC be reached via Telnet?

Telnet: Open command line, telent <enter IP address port number> (e.g. for Modbus: telnet 192.168.0.100 502) -> press Enter.

If the monitor display turns black, a connection could be established.

- Did you configure the Net address in the address properties of the variable correctly?
 - Does the addressing match with the configuration in the driver dialog?



- Does the net address match the address of the target station?
- ▶ Did you use the right object type for the variable?

Example: Driver variables are purely statistics variables. They do not communicate with the PLC. (See chapter Driver variable (on page 35).)

SOME VARIABLES REPORT INVALID.

- ▶ INVALID bits always refer to a net address.
- ▶ At least one variable of the net address is faulty.

VALUES ARE NOT DISPLAYED, NUMERIC VALUES REMAIN EMPTY

Driver is not working. Check the:

- ► Installation of zenon
- ▶ the driver installation
- ▶ The installation of all components
 - -> Pay attention to error messages during the start of the Runtime.

VARIABLES ARE DISPLAYED WITH A BLUE DOT

The communication in the network is faulty:

- With a network project:
 Is the network project also running on the server?
- With a stand-alone project or a network project which is also running on the server: Deactivate the property Only read from standby in node Driver connection/Addressing.

VALUES ARE DISPLAYED INCORRECTLY

Check the information for the calculation in node Value calculation of the variable properties.



DRIVER FAILS OCCASIONALLY

Analysis with the Diagnosis Viewer (on page 44):

-> Which messages are displayed?