


zenon driver manual





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



Contents

1.	Welc	ome to	COPA-DATA help	5
2.	Logix	32		5
3.	LOGI	X32 - Da	ata sheet	(
4.	Drive	r histor	у	7
5.	Requ	irement	ts	7
	5.1	PC		8
	5.2	PLC		8
6.	Confi	guratio	n	8
	6.1	Creatin	g a driverg	8
	6.2	Setting	s in the driver dialog	10
		6.2.1	General	10
		6.2.2	TCP configuration	13
		6.2.3	TCP/IP connection	14
7.	Creat	ing vari	ables	16
	7.1	Creatin	g variables in the Editor	16
	7.2	Addres	sing	19
	7.3	Driver o	objects and datatypes	2 3
		7.3.1	Driver objects	23
		7.3.2	Mapping of the data types	2 3
	7.4	Creatin	g variables by importing	24
		7.4.1	XML import of variables from another zenon project	25
		7.4.2	DBF Import/Export	25
		7.4.3	Offline import	31
		7.4.4	Variable export	34
	7.5	Driver \	variables	36
8.	Drive	r-specif	fic functions	41
۵	Drive	r comm	ands	A *



10. Error	.0. Error analysis				
10.1	Error entries	44			
10.2	Analysis tool	45			
10.3	Check list	47			



1. Welcome to COPA-DATA help

GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

2. Logix32

This driver is used for connecting to one ore more Logix PLCs via a network connection.



3. LOGIX32 - Data sheet

General:	
Driver file name	LOGIX32.exe
Driver description	Allen-Bradley Logix Ethernet
PLC types	ControlLogix 5550 and 5555 PLCs are supported; Compact Logix Ethernet PLC L35E are supported; MicroLogix PLCs are not supported.
PLC manufacturer	Allen-Bradley; Rockwell;

Driver supports:	
Protocol	EtherNet/IP;
Addressing: address based	-
Addressing: name based	x
Spontaneous communication	-
Polling communication	x
Online browsing	x
Offline browsing	x
Real-time capable	-
Blockwrite	x
Modem capable	-
Serial logging	-
RDA numerical	-



RDA String	-

Prerequisites:	
Hardware PC	Standard network card
Software PC	-
Hardware PLC	ControlLogix needs AB 1756 ENET interface card
Software PLC	-
Requires v-dll	-

Platforms:	
Operating systems	Windows CE 5.0, CE 6.0; Windows XP, Vista, 7, Server 2003, Server 2008/R2;
CE platforms	x86; ARM; Pocket-PC;

4. Driver history

Date	Driver version	Change
07.07.08	3400	Re-created driver documentation
22.10.08	4100	added private and alias variables

5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.



5.1 PC

This driver supports a connection via the standard network card of the PC. Make sure that the PLC and the PC are in the same network range and that the subnet masks are set accordingly on both devices.

5.2 PLC

PLC can be configured with tools (AllanBradley).

6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.



Info


Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.


6.1 **Creating a driver**

In order to create a new driver:

▶ Right-click on Driver in the Project Manage and select Driver new in the context menu.








- Select the desired driver and give it a name:
 - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.
 - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (_).
 - Attention: This name cannot be changed later on.
- ► Confirm the dialog with ox. In the following dialog the single configurations of the drivers are defined.
- ▶ Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.






6.2 Settings in the driver dialog

You can change the following settings of the driver:

6.2.1 General





Parameters	Description
Mode	Allows to switch between hardware mode and simulation mode Hardware: A connection to the control is established. Simulation static No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area, e.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver. Simulation - counting
	No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically. Simulation - programmed N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver
Keep update list in the memory	simulation (main.chm::/25206.htm). Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.
Output can be written	Active: Outputs can be written. Inactive: Writing of outputs is prevented. Note: Not available for every driver.



Variable image remanent	This option saves and restores the current value, time stamp and the states of a data point.
	Fundamental requirement: The variable must have a valid value and time stamp.
	The variable image is saved in mode hardware if:
	one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active
	The variable image is always saved if:
	▶ the variable is of the object type Driver variable
	the driver runs in simulation mode. (not programmed simulation)
	The following states are not restored at the start of the Runtime:
	► SELECT(8)
	▶ WR-ACK(40)
	▶ WR-SUC(41)
	The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image.
Stop at the Standby Server	Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.
	Attention: If this option is active, the gapless archiving is no longer guaranteed.
	Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (statusverarbeitung.chm::/24150.htm) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.
Global Update time	Active: The set Global update time in ms is used for all variables in the project. The priority set at the variables is not used. Inactive: The set priorities are used for the individual variables.
Priority	Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken



place for each variable separately in the settings of the variable properties.


The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities. Thus the communication load is distributed better.

UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For Set value, Advising of variables and Requests, a read cycle is immediately triggered for all drivers regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.


6.2.2 TCP configuration





Parameters	Description
TCP configuration file	The file Default.lix is set by default and has to be in the current project directory. The filename Default.lix can be changed for a project by simply overwriting it.
Error waiting time (ms)	If the connection fails, the driver will take this amount of time between re-attempts to establish communication. Shorter times result in a higher need of network resources.
Use identification for external name	The name of the variable is not resolved via the name but via the identification.

6.2.3 TCP/IP connection





Parameters	Description
Connection file	Selected configuration file
Connections	Displays the connection names with the corresponding hardware addresses. By selecting the connection name with the mouse the connection parameters are displayed.
Net address	Corresponds to the net address of the variable definition.
Name	Freely definable name.
IP address	IP address, depends on the settings of the AB 1756 ENET communication processor.
Timeout	Timeout time in milliseconds for the response from the communication processor.
CPU insertion number	Number of the slot into which the CPU was inserted.
New	Create new connection
Edit	Edit existing connection
	Select the desired connection in the connection list, press button "Edit Conn.". Make changes and close with "Save".
Delete	Delete existing connection
Save	Save new/amended entries.
Cancel	Discard amended entries.
OK	Accept changes in the dialog and close dialog.
	Only available if no connection is in the "edit" state.
Cancel	Discards all changes and closes dialog.
Help	Opens online help.



Maximum number of connections: 256 (0-255).

CREATE NEW CONNECTION

1. click on the button New



- 2. Enter the connection details.
- 3. Click on save

EDIT CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Edit
- 3. change the connection parameters
- 4. finish with save

DELETE CONNECTION

- 1. select the connection in the connection list
- 2. click on the button Delete
- 3. the connection will be removed from the list

SHOW CONNECTION DETAILS

Highlight the desired connection in the connection list.

7. Creating variables

This is how you can create variables in the zenon Editor:

7.1 Creating variables in the Editor

Variables can be created:

- ▶ as simple variables
- ▶ in arrays main.chm::/15262.htm




▶ as structure variables main.chm::/15278.htm

VARIABLE DIALOG

To create a new variable, regardless of which type:

Select the New variable command in the variables node in the context menu



- 2. The dialog for configuring variables is opened
- 3. configure the variable



4. The settings that are possible depends on the type of variables



Property	Description
Name	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name. Attention: The # character is not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive.
Drivers	Select the desired driver from the drop-down list. Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.
Driver object type (cti.chm::/28685.h tm)	Select the appropriate driver object type from the drop-down list.



Data type	Select the desired data type. Click on the button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- ► Automatically adapted if the data type is changed

Note for signal range: If a change is made to a data type that does not support the set signal range, the signal range is amended automatically. For example, for a change from INT to SINT, the signal range is changed to 127. The amendment is also carried out if the signal range was not inherited from the data type. In this case, the measuring range must be adapted manually.

7.2 Addressing

The driver communicates on a name basis (via the variable name) or optionally, via the identification.



Property	Description
Name	Freely definable name
	Attention: the name must be unique within each control system project. The name will be used for the unique addressing.
Identification	Any text can be entered here, e.g. for resource labels, comments, etc. Optionally, the identification can be used for addressing. Please make sure that the name is not used a second time with a different data type.
Net address	Bus address or net address of the variable.
	This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides.
Data block	not used for this driver
Offset	not used for this driver
Alignment	not used for this driver
Bit number	not used for this driver
String length	Only available for String variables: Maximum number of characters that the variable can take. Must always be entered manually. The online import does not support any Strings.
Driver object type	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.
Data type	Data type of the variable, which is selected during the creation of the variable; the type can be changed here later.
	ATTENTION: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.

LIMITATIONS

Only global, private and alias variables are supported.

The following pre-defined data types are supported for these tags: (TIMER, COUNTER, PID, STRING, BOOL, BYTE, INT, SINT, UINT, USINT, WORD, DINT, UDINT, DWORD, REAL, LREAL)

The variable names are case sensitive.

Creating string variables via browsing (see below) is not possible; you have to manually create the zenon String variables with the same variable names or the same variable identifications that are used in the PLC.



Example: There is a String structure in the PLC that looks as follows:

- ▶ long StringStrukt.LEN
- char StringStrukt.DATA[60]

Please enter "stringstrukt.DATA[0]" as the name or identification.

Also, copy the array length (in this case: 60 Bytes) to the field String length.

There must be no other variable with the same name and a

different data type!

There must be no additional Byte variable with this name.

CONTROL LOGIX VARIABLE TYPES

All pre-defined and user-defined variables (tags) are supported. You can access single bits of the following basic data types via variable name/bit number.

Tag or array type	Sub element
SINT	/00 - 07 Example: MySINT/01
INT	/00 - 15 Example: MyINT/03
DINT	/00 - 31 Example: MyDINT/23

ZENON ARRAY VARIABLES

A zenon array variable represents a memory area (arrays or structures) of the Control Logix.

You have read and write access to the zenon array variable via the Recipe Manager and VBA. One advantage of the Control Logix is that block reading and block writing is very efficient. Supported driver objects for array variables are (i/u8Bit ,i/u16Bit ,i/u32Bit ,float).

A zenon array variable is created via the variable dialog. Enter the size of the array in the input field "Array size". If you have the same data type as you have on the Control Logix, you also have to enter the same dimension in the input field "Array size".

[&]quot;StringStrukt.DATA[0]".



Example

Example1 with a Control Logix array: There is a global variable UDINT arTest[106] on the Control Logix. See the illustration below for the definition on the zenon page.

You can also put a zenon array variable over a Control Logix structure. This means that an unformatted binary dump of the structure will be read and written.

A zenon array variable is created via the variable dialog. Enter the size of the structure in the input field "Array size".

If it is an "i/u8Bit" array, you have to enter the size of the structure in Bytes in the input field "Array size".

If it is an "i/u16Bit" array, you have to enter the size of the structure in Bytes/2 in the input field "Array size".

If it is an "i/u32Bit" array, you have to enter the size of the structure in Bytes/4 in the input field "Array size".

If it is a "float" array, you have to enter the size of the structure in Bytes/4 in the input field "Array size".



Info

The number of Bytes contained in a structure or an array can be found out in the development environment (RSLogix 5000).



Example

Example 2 with a Control Logix structure: There is a global variable STRUKT1 sStrukt1 on the Control Logix; its size is 100 Bytes. See the illustration below for the definition on the zenon page.



7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

7.3.1 Driver objects

The following object types are available in this driver:

Driver object type	Channel type	Read / Write	Supported data types	Comment
PLC marker	35	R/W	REAL, BOOL, DINT, UDINT, USINT, INT, UINT, SINT, STRING	
Driver variable	35	R/W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the statistical analysis of communication. Find out more in the chapter about the Driver variables (on page 36)

7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.



PLC	zenon	Data type
BOOL	BOOL	8
SINT	USINT	9
SINT	SINT	10
INT	UINT	2
INT	INT	1
DINT	UDINT	4
DINT	DINT	3
-	ULINT	27
-	LINT	26
REAL	REAL	5
-	LREAL	6
SINT[82]	STRING	12
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19

Data type: The property Data type is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



7.4.1 XML import of variables from another zenon project

For the import/export of variables the following is true:

- The import/export must not be started from the global project.
- The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type INT with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type STRING. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer INT variables, but STRING variables.

7.4.2 **DBF Import/Export**

Data can be exported to and imported from dBase.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... select the Import dBase command
- 3. follow the import assistant



The format of the file is described in the chapter File structure.



Info

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... Select the Export dBase command
- 3. follow the export assistant



Attention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.

e.g. the path C:\users\John.Smith\test.dbf is invalid.

Valid: C:\users\JohnSmith\test.dbf

must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



Info

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- ▶ correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ Be stored close to the root directory (Root)

DESIGN

Description	Туре	Field size	Comment
KANALNAME	Char	128	Variable name.
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually).
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_D	Log	1	The variable is deleted with the $1\ \rm entry$ (field/column has to be created by hand).
TAGNR	С	128	Identification.
			The length can be limited using the MAX_LAENGE entry in project.ini .
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset



BITADR N	2	For bit variables: bit address
1		For byte variables: 0=lower, 8=higher byte
		For string variables: Length of string (max. 63 characters)
ARRAYSIZE N	16	Number of variables in the array for index variables
		ATTENTION: Only the first variable is fully available. All others
		are only available for VBA or the Recipe Group Manager
		are only available for VBA of the Necipe Group ividinager
LES SCHR R	1	Write-Read-Authorization
_		0: Not allowed to set value.
		1: Allowed to set value.
MIT_ZEIT R	1	time stamp in zenon (only if supported by the driver)
OBJEKT N	2	Driver-specific ID number of the primitive object
		comprises KANALTYP and DATENART
OT CMTN	16	New Processing distance I are in the constant and the con
SIGMIN Flo	oat 16	Non-linearized signal - minimum (signal resolution)
SIGMAX F	16	Non-linearized signal - maximum (signal resolution)
		(-8
ANZMIN F	16	Technical value - minimum (measuring range)
ANZMAX F	16	Technical value - maximum (measuring range)
ANZKOMMA N	1	Number of decimal places for the display of the values
ANZIOTITA	1	
		(measuring range)
UPDATERATE F	19	Update rate for mathematics variables (in sec, one decimal
		possible)
		not used for all other variables
		The diseases for all other variables
MEMTIEFE N	7	Only for compatibility reasons
	1.5	
HDRATE F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE N	7	HD entry depth for historical values (number)
110111111	,	The entry depart for historical values (number)
NACHSORT R	1	HD data as postsorted values
DRRATE F	19	Updating to the output (for zenon DDE server, in [s], one decimal
		possible)
HYST PLUS F	16	Docitive hystoresis from measuring range
HYST_PLUS F	16	Positive hysteresis, from measuring range
HYST MINUS F	16	Negative hysteresis, from measuring range
PRIOR N	16	Priority of the variable
REAMATRIZE C	32	Allocated reaction matrix



F	16	Substitute value, from measuring range
F	16	Minimum for set value actions, from measuring range
F	16	Maximum for set value actions, from measuring range
R	1	Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks
С	128	Resource label.
		Free string for export and display in lists.
		The length can be limited using the MAX_LAENGE entry in project.ini .
R	1	Non-linear value adaption:
		0: Non-linear value adaption is used
		1: non linear value adaption is not used
С	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
С	128	Linked VBA macro for writing the variable value for non-linear value adjustment.
N	16	Linked counter REMA.
N	16	Gradient overflow for counter REMA.
	F F R C C	F 16 F 16 R 1 C 128 C 128 C 128 N 16



△ Attention.

When importing, the driver object type and data type must be amended to the target ${\it driver in the DBF file in order for variables to be imported.}$

LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 to 4:



Description	Туре	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1 , the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Hysteresis in %
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Function linking
ASK_FUNC1	R	1	With interrogation before execution
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	С	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	С	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.



7.4.3 Offline import

The offline import makes it possible to import variables from file LOGIX_PDFEF.txt. Only real variables are imported, no alias.




Attention

The file LOGIX_PDEF.txt must be in the same folder as the driver EXE file for the import. The definitions of all predefined types that are necessary for import from L5K files are contained in this.

IMPORTING VARIABLES

Right click on the driver and select Import variable from the driver... from the context menu Alternatively, you can also click on the corresponding button in the toolbar to start the import of variables.



The following settings are available.




Parameters	Description
Connection	Select an existing connection. You configure the connections under TCP/IP connection (on page 14).
Prefix	If you would like to issue the variable to be imported with a prefix, enter the desired prefix.
Import of	 Select the import source using the option field: Online Import - import the variables directly from the PLC Offline Import - Here, the variables are imported from the L5K file. To do this, enter the path to the desired L5K file or select it using the file selection dialog. Click on , to display the file selection dialog.
Filter	Note: The program list is automatically imported as soon as you activate the checkbox. Activate the checkbox if you would like to use a filter. You have the possibility to filter according to: Data types Programs Variable groups (all variables, only global variables, only local variables)
Options	
Offer only not available variables	Activate this checkbox if only the variables that do not exist in zenon are to be displayed.
Search for variables to be deleted	Activate this checkbox if you would like to have an additional variable selection dialog displayed, in which all variables are displayed that exist for this driver in zenon but not in the PLC. Variables that you select in this dialog are deleted.

Click on \mathbf{Next} to import the variables.








Parameters	Description
Name	Name and/or address of the variables in the PLC and/or in zenon.
Data type	Data type of the variable in zenon.
Alias	1, if the variable is an alias variable, otherwise 0 .
Internal	1, if the variable is an internal variable, otherwise 0.
	Note for Logix ODVA: Internal variables are created here as SPECIAL MARKERS, because they can only be read by the ODVA driver as unblocked.

Insert the desired variables and click on ox to create them.



If you have activated Search for variables to be deleted, the following dialog is displayed to you.



Parameters	Description
Name or identification	Name or identification of the variable, depending on the setting in the driver configuration for addressing. Contains the address or the name of the variable as it exists in the PLC.
Name	Name of the variable in zenon.

7.4.4 Variable export

VARIABLE EXPORT TO *.CSV FILE

For zenon 5.50, the driver of version Logix32.exe "5.2.0.20" and above and Logix32V.dll "5.2.0.3" and above received an option to export variables of a controller tag in the browser dialog to a *.csv file.

The dialog contains two new elements: the "Show all tags" checkbox and the file button.



Show all tags:

With this option, all items of a controller tag will be displayed, even the ones that have already been included in zenon.

This button opens the "Save as" dialog, which allows you to specify the location for storing the *.csv file. After confirming the "Save as" dialog, the file will be stored - with all items of the controller tag, even the ones that are not displayed.

File structure:

The file starts with a HEADER that contains the time and the driver revision.

Then, the items follow, according to the following structure:

variable name;data type;current value

'DATETIME: 12.07.04 08:53:30

'DRIVER-REVISION:5.2.0.20

Schachteltest_Theo.Ebene0.Ebene1.Ebene2.Variable1;INT;21

Schachteltest_Theo.Ebene0.Ebene1.Ebene2.Variable2;INT;22

Schachteltest_Theo.Ebene0.Ebene1.Ebene2.Variable3;INT;23

 $Schachteltest_Theo.Ebene 0. Ebene 1. Ebene 2. Variable 4; INT; 24$

35



7.5 **Driver variables**

The driver kit implements a number of driver variables. These are divided into:

- Information
- Configuration
- Statistics and
- Error messages

The definitions of the variables defined in the driver kit are available in the import file drvvar.dbf (on the CD in the directory: CD Drive:/Predefined/Variables) and can be imported from there.

Hint: Variable names must be unique in zenon. If driver variables are to be imported from drvvar.dbf again, the variables that were imported beforehand must be renamed.



Not every driver supports all driver variants.

For example:

- Variables for modem information are only supported by modem-compatible drivers
- Driver variables for the polling cycle only for pure polling drivers
- Connection-related information such as ErrorMSG only for drivers that only edit one connection at a a time



INFORMATION

Name from import	Туре	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon service pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection stopped
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped



			For driver stop, the variable has the value TRUE and an OFF bit. After the driver has started, the variable has the value FALSE and no OFF bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

CONFIGURATION

Name from import	Туре	Offset	Description
ReconnectInRead	BOOL	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet.
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver



Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	SINT	14	Number of bits per character of the serial interface
			Value = 0 if the driver cannot establish any serial connection.
StopBit	SINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UDINT	54	Time in seconds (s) to establish a connection.



STATISTICS

Name from import	Туре	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group нідь in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).



PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

ERROR MESSAGES

Name from import	Туре	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	UDINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	SINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

8. Driver-specific functions

This driver supports the following functions:

BLOCKWRITE:

If you want to set many value at the same time (e.g. for recipes), you can pack the individual variables together and send them in a few telegrams.



Activating blockwrite in the Projekt.ini file:

[LOGIX]


BLOCKWRITE=1

9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function <code>Driver</code> commands. To do this:

- create a new function
- ▶ select Variables -> Driver commands
- ▶ The dialog for configuration is opened





Parameters	Description
Drivers	Drop-down list with all drivers which are loaded in the project.
Current state	Fixed entry which has no function in the current version.
Driver commands	Drop-down list for the selection of the command.
> Start driver (online mode)	Driver is reinitialized and started.
▶ Stop driver (offline	Driver is stopped. No new data is accepted.
mode)	Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20).
Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
Activate driver write set value	Write set value to a driver is allowed.
Deactivate driver write set value	Write set value to a driver is prohibited.
▶ Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
Show this dialog in the Runtime	The dialog is shown in Runtime so that changes can be made.

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the driver command function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project



server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

10.1 Error entries

The driver writes error entries in plain text.

COMMON ERROR MESSAGES

Number	Meaning	Reason
CIP		
-1	EIPERROR	Error in the communication via Ethernet IP of TCP.
-2	TIMEOUT	Timeout error.
-3	PROT	Error in the CIP protocol.
0	OK	Successful communication.
EIP		
0	TIMEOUT	Timeout error.
-1	ERROR	Protocol error or TCP error.
-2	BUFFER	Insufficient buffer size.

Error array size

If you specified an array size that was to big, the following entry will be written to the log file.

11.06.04 11:25:17 | Error to Large Array Bytesize:10968 for this zenon Variables the Logix Bytesize:10960 Typesize:10960 GetDataFromTag:Logix32Dump Item:Logix32Dump from IP Adress:192.168.0.212 Failed HW:0 SocketError:0x0 Para1=0 Para2=0

This says that 10968 Bytes were queried, but only 10960 are available on the PLC.

10.2 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.00 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder <u>log</u> in directory ProgramData, example: C:\ProgramData\zenon \zenon700\LOG for zenon version 7.00 SPO. Log files are text files with a special structure.

Attention: With the default settings, a driver only logs error information. With the <code>piagnosis</code> <code>viewer</code> you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.



In the Diagnosis Viewer you can also:

- follow currently created entries live
- customize the logging settings
- change the folder in which the log files are saved

Hints:

- 1. In Windows CE even errors are not logged per default due to performance reasons.
- The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property Add all columns with entry in the context menu of the column header.
- 4. If you only use Error logging, the problem description is in column Error text. For other diagnosis level the description is in column General text.
- 5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in Error text and/or Error code and/or Driver error parameter (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 6. At the end of your test set back the diagnosis level from Debug Or Deep Debug. At Debug and Deep Debug there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.



You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.



10.3 Check list

Cable disconnected.

Wrong network parameters in the CP or PC.

Wrong String length (too long).

Too slow: scattered data areas; increase update time.

When resolving the name via the identification, make sure that you use a unique identification.

There will be a problem if you configured several connections with the same identification in one driver. (Change DriverKit 5.50 SP6)