




**COPADATA**  
do it your way

# zenon driver manual

**CTI**

**v.7.00**





© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.

# Contents

<b>1. Welcome to COPA-DATA help .....</b>	<b>5</b>
<b>2. CTI .....</b>	<b>5</b>
<b>3. CTI - Data sheet .....</b>	<b>6</b>
<b>4. Driver history .....</b>	<b>7</b>
<b>5. Requirements.....</b>	<b>8</b>
<b>6. Configuration .....</b>	<b>8</b>
6.1 Creating a driver.....	8
6.2 Settings in the driver dialog .....	10
6.2.1 General .....	10
6.2.2 Driver dialog 1 .....	13
<b>7. Creating variables.....</b>	<b>15</b>
7.1 Creating variables in the Editor.....	15
7.2 Addressing.....	17
7.3 Secondary object type .....	18
7.4 Driver objects and datatypes .....	21
7.4.1 Driver objects .....	21
7.4.2 Mapping of the datatypes .....	22
7.5 Creating variables by importing.....	23
7.5.1 XML import of variables from another zenon project.....	24
7.5.2 DBF Import/Export .....	24
7.6 Driver variables .....	30
<b>8. Driver-specific functions .....</b>	<b>35</b>
<b>9. Driver commands .....</b>	<b>37</b>
<b>10. Error analysis.....</b>	<b>38</b>
10.1 Analysis tool .....	39
10.2 Analysis for wrongly addressed variables .....	40

10.3 Check list .....45

# 1. Welcome to COPA-DATA help

## GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: [documentation@copadata.com](mailto:documentation@copadata.com) (<mailto:documentation@copadata.com>).

## PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: [support@copadata.com](mailto:support@copadata.com) (<mailto:support@copadata.com>)

## LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: [sales@copadata.com](mailto:sales@copadata.com) (<mailto:sales@copadata.com>)

# 2. CTI

Driver for CTI or Texas Instruments TI 505 for protocols CAMP, NITP with packed task codes.

The driver supports:

- ▶ several TCP connections (controls) per driver
- ▶ Multi block read via packed task codes
- ▶ Blockwrite.

### 3. CTI - Data sheet

<b>General:</b>	
Driver file name	CTI.exe
Driver description	CTI driver
PLC types	CTI PLCs, Ti505, Simatic 545, Simatic 555
PLC manufacturer	Siemens; Texas Instruments; CTI;

<b>Driver supports:</b>	
Protocol	NITP; CAMP;
Addressing: address based	x
Addressing: name based	-
Spontaneous communication	-
Polling communication	x
Online browsing	-
Offline browsing	-
Real-time capable	-
Blockwrite	x
Modem capable	-

Serial logging	-
RDA numerical	x
RDA String	x

Prerequisites:	
Hardware PC	Standard networkcard
Software PC	-
Hardware PLC	-
Software PLC	-
Requires v-dll	x

Platforms:	
Operating systems	Windows CE 5.0, CE 6.0; Windows XP, Vista, 7, Server 2003, Server 2008/R2;
CE platforms	x86; ARM; Pocket-PC;

## 4. Driver history

Date	Driver version	Change
16.03.10	100	Created driver documentation

## 5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

## 6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.



### Info


*Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.*

### 6.1 Creating a driver

In order to create a new driver:

- ▶ Right-click on **Driver** in the Project Manage and select **Driver new** in the context menu.

- ▶ In the following dialog the control system offers a list of all available drivers.



- ▶ Select the desired driver and give it a name:
  - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.
  - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (\_).
  - **Attention:** This name cannot be changed later on.
- ▶ Confirm the dialog with **OK**. In the following dialog the single configurations of the drivers are defined.
- ▶ Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.

### Info

*For new projects and for existing projects which are converted to version 6.21 or higher, the following drivers are created automatically:*


- ▶ Internal
- ▶ MathDr32
- ▶ SysDrv.



## 6.2 Settings in the driver dialog

You can change the following settings of the driver:

### 6.2.1 General



Parameters	Description
Mode	<p>Allows to switch between hardware mode and simulation mode</p> <ul style="list-style-type: none"> <li>▶ Hardware: <p>A connection to the control is established.</p> </li> <li>▶ Simulation static <p>No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area, e.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.</p> </li> <li>▶ Simulation - counting <p>No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically.</p> </li> <li>▶ Simulation - programmed <p>N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).</p> </li> </ul>
Keep update list in the memory	<p>Variables which were requested once are still requested from the control even if they are currently not needed.</p> <p>This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.</p>
Output can be written	<p>Active: Outputs can be written.</p> <p>Inactive: Writing of outputs is prevented.</p> <p><b>Note:</b> Not available for every driver.</p>

Variable image remanent	<p>This option saves and restores the current value, time stamp and the states of a data point.</p> <p>Fundamental requirement: The variable must have a valid value and time stamp.</p> <p>The variable image is saved in mode hardware if:</p> <ul style="list-style-type: none"> <li>▶ one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active</li> </ul> <p>The variable image is always saved if:</p> <ul style="list-style-type: none"> <li>▶ the variable is of the object type <code>Driver variable</code></li> <li>▶ the driver runs in simulation mode. (not programmed simulation)</li> </ul> <p>The following states are not restored at the start of the Runtime:</p> <ul style="list-style-type: none"> <li>▶ SELECT(8)</li> <li>▶ WR-ACK(40)</li> <li>▶ WR-SUC(41)</li> </ul> <p>The mode <code>Simulation - programmed</code> at the driver start is not a criterion in order to restore the remanent variable image.</p>
Stop at the Standby Server	<p>Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.</p> <p><b>Attention:</b> If this option is active, the gapless archiving is no longer guaranteed.</p> <p><b>Active:</b> Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status <code>switched off</code> (<code>statusverarbeitung.chm: /24150.htm</code>) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.</p>
Global Update time	<p><b>Active:</b> The set <code>Global update time</code> in ms is used for all variables in the project. The priority set at the variables is not used.</p> <p><b>Inactive:</b> The set priorities are used for the individual variables.</p>
Priority	<p>Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken</p>

place for each variable separately in the settings of the variable properties. The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities. Thus the communication load is distributed better.


## UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For **Set value**, **Advising** of variables and **Requests**, a read cycle is immediately triggered for all drivers - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

### 6.2.2 Driver dialog 1

Configuration of the connections to the PLCs.



Parameters	Description
<b>Connections</b>	Contains the configured connections. Select a connection to display the connection settings.
<b>Net address</b>	The net address identifies the connection. Therefore, every connection must have a unique net address assigned to a connection via the net address.
<b>Connection name</b>	Freely definable name for the easier distinction of connections.
<b>IP address</b>	IP address of the PLC that you are communicating with.
<b>Timeout [ms]</b>	Timeout time in milliseconds.

### CREATE NEW CONNECTION

1. click on the button **New**
2. Enter the connection details.
3. click on **Save**

### EDIT CONNECTION

1. select the connection in the connection list
2. click on the button **Edit**
3. change the connection parameters
4. finish with **save**

### DELETE CONNECTION

1. select the connection in the connection list
2. click on the button **Delete**
3. the connection will be removed from the list

## 7. Creating variables

This is how you can create variables in the zenon Editor:

### 7.1 Creating variables in the Editor


Variables can be created:

- ▶ as simple variables
- ▶ in arrays main.chm::/15262.htm
- ▶ as structure variables main.chm::/15278.htm

#### VARIABLE DIALOG


To create a new variable, regardless of which type:

1. Select the **New variable** command in the **variables** node in the context menu



2. The dialog for configuring variables is opened

3. configure the variable
4. The settings that are possible depends on the type of variables



Property	Description
Name	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.  <b>Attention:</b> The # character is not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the <b>Finish</b> button remains inactive.
Drivers	Select the desired driver from the drop-down list.  <b>Note:</b> If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.
Driver object type (cti.chm::/28685.htm)	Select the appropriate driver object type from the drop-down list.

Data type	Select the desired data type. Click on the ... button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

## INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- ▶ derived from the datatype
- ▶ Automatically adapted if the data type is changed

**Note for signal range:** If a change is made to a data type that does not support the set `signal range`, the `signal range` is amended automatically. For example, for a change from `INT` to `SINT`, the `signal range` is changed to 127. The amendment is also carried out if the `signal range` was not inherited from the data type. In this case, the `measuring range` must be adapted manually.

## 7.2 Addressing

Group/Property	Description
General	
Name	Freely definable name. <b>Attention:</b> For every zenon project the name must be unambiguous.
Identification	Freely assignable identification, e.g. for resources lable, comment ...
Addressing	
Secondary object	States the secondary object type (on page 18) for Time/Counter, Drum, Loop variable and Alarm variable.
Net address	Bus address or net address of the variable.  This address refers to the bus address in the connection configuration of the

	driver. This defines the PLC, on which the variable resides.
Data block	Not used.
Offset	Offset of the variable, the storage address of the variable in the PLC or the element number of the variable in the PLC. Adjustable from 0 to 4294967295.
Alignment	Alignment of a byte within a word (only for VMEMORY and KMEMORY)
Bit number	Number of the bit within the configured offset.  <b>POSSIBLE ENTRIES: 0 ... 65535</b>
String length	Only available for String variables: Maximum number of characters that the variable can take.
Driver connection/Driver object type	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.
Driver connection/Data type	Data type of the variable. Is selected during the creation of the variable; the type can be changed here later.  <b>ATTENTION:</b> If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.

### 7.3 Secondary object type

For driver object types time/counter, drum, loop variable or alarm variable the following data types and secondary object types are available:

Driver object type	Data type
<b>Timer/Counter</b>	
Preset (TCP)	INT
Current (TCC)	INT
<b>Drum</b>	
Step Preset (DSP)	INT
Step Current (DSC)	INT
Count Preset (DCP)	INT
Count Current (DCC)	INT*
<b>Loop Variable</b>	
Gain (LKC.)	REAL
Reset Time - min (LTI.)	REAL
Rate Time – min (LTD.)	REAL
Sample Rate – sec (LTS)	REAL
Process Variable (LPV)	REAL, INT
PV High Limit (LPVH)	REAL
PV Low Limit (LPVL)	REAL
Set Point (LSP)	REAL, INT
SP High Limit (LSPH)	REAL, INT
SP Low Limit (LSPL)	REAL, INT
Output (LMN)	REAL, INT
Bias (LMX)	REAL, INT
Error (empty)	REAL, INT
High-High Alarm Limit (LHHA)	REAL, INT
High Alarm Limit (LHA)	REAL, INT
Low Alarm Limit (LLA)	REAL, INT
Low-Low Alarm Limit (LLLA)	REAL, INT

Alarm Deadband (LADB)	REAL, INT
Orange Dev Alarm Limit (LODA)	REAL, INT
Yellow Dev Alarm Limit (LYDA)	REAL, INT
Rate of Change Alarm Limit (LRCA)	REAL
Alarm Acknowledge Flags (LACK)	UINT
Deriv Gain Limiting Coeff (LKD)	REAL
Loop Status UINT	
Loop Mode UNIT	
Loop V-Flags (LVF)	UINT
Control Flags – MSW (LCFH)	UINT
Control Flags – LSW (LCFL)	UINT
Ramp/Soak Status Flags (LRSF)	UINT
Ramp/Soak Step Number (LRSN)	INT
<b>Alarm Variable</b>	
Sample Rate – sec (ATS)	REAL
Process Variable (APV)	REAL, INT
PV High Limit (APVH)	REAL
PV Low Limit (APVL)	REAL
Set Point (ASP)	REAL, INT
SP High Limit (ASPH)	REAL, INT
SP Low Limit (ASPL)	REAL, INT
Error (AERR)	REAL, INT*
High-High Alarm Limit (AHHA)	REAL, INT
High Alarm Limit (AHA)	REAL, INT
Low Alarm Limit (ALA)	REAL, INT
Low-Low Alarm Limit (ALLA)	REAL, INT
Alarm Deadband (AADB)	REAL, INT

Orange Dev Alarm Limit (AODA)	REAL, INT
Yellow Dev Alarm Limit (AYDA)	REAL INT
Rate of Change Alarm Limit (ARCA)	REAL, INT
Alarm Acknowledge Flags (AACK)	UINT*
Alarm V-Flags (AVF)	UINT*
Alarm Control Flags – MSW (ACFH)	UINT
Alarm Control Flags – LSW (LCFL)	UINT

\* Read only

## 7.4 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

### 7.4.1 Driver objects

The following object types are available in this driver:

Driver object type	Channel type	Read / Write	Supported data types	Description
V memory	64	R / W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	
K memory	65	R	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	
STW memory	66	R / W	INT,UINT	
WX memory	67	R / W	INT,UINT	
WX memory	68	R / W	INT,UINT	
X memory	69	R / W	BOOL	
Y memory	70	R / W	BOOL	
C memory	71	R / W	BOOL	
Time/Counter	72	R / W	INT	
Drum	73	R / W	INT	
Loop variable	74	R / W	INT,UINT,REAL	
Alarm variable	75	R / W	INT,UINT,REAL	
Driver variable	35	R / W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the statistical analysis of communication.  Find out more in the chapter about the Driver variables (on page 30)

## 7.4.2 Mapping of the datatypes

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

PLC	zenon	Data type
BOOL	BOOL	8
-	USINT	9
-	SINT	10
UINT	UINT	2
INT	INT	1
-	UDINT	4
-	DINT	3
-	ULINT	27
-	LINT	26
REAL	REAL	5
-	LREAL	6
STRING	STRING	12
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19

**Data type:** The property `Data type` is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

## 7.5 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.

### 7.5.1 XML import of variables from another zenon project

For the import/export of variables the following is true:

- ▶ The import/export must not be started from the global project.
- ▶ The start takes place via:
  - Context menu of variables or data typ in the project tree
  - or context menu of a variable or a data type
  - or symbol in the symbol bar variables

#### Attention

*When importing/overwriting an existing data type, all variables based on the existing data type are changed.*

#### *Example:*

*There is a data type XYZ derived from the type `INT` with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type `STRING`. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer `INT` variables, but `STRING` variables.*

### 7.5.2 DBF Import/Export

Data can be exported to and imported from dBase.

#### **IMPORT DBF FILE**

To start the import:

1. right-click on the variable list
2. in the drop-down menu of **Extended export/import...** select the **Import dBase** command
3. follow the import assistant

The format of the file is described in the chapter File structure.

### Info

*Note:*

- ▶ Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

## EXPORT DBF FILE

To start the export:

1. right-click on the variable list
2. in the drop-down menu of **Extended export/import...** select the **Export dBase** command
3. follow the export assistant

### Attention

DBF files:

- ▶ must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ must not have dots (.) in the path name.  
e.g. the path `C:\users\John.Smith\test.dbf` is invalid.  
Valid: `C:\users\JohnSmith\test.dbf`
- ▶ must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.

### Info

*dBase does not support structures or arrays (complex variables) at export.*

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:

### Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- ▶ correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ Be stored close to the root directory (Root)

## DESIGN

Description	Type	Field size	Comment
KANALNAME	Char	128	Variable name.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
KANAL_R	C	128	The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually).  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	C	128	Identification.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
EINHEIT	C	11	Technical unit
DATENART	C	3	Data type (e.g. bit, byte, word, ...) corresponds to the data type.
KANALTYP	C	3	Memory area in the PLC (e.g. marker area, data area, ...) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset

BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipe Group Manager
LES_SCHR	R	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises KANALTYP and DATENART
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
MEMTIEFE	N	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	N	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST_MINUS	F	16	Negative hysteresis, from measuring range
PRIOR	N	16	Priority of the variable
REAMATRIZE	C	32	Allocated reaction matrix

ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks
RESOURCE	C	128	Resource label. Free string for export and display in lists.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: non linear value adaption is not used
ADJZENON	C	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	C	128	Linked VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

 **Attention.**

*When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.*

## LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 to 4:

Description	Type	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Hysteresis in %
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Function linking
ASK_FUNC1	R	1	With interrogation before execution
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	C	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	C	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.

## 7.6 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- ▶ Information
- ▶ Configuration
- ▶ Statistics and
- ▶ Error messages

The definitions of the variables defined in the driver kit are available in the import file `drvvar.dbf` (on the CD in the directory: `CD_Drive:/Predefined/Variables`) and can be imported from there.

**Hint:** Variable names must be unique in zenon. If driver variables are to be imported from `drvvar.dbf` again, the variables that were imported beforehand must be renamed.



### Info

*Not every driver supports all driver variants.*

*For example:*

- ▶ Variables for modem information are only supported by modem-compatible drivers
- ▶ Driver variables for the polling cycle only for pure polling drivers
- ▶ Connection-related information such as ErrorMSG only for drivers that only edit one connection at a time

## INFORMATION

Name from import	Type	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon service pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection stopped
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped

			For <code>driver stop</code> , the variable has the value <code>TRUE</code> and an <code>OFF</code> bit. After the driver has started, the variable has the value <code>FALSE</code> and no <code>OFF</code> bit.
<code>SimulRTState</code>	<code>UDINT</code>	60	Informs the status of Runtime for driver simulation.

## CONFIGURATION

Name from import	Type	Offset	Description
<code>ReconnectInRead</code>	<code>BOOL</code>	27	If <code>TRUE</code> , the modem is automatically reconnected for reading
<code>ApplyCom</code>	<code>BOOL</code>	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method <code>SrvDrvVarApplyCom</code> being called (which currently has no further function).
<code>ApplyModem</code>	<code>BOOL</code>	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method <code>SrvDrvVarApplyModem</code> . This closes the current connection and opens a new one according to the settings <code>PhoneNumberSet</code> and <code>ModemHwAdrSet</code> .
<code>PhoneNumberSet</code>	<code>STRING</code>	38	Telephone number, that should be used
<code>ModemHwAdrSet</code>	<code>DINT</code>	39	Hardware address for the telephone number
<code>GlobalUpdate</code>	<code>UDINT</code>	3	Update time in milliseconds (ms).
<code>BGlobalUpdaten</code>	<code>BOOL</code>	4	<code>TRUE</code> , if update time is global
<code>TreiberSimul</code>	<code>BOOL</code>	5	<code>TRUE</code> , if driver in sin simulation mode
<code>TreiberProzab</code>	<code>BOOL</code>	6	<code>TRUE</code> , if the variables update list should be kept in the memory
<code>ModemActive</code>	<code>BOOL</code>	7	<code>TRUE</code> , if the modem is active for the driver

Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	SINT	14	Number of bits per character of the serial interface  Value = 0 if the driver cannot establish any serial connection.
StopBit	SINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UDINT	54	Time in seconds (s) to establish a connection.

## STATISTICS

Name from import	Type	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group <b>Normal</b> in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group <b>Higher</b> in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group <b>High</b> in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group <b>Highest</b> in milliseconds (ms).

PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed
------------	------	----	---

## ERROR MESSAGES

Name from import	Type	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	UDINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	SINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

## 8. Driver-specific functions

This driver supports the following functions:

## PACKED TASK CODES

The driver uses CAMP packets with packed task code. This means: Several read or write requests are grouped in one CAMP/TCP packet. This increases the performance at reading and writing. In contrast to blockwrite the write order is not lost.

## BLOCKWRITE

The driver supports blockwrite for driver object types `V memory` and not string variables.

Blockwrite allows for the efficient sending of multiple set values (e.g. recipes). Variables that lie next to each other in the PLC memory will be written to with a single write telegram or combined into a few telegrams (for larger areas).

**Attention:** if blockwrite is activated, the write sequence of the variables does not necessarily have to match their sending sequence.

Blockwrite can be activated with an entry in the `project.ini` file:

1. select the project in Project Manager
2. press the short cut `Ctrl+Alt+E`
3. the SQL folder of zenon opens in the Windows Explorer
4. `C:\ProgramData\COPA-DATA\SQL\...\FILES`
5. navigate to `\zenon\system\`
6. open the file `project.ini` with a text editor.
7. add the following entry:


```
[CTI]
BLOCKWRITE=1
```

## 9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function `Driver commands`. To do this:

- ▶ create a new function
- ▶ select *Variables -> Driver commands*
- ▶ The dialog for configuration is opened



Parameters	Description
Drivers	Drop-down list with all drivers which are loaded in the project.
Current state	Fixed entry which has no function in the current version.
<b>Driver commands</b>	Drop-down list for the selection of the command.
▶ Start driver (online mode)	Driver is reinitialized and started.
▶ Stop driver (offline mode)	Driver is stopped. No new data is accepted. <b>Note:</b> If the driver is in offline mode, all variables that were created for this driver receive the status <code>switched off</code> (OFF; Bit 20).
▶ Driver in simulation	Driver is set into simulation mode. The values of all variables of the driver are simulated by the

mode	driver. No values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Activate driver write set value	Write set value to a driver is allowed.
▶ Deactivate driver write set value	Write set value to a driver is prohibited.
▶ Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
Show this dialog in the Runtime	The dialog is shown in Runtime so that changes can be made.

## DRIVER COMMANDS IN THE NETWORK

If the computer, on which the `driver command` function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

## 10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

## 10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.00 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder `LOG` in directory `ProgramData`, example: `C:\ProgramData\zenon \zenon700\LOG` for zenon version 7.00 SPO. Log files are text files with a special structure.

**Attention:** With the default settings, a driver only logs error information. With the `Diagnosis Viewer` you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- ▶ customize the logging settings
- ▶ change the folder in which the log files are saved

### Hints:

1. In Windows CE even errors are not logged per default due to performance reasons.
2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property `Add all columns with entry` in the context menu of the column header.
4. If you only use `Error logging`, the problem description is in column `Error text`. For other diagnosis level the description is in column `General text`.
5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in `Error text` and/or `Error code` and/or `Driver error parameter (1 and 2)`. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
6. At the end of your test set back the diagnosis level from `Debug` or `Deep Debug`. At `Debug` and `Deep Debug` there are a great deal of data for logging which are saved to the hard drive and

which can influence your system performance. They are still logged even after you close the **Diagnosis Viewer**.



### Info

*You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.*

## 10.2 Analysis for wrongly addressed variables

If storage areas have status I bit, a reason can be that variables are wrongly addressed. With the help of the Diagnosis Viewer (main.chm::/12464.htm) you can figure this out. The log files of the Diagnosis Viewer should contain a message similar to this:

```
Connection '0': Reading variable block failed. TT '1', offset '2094', count '2'
```

In this case the following things are important:

- ▶ Offset of variables: 2094
- ▶ TT number: 1

Via the TT number from the log message it is possible to find out the driver object type of the variable.

**LIST OF TT NUMBERS WITH DRIVER OBJECT TYPES**

TT	Driver Object Type	Secondary Object	Data Type
01	V Memory		UINT
01			INT
01			DINT
01			Real
01			String
02 *	K Memory		UINT
02 *			INT
02 *			DINT
02 *			Real
02 *			String
03 *	Discrete Input (X)		BOOL
4	Discrete Output (Y)		BOOL
5	Control Relay (C)		UINT
09 *	WX Memory		UINT
09 *			INT

0A	WY Memory		UINT
0A			INT
1A *	Status Word (STW) UINT 1A *		DINT
0E	Timer/Counter Preset (TCP) INT 0E	Preset (TCP)	INT
0F		Current (TCC)	INT
10	Drum	Step Preset (DSP)	INT
11		Step Current (DSC)	INT
12		Count Preset (DCP)	INT
1B *		Count Current (DCC)	INT
20	Loop Variable	Gain (LKC.)	Real
21		Reset Time - min (LTI.)	Real
22		Rate Time – min (LTD.)	Real
2A		Sample Rate – sec (LTS)	Real
25		Process Variable (LPV)	Real
3A			INT
26		PV High Limit (LPVH)	Real
27		PV Low Limit (LPVL)	Real
2B		Set Point (LSP)	Real
3E			INT
35		SP High Limit (LSPH)	Real
4A			INT
36		SP Low Limit (LSPL)	Real
49			INT
2C		Output (LMN)	Real (%)
3D			INT

31		Bias (LMX)	Real
48			INT
30		Error (empty)	Real
3F			INT
32		High-High Alarm Limit (LHHA)	Real
40			INT
23		High Alarm Limit (LHA)	Real
38			INT
24		Low Alarm Limit (LLA)	Real
39			INT
33		Low-Low Alarm Limit (LLLA)	Real
41			INT
37		Alarm Deadband (LADB)	Real
42			INT
28		Orange Dev Alarm Limit (LODA)	Real
3B			INT
29		Yellow Dev Alarm Limit (LYDA)	Real
3C			INT
34		Rate of Change Alarm Limit (LRCA)	Real
4F *		Alarm Acknowledge Flags (LACK)	UINT
4D		Deriv Gain Limiting Coeff (LKD)	Real
1E		Loop Status	UINT

1F		Loop Mode	UNIT
2D *		Loop V-Flags (LVF)	UINT
4B		Control Flags – MSW (LCFH)	UINT
4C		Control Flags – LSW (LCFL)	UINT
2F *		Ramp/Soak Status Flags (LRSF)	UINT
4E		Ramp/Soak Step Number (LRSN)	INT
57	Alarm Variable	Sample Rate – sec (ATS)	Real
52		Process Variable (APV)	Real
64			INT
53		PV High Limit (APVH)	Real
54		PV Low Limit (APVL)	Real
58		Set Point (ASP)	Real
67			INT
5F		SP High Limit (ASPH)	Real
70			INT
60		SP Low Limit (ASPL)	Real
6F			INT
5B *		Error (AERR)	Real
69 *			INT
5C		High-High Alarm Limit (AHHA)	Real
6A			INT
50		High Alarm Limit (AHA)	Real
62			INT

51		Low Alarm Limit (ALA)	Real
63			INT
5D		Low-Low Alarm Limit (ALLA)	Real
6B			INT
61		Alarm Deadband (AADB)	Real
68			INT
55		Orange Dev Alarm Limit (AODA)	Real
65			INT
56		Yellow Dev Alarm Limit (AYDA)	Real
66			INT
5E		Rate of Change Alarm Limit (ARCA)	Real
73 *		Alarm Acknowledge Flags (AACK)	UINT
59 *		Alarm V-Flags (AVF)	UINT
71		Alarm Control Flags – MSW (ACFH)	UINT
72		Alarm Control Flags – LSW (LCFL)	UINT

\* Read Only Variable

## 10.3 Check list

Checks after communication errors:

- ▶ Is the PLC connected to the power supply?
- ▶ Are the participants available in the TCP/IP network?

- ▶ Can the PLC be reached via the `ping` command?
- ▶ Can the PLC be reached at the respective port via `TELNET`?
- ▶ Did you configure the net address correctly, both in the driver dialog and in the address properties of the variables?
- ▶ Did you use the right object type for the variable?
- ▶ Does the offset addressing of the variable match the one in the PLC?
- ▶ Analysis with the Diagnosis Viewer: Which messages are displayed?