

zenon driver manual PadNetPciNT

v.7.00



© 2012 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.



Contents

1.	Welcome to COPA-DATA help5			
2.	PadN	etPciNT		5
3.	PADN	NETPCIN	T - Data sheet	5
4.	Drive	r history	/	7
5.	Requ	irement	S	7
	5.1	РС		8
	5.2	PLC		8
6.	Confi	guratior	۱	8
	6.1	Creating	g a driver	9
	6.2	Settings	in the driver dialog	10
		6.2.1	General	10
		6.2.2	Settings	13
7.	Creat	ing varia	ables	13
7.	Creat	•	ables yvariables in the Editor	
7.		Creating		14
7.	7.1	Creating Address	y variables in the Editor	14 17
7.	7.1 7.2	Creating Address	y variables in the Editor	14 17 17
7.	7.1 7.2	Creating Address Driver o	y variables in the Editor ing bjects and datatypes	14 17 17 18
7.	7.1 7.2	Creating Address Driver o 7.3.1 7.3.2	g variables in the Editor ing bjects and datatypes Driver objects	14 17 17 18 19
7.	7.1 7.2 7.3	Creating Address Driver o 7.3.1 7.3.2	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types	14 17 17 18 19 20
7.	7.1 7.2 7.3	Creating Address Driver o 7.3.1 7.3.2 Creating	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types g variables by importing	14 17 17 18 19 20 20
7.	7.17.27.37.4	Creating Address Driver o 7.3.1 7.3.2 Creating 7.4.1 7.4.2	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types g variables by importing XML import of variables from another zenon project	14 17 17 18 19 20 20 21
	7.17.27.37.47.5	Creating Address Driver o 7.3.1 7.3.2 Creating 7.4.1 7.4.2 Driver v	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types g variables by importing XML import of variables from another zenon project DBF Import/Export	14 17 17 18 19 20 20 21 27
	 7.1 7.2 7.3 7.4 7.5 Drive 	Creating Address Driver o 7.3.1 7.3.2 Creating 7.4.1 7.4.2 Driver v r-specifi	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types g variables by importing XML import of variables from another zenon project DBF Import/Export ariables	14 17 17 18 19 20 20 21 27 32
8. 9.	 7.1 7.2 7.3 7.4 7.5 Drive Drive 	Creating Address Driver o 7.3.1 7.3.2 Creating 7.4.1 7.4.2 Driver v r-specifi r comma	g variables in the Editor ing bjects and datatypes Driver objects Mapping of the data types g variables by importing XML import of variables from another zenon project DBF Import/Export ariables c functions	14 17 17 18 19 20 20 21 27 32 33



Check list	36
	Check list



1. Welcome to COPA-DATA help

GENERAL HELP

If you miss any information in this help chapter or have any suggestions for additions, please feel free to contact us via e-mail: documentation@copadata.com (mailto:documentation@copadata.com).

PROJECT SUPPORT

If you have concrete questions relating to your project, please feel free to contact the support team via e-mail: support@copadata.com (mailto:support@copadata.com)

LICENSES AND MODULES

If you realize that you need additional licenses or modules, please feel free to contact the sales team via e-mail: sales@copadata.com (mailto:sales@copadata.com)

2. PadNetPciNT

3. PADNETPCINT - Data sheet



General:	
Driver file name	PADNETPCINT.exe
Driver description	PDNet PCI - driver
PLC types	Schneider Modicon PLCs: TSX Compact A120, TSX Compact Micro, TSX A250, A350, A500, TSX Quantum. ABB Protronic PLCs: T200, CS31, AC31. Siemens PLCs: S5-115U, S5-135U, S5-155U, S7-300, S7-400
PLC manufacturer	ABB; Apex; Modicon; Siemens; PDNet; Schneider;

Driver supports:	
Protocol	PDNet;
Addressing: address based	x
Addressing: name based	-
Spontaneous communication	-
Polling communication	x
Online browsing	-
Offline browsing	-
Real-time capable	-
Blockwrite	-
Modem capable	-
Serial logging	-
RDA numerical	-
RDA String	-



Prerequisites:	
Hardware PC	Apex PDNet PCI bus card: PAD-PCI
Software PC	Driver for PDNet cards has to be installed - Is available on the zenon installation CD
Hardware PLC	There are adequate PDNet slot cards from Apex for the different PLCs
Software PLC	Program for the according CP-connection from Apex necessary
Requires v-dll	-

Platforms:	
Operating systems	Windows XP;
CE platforms	-;

4. Driver history

Date	Driver version	Change
07.07.08	200	Created driver documentation

5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.



5.1 PC

HARDWARE

Network card APEX Pad PG Rev 1 TokenRing (PCI version).

SOFTWARE

NT drivers for the APEX network card. Configured network connection, especially the definition of the write/read ranges. The configuration is performed with the program NETPro. PADITF32.DLL

Copy the driver file PadNetNT.EXE to the current zenon directory (unless it is already there).

5.2 PLC

HARDWARE

ABB PLC with communication processor. The driver was tested with the CP 07KP66.

SOFTWARE

Programm for the CP connection

6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.

💡 Info

Find out more about further settings for zenon variables in the chapter Variables



(main.chm::/15247.htm) of the online manual.

6.1 Creating a driver

In order to create a new driver:

- ▶ Right-click on Driver in the Project Manage and select Driver new in the context menu.
- ► In the following dialog the control system offers a list of all available drivers.

		^
		Ξ
- 📑 Codesys Arti Sof		
Codesys SoftSP:	5 Treiber	
H ABB		
AEG AEG		
Allen Bradley Alstom		
Alscom		
Archive		
Arcnet		
Areva		
Asfinag		
Bachmann		
Decent		-
Treiberbezeichnung		
Codesys Arti NG Treiber		
Treiberinformationen		
Beschreibung:	eue Generation" für die Codesys 35-ARTI (Asynchron Runtime	1
		1
Codesys Soft SPS Treiber "N	Treiber unterstützt die direkte Variablenübernahme aus der	15
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der	 Treiber unterstützt die direkte Variablenübernahme aus der ung und ersetzt den Codesys Arti Soft SPS Treiber. 	-
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu	ung und ersetzt den Codesys Arti Soft SPS Treiber.	
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu Für folgende SPS Typen gee	ung und ersetzt den Codesys Arti Soft SPS Treiber. ignet:	
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu Für folgende SPS Typen gee	ung und ersetzt den Codesys Arti Soft SPS Treiber. ignet: : XControl SP5en XC200 und XC600, sowie Elau PacDrive	
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu Für folgende SPS Typen gee Codesys Soft SPSen, Moeller Steuerungen MAX 4, C200,	ing und ersetzt den Codesys Arti Soft SPS Treiber. ignet: XControl SPSen XC200 und XC600, sowie Elau PacDrive C400, C600, P600.	
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu Für folgende SPS Typen gee Codesys Soft SPSen, Moeller Steuerungen MAX 4, C200, 4 Folgende Kopplungsarten we	ing und ersetzt den Codesys Arti Soft SPS Treiber. ignet: XControl SPSen XC200 und XC600, sowie Elau PacDrive C400, C600, P600.	
Codesys Soft SPS Treiber "N Interface) Schnittstelle. Der Codesys Enwicklungsumgebu Für folgende SPS Typen gee Codesys Soft SPSen, Moeller Steuerungen MAX 4, C200,	ing und ersetzt den Codesys Arti Soft SPS Treiber. ignet: XControl SPSen XC200 und XC600, sowie Elau PacDrive C400, C600, P600.	

- Select the desired driver and give it a name:
 - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, every time a new name has to be given each time.
 - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (_).
 - Attention: This name cannot be changed later on.



- Confirm the dialog with ox. In the following dialog the single configurations of the drivers are defined.
- Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.

	♀ Info
	For new projects and for existing projects which are converted to version 6.21 or higher, the following drivers are created automatically:
►	Internal
►	MathDr32
•	SysDrv.

6.2 Settings in the driver dialog

You can change the following settings of the driver:

6.2.1 General

General Mode: Hardware Variable Variable image remanent Stopped on Standby-Server	
Mode: Cance Hardware Help Keep update list in memory Help Outputs writeable Variable image remanent Stopped on Standby-Server Stopped on Standby-Server	
Mode: Hardware Help Keep update list in memory Outputs writeable Variable image remanent Stopped on Standby-Server	
Keep update list in memory Outputs writeable Variable image remanent Stopped on Standby-Server	
Outputs writeable Variable image remanent Stopped on Standby-Server	
Variable image remanent Stopped on Standby-Server	
Stopped on Standby-Server	
Update time global Global updatetime in ms:	
1000	
Priority normal: 1000 ms	
high: 500 ms	
higher: 300 ms	
highest: 100 ms	



Parameters	Description
Mode	 Allows to switch between hardware mode and simulation mode Hardware: A connection to the control is established. Simulation static No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area, e.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver. Simulation - counting No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically. Simulation - programmed N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon
	Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).
Keep update list in the memory	Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.
Output can be written	Active: Outputs can be written. Inactive: Writing of outputs is prevented.
	Note: Not available for every driver.



Variable image remanent	This option saves and restores the current value, time stamp and the states of a data point.
	Fundamental requirement: The variable must have a valid value and time stamp.
	The variable image is saved in mode hardware if:
	 one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active
	The variable image is always saved if:
	the variable is of the object type Driver variable
	the driver runs in simulation mode. (not programmed simulation)
	The following states are not restored at the start of the Runtime:
	SELECT(8)
	▶ WR-ACK(40)
	WR-SUC(41)
	The mode Simulation – programmed at the driver start is not a criterion in order to restore the remanent variable image.
Stop at the Standby Server	Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.
	Attention: If this option is active, the gapless archiving is no longer guaranteed.
	Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (statusverarbeitung.chm::/24150.htm) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.
Global Update time	Active: The set Global update time in ms is used for all variables in the project. The priority set at the variables is not used. Inactive: The set priorities are used for the individual variables.
Priority	Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken



place for each variable separately in the settings of the variable properties. The communication of the individual variables are graduated in respect of
importance or necessary topicality using the priorities. Thus the
communication load is distributed better.

UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For Set value, Advising of variables and Requests, a read cycle is immediately triggered for all drivers - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

6.2.2 Settings

Configuration	
General Settings	DK
Parameters	Description
Pad Number	Number of the network connection that will be used.

7. Creating variables

This is how you can create variables in the zenon Editor:



7.1 Creating variables in the Editor

Variables can be created:

- as simple variables
- ▶ in arrays main.chm::/15262.htm
- ▶ as structure variables main.chm::/15278.htm

VARIABLE DIALOG

To create a new variable, regardless of which type:

- 🗊 Project Manager Workspace 'C:\WSP6_PBJ 袶 🥸 😰 🐚 🛝 🗙 🔠 🔹 🛊 🔷 🌑 🖾 팬 🍰 🚽 🏹 - 🐻 🏑 약 🏹 💣 🥹 Status Name Data block n Unit Net address Offset Bit num... Alignm... ♦ Variables Driver T Filter.... Filter text Filter text 🛛 Filter... 🔽 Filter... 🔽 Filter text Filter b Dover
 Datatypes
 Datatypes
 Reaction m...
 Allocations
 OAlarm
 Units 0 0 drv_a ė drv_C drv_E Variable new Ins 0 0 0 Create standard function 0 0 0 0 ١. drv_N 0 0 0 0 Linked elements Screens drv_N n n 0 0 ۵ پرچ 11 Functions drv_N Π n Π 0 Copy Ctrl+C Language table Historian drv_№ 0 0 0 0 Paste Ctrl+V drv_N 0 0 0 0 Recipes Delete Del 0 drv_S Time control 0 0 0 Interr 0 0 0 0 Programming interfa straton (IEC 6113... Expand/collapse node ŝ ۲ Interr 0 0 0 + 0 Production & Facility Interlockings Activate all + Interr n n 0 0 Activate i Command Deactivate Energy Manageme Message Control Export XML selected... Menus Import XML.. | Report Generator - 🕵 User administrati... - 💇 SAP interface Extended import/export ۲ Extended filter Files
 History of chang. ۲ Remove all filter Projektsicherun. Edit selected cell F2 able • • 42 total / 1 Replace text in selected column.. 🚦 Project tree 🛛 😤 Network topology Replace text in limits...
- 1. Select the New variable command in the variables node in the context menu

- 2. The dialog for configuring variables is opened
- 3. configure the variable



ate variable			×
Settings Name: S. Variable			
S_Variable			
Driver			
SIMUL32 - SIMUL_WIZ		-	
Driver object type			
PLC marker		•	
Datatype			
REAL			
Array settings			
 Start index is 0 			
Dim 1	Dim 2	Dim 3	
0	0	0	
Addressing options			
Automatic addressing			
Addressing according to	data type offset and sta	rt offset	
Manual addressing			
Each datatype starts wit	th new offset		
Automatic addressing			
Activate all elements			
 Activate element manual 	lly		
Back	Finish	Cancel He	elp

4. The settings that are possible depends on the type of variables

Property	Description
Name	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name. Attention: The # character is not permitted in variable names. If non- permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive.
Drivers	Select the desired driver from the drop-down list. Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.
Driver object type (cti.chm::/28685.h tm)	Select the appropriate driver object type from the drop-down list.



Data type	Select the desired data type. Click on the button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- Automatically adapted if the data type is changed

Note for signal range: If a change is made to a data type that does not support the set signal range, the signal range is amended automatically. For example, for a change from INT to SINT, the signal range is changed to 127. The amendment is also carried out if the signal range was not inherited from the data type. In this case, the measuring range must be adapted manually.



7.2 Addressing

Property	Description	
Name	Freely definable name	
	Attention: the name must be unique within each control system project.	
Identification	Any text can be entered here, e.g. for resource labels, comments	
Net address	Bus address or net address of the variable.	
	This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides.	
Data block	For variables of object type Extended data block, enter the datablock number here.	
	Configurable [0 4294967295] . Please look up the exact maximum range for data blocks in the manual of the PLC.	
Offset	Offset of the variable; the memory address of the variable in the PLC. Configurable [0 4294967295].	
Alignment	not used for this driver	
Bit number	Number of the bit within the configured offset.	
	Valid input [0 65535], Working range [07]	
String length	Only available for String variables: Maximum number of characters that the variable can take.	
Driver object type	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.	
Data type	Data type of the variable, which is selected during the creation of the variable; the type can be changed here later.	
	ATTENTION: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.	

7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.



7.3.1 Driver objects

The following object types are available in this driver:

Driver object type	Channel type	Read / Write	Supported data types	Comment
16-Bit field	78	R/W	UINT	
32-Bit field	79	R/W	UDINT	
8-Bit field	77	R/W	USINT	
Ascii	73	R/W	STRING	
Byte	64	R/W	SINT	
Double Word	68	R/W	UDINT	
Integer	67	R/W	INT	
Long Integer	69	R/W	DINT	
Marker	76	R/W	BOOL	
Net status	8	R	UINT	
Short integer	65	R/W	USINT	
Single	70	R/W	REAL	
String array	74	R/W	STRING	
Wort	66	R/W	UINT	
Word-bit	10	R/W	BOOL	



Object	Read	Write	Comment
Configurati on			Opens the driver configuration menu
Boolean	Y	Y	
i/u8Bit	Y	Y	
i/u16Bit	Y	Y	
i/u32Bit	Y	Y	
float32	Y	Y	
String	Y	Y	

OBJECTS FOR PROCESS VARIABLES IN ZENON

7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.



PLC	zenon
18	i/u8Bit (signed)
I16	i/u16Bit (signed)
I32	i/u32Bit (signed)
U8	i/u8Bit
U16	i/u16Bit
U32	i/u32Bit
F32	float32
Boolean	Boolean
string	String

EXAMPLE FOR ALL POSSIBLE ZENON DATA TYPES

Data type: The property Data type is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.

7.4.1 XML import of variables from another zenon project

For the import/export of variables the following is true:

- The import/export must not be started from the global project.
- The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type INTwith variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type STRING. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer INT variables, but STRING variables.

7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... select the Import dBase command
- 3. follow the import assistant

The format of the file is described in the chapter File structure.

💡 Info

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.



EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down menu of Extended export/import... select the Export dBase command
- 3. follow the export assistant

Attention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name. e.g. the path C:\users\John.Smith\test.dbf is invalid. Valid: C:\users\JohnSmith\test.dbf
- must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.

🂡 Info

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



▲ Attention

dBase does not support structures or arrays (complex variables) when exporting.

DBF files must:

- correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- Be stored close to the root directory (Root)

DESIGN

Description	Туре	Field size	Comment
KANALNAME	Char	128	Variable name.
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "KANALNAME" (field/column must be entered manually).
			The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_D	Log	1	The variable is deleted with the $\ensuremath{\mathbbm 1}$ entry (field/column has to be created by hand).
TAGNR	С	128	Identification.
			The length can be limited using the MAX_LAENGE entry in project.ini .
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset



BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)	
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipe Group Manager	
LES_SCHR	R	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.	
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)	
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises KANALTYP and DATENART	
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)	
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)	
ANZMIN	F	16	Technical value - minimum (measuring range)	
ANZMAX	F	16	Technical value - maximum (measuring range)	
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)	
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables	
MEMTIEFE	N	7	Only for compatibility reasons	
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)	
HDTIEFE	N	7	HD entry depth for historical values (number)	
NACHSORT	R	1	HD data as postsorted values	
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)	
HYST_PLUS	F	16	Positive hysteresis, from measuring range	
HYST_MINUS	F	16	Negative hysteresis, from measuring range	
PRIOR	N	16	Priority of the variable	
REAMATRIZE	С	32	Allocated reaction matrix	



ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the standby-server in redundant networks
RESOURCE	С	128	Resource label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: non linear value adaption is not used
ADJZENON	С	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	с	128	Linked VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

▲ Attention.

When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.

LIMIT DEFINITION

Limit definition for limit values 1 to 4 , $\$ and status 1 to 4:



Description	Туре	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	Technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1 , the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Hysteresis in %
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Function linking
ASK_FUNC1	R	1	With interrogation before execution
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	С	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	С	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.



7.5 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- Information
- Configuration
- Statistics and
- Error messages

The definitions of the variables defined in the driver kit are available in the import file drvvar.dbf (on the CD in the directory: CD Drive:/Predefined/Variables) and can be imported from there.

Hint: Variable names must be unique in zenon. If driver variables are to be imported from drvvar.dbf again, the variables that were imported beforehand must be renamed.

💡 Info

Not every driver supports all driver variants.

For example:

- Variables for modem information are only supported by modem-compatible drivers
- Driver variables for the polling cycle only for pure polling drivers
- Connection-related information such as ErrorMSG only for drivers that only edit one connection at a a time



INFORMATION

Name from import	Туре	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon service pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection stopped
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped



			For driver stop, the variable has the value TRUE and an OFF bit. After the driver has started, the variable has the value FALSE and no OFF bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

CONFIGURATION

Name from import	Туре	Offset	Description
ReconnectInRead	BOOL	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet.
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver



Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	SINT	14	Number of bits per character of the serial interface
			Value = 0 if the driver cannot establish any serial connection.
StopBit	SINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UDINT	54	Time in seconds (s) to establish a connection.



STATISTICS

Name from import	Туре	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group High in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).



PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were
			executed

ERROR MESSAGES

Name from import	Туре	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	UDINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	SINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

8. Driver-specific functions

This driver supports the following functions:



9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function **Driver** commands. To do this:

- create a new function
- ▶ select Variables -> Driver commands
- The dialog for configuration is opened

Driver	
Driver commands	
Settings Driver S7TCP-IP Current status Priver	<u>⊆</u> ancel <u>H</u> elp
Driver command	
Show this dialog in the Runtime	

Parameters	Description		
Drivers	Drop-down list with all drivers which are loaded in the project.		
Current state	Fixed entry which has no function in the current version.		
Driver commands	Drop-down list for the selection of the command.		
Start driver (online mode)	Driver is reinitialized and started.		
 Stop driver (offline mode) 	Driver is stopped. No new data is accepted. Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20).		
Driver in simulation	Driver is set into simulation mode. The values of all variables of the driver are simulated by the		



	mode	driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
•	Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
•	Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
•	Activate driver write set value	Write set value to a driver is allowed.
•	Deactivate driver write set value	Write set value to a driver is prohibited.
•	Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
•	Disconnect from modem	Terminate connection (for modem drivers)
	ow this dialog in the ntime	The dialog is shown in Runtime so that changes can be made.

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the driver command function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.



10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.00 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder Log in directory ProgramData, example: C:\ProgramData\zenon \zenon700\LOG for zenon version 7.00 SPO. Log files are text files with a special structure.

Attention: With the default settings, a driver only logs error information. With the Diagnosis Viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- follow currently created entries live
- customize the logging settings
- change the folder in which the log files are saved

Hints:

- 1. In Windows CE even errors are not logged per default due to performance reasons.
- 2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- 3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property Add all columns with entry in the context menu of the column header.
- 4. If you only use Error logging, the problem description is in column Error text. For other diagnosis level the description is in column General text.
- 5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in Error text and/or Error code and/or Driver error parameter (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 6. At the end of your test set back the diagnosis level from Debug Or Deep Debug. At Debug and Deep Debug there are a great deal of data for logging which are saved to the hard drive and



which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.

💡 Info

You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.

10.2 Check list

Is the COM port in use by another application or are the settings incorrect?

Is the device (PLC) that you are trying to communicate with connected to the power supply?

Is the cable between PLC and PC/IPC connected correctly?

Are the used datablocks defined correctly in the PLC?

Have you analyzed the error text file (which errors did occur)?

Send the zenon project to support@copadata.com (mailto:support@copadata.com)