


zenon driver manual

IEC61499

v.7.11





©2014 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. The technical data contained herein has been provided solely for informational purposes and is not legally binding. Subject to change, technical or otherwise.

Contents

1. Welcome to COPA-DATA help	5
2. IEC61499	5
3. IEC61499 - Data sheet	6
4. Driver history	7
5. Requirements.....	8
6. Configuration	8
6.1 Creating a driver.....	8
6.2 Settings in the driver dialog	10
6.2.1 General	11
6.2.2 Connections.....	14
7. Creating variables.....	15
7.1 Creating variables in the Editor.....	15
7.2 Addressing.....	19
7.3 Driver objects and datatypes	19
7.3.1 Driver objects	20
7.3.2 Mapping of the data types	20
7.4 Creating variables by importing	21
7.4.1 XML import.....	22
7.4.2 DBF Import/Export	22
7.5 Driver variables	29
8. Driver-specific functions	34
9. Driver commands	35
10. Service and protocol specification	37
10.1 Service specification.....	39
10.2 Protocol specification.....	45
10.3 Appendix	50

11. Error analysis.....	50
11.1 Analysis tool	50
11.2 Check list	52

1. Welcome to COPA-DATA help

GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to documentation@copadata.com (<mailto:documentation@copadata.com>).

PROJECT SUPPORT

You can receive support for any real project you may have from our Support Team, who you can contact via email at support@copadata.com (<mailto:support@copadata.com>).

LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email sales@copadata.com (<mailto:sales@copadata.com>).

2. IEC61499

Driver for connecting PLCs supporting the simple spontaneous communication protocol. This protocol has been developed by the Automation and control institute (TU-Wien) and Ing. Punzenberger COPA-DATA GmbH in the course of the OntoReA project. The protocol was specifically designed to communicate with IEC 61499 based controls.

3. IEC61499 - Data sheet

General:	
Driver file name	IEC61499.exe
Driver name	IEC 61499 driver
PLC types	IEC 61499 compatible PLCs
PLC manufacturer	IEC;

Driver supports:	
Protocol	SSCP;
Addressing: Address-based	x
Addressing: Name-based	-
Spontaneous communication	x
Polling communication	-
Online browsing	-
Offline browsing	-
Real-time capable	x
Blockwrite	-
Modem capable	-
Serial logging	-
RDA numerical	-
RDA String	-

Requirements:	
Hardware PC	-
Software PC	-
Hardware PLC	-
Software PLC	Communication blocks for the SSCP protocol have to be implemented. See driver documentation
Requires v-dll	-

Platforms:	
Operating systems	Windows Vista, 7, 8, 8.1 Server 2008/R2, Server 2012/R2;
CE platforms	-;

4. Driver history

Date	Driver version	Change
2/25/2010	100	Created driver documentation

DRIVER VERSIONING

The versioning of the drivers was changed with zenon 7.10. There is a cross-version build number as of this version. This is the number in the 4th position of the file version,
For example: 7.10.0.4228 means: The driver is for version 7.10 service pack 0, and has the build number 4228.

Expansions or error rectifications will be incorporated into a build in the future and are then available from the next consecutive build number.



Example

*A driver extension was implemented in build **4228**. The driver that you are using is build number **8322**. Because the build number of your driver is higher than the build number of the extension, the extension is included. The version number of the driver (the first three digits of the file version) do not have any significance in relation to this. The drivers are version-agnostic*

5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.



Information


Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.

6.1 Creating a driver

In order to create a new driver:

1. Right-click on **Driver** in the Project Manage and select **Driver new** in the context menu.

2. In the following dialog the control system offers a list of all available drivers.



3. Select the desired driver and give it a name:
- The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, a new name has to be given each time.
 - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (_).

- **Attention:** This name cannot be changed later on.
4. Confirm the dialog with **OK**. In the following dialog the single configurations of the drivers are defined.

Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.



Information

For new projects and for existing projects which are converted to version 6.21 or higher, the following drivers are created automatically:


- ▶ Internal
- ▶ MathDr32
- ▶ SysDrv.

▶

6.2 Settings in the driver dialog

You can change the following settings of the driver:

6.2.1 General



Parameters	Description
Mode	<p>Allows to switch between hardware mode and simulation mode</p> <ul style="list-style-type: none"> ▶ Hardware: A connection to the control is established. ▶ Simulation static No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by straton. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver. ▶ Simulation - counting No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically. ▶ Simulation - programmed N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the straton Workbench and runs in a straton Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).
Keep update list in the memory	<p>Variables which were requested once are still requested from the control even if they are currently not needed.</p> <p>This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.</p>
Outputs writeable	<p>Active: Outputs can be written.</p> <p>Inactive: Writing of outputs is prevented.</p> <p>Note: Not available for every driver.</p>

Variable image remanent	<p>This option saves and restores the current value, time stamp and the states of a data point.</p> <p>Fundamental requirement: The variable must have a valid value and time stamp.</p> <p>The variable image is saved in mode hardware if:</p> <ul style="list-style-type: none"> ▶ one of the states <code>S_MERKER_1(0)</code> up to <code>S_MERKER8(7)</code>, <code>REVISION(9)</code>, <code>AUS(20)</code> or <code>ERSATZWERT(27)</code> is active <p>The variable image is always saved if:</p> <ul style="list-style-type: none"> ▶ the variable is of the object type <code>Driver variable</code> ▶ the driver runs in simulation mode. (not programmed simulation) <p>The following states are not restored at the start of the Runtime:</p> <ul style="list-style-type: none"> ▶ <code>SELECT(8)</code> ▶ <code>WR-ACK(40)</code> ▶ <code>WR-SUC(41)</code> <p>The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image.</p>
Stopped on Standby Server	<p>Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.</p> <p>Attention: If this option is active, the gapless archiving is no longer guaranteed.</p> <p>Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (<code>statusverarbeitung.chm: :/24150.htm</code>) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.</p>
Update time global	<p>Active: The set <code>Update time global</code> in ms is used for all variables in the project. The priority set at the variables is not used.</p> <p>Inactive: The set priorities are used for the individual variables.</p>
Priority	<p>Here you set the polling times for the individual priorities. All variables with the according priority are polled in the set time. The allocation is taken</p>

	place for each variable separately in the settings of the variable properties. The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities. Thus the communication load is distributed better.
OK	Accepts settings in all tabs and closes dialog.
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

UPDATE TIME FOR CYCLICAL DRIVER

The following applies for cyclical drivers:

For **Set value**, **Advising** of variables and **Requests**, a read cycle is immediately triggered for all drivers - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

6.2.2 Connections

Configuration of the connections to the PLCs.

Parameters	Description
Connections	Contains the configured connections. Select a connection to display the connection settings.
Connection name	Freely definable name for the easier distinction of connections.
Net address	The net address identifies the connection. Therefore, every connection must have a unique net address assigned to a connection via the net address.
IP address	IP address of the PLC that you are communicating with.
Port number	TCP port of the PLC that you are communicating with.
Timeout [ms]	Timeout time in milliseconds.
Error wait time [ms]	Error wait time in milliseconds.

CREATE NEW CONNECTION

1. click on the button **New**

2. Enter the connection details.
3. click on **Save**

EDIT CONNECTION

1. select the connection in the connection list
2. click on the button **Edit**
3. change the connection parameters
4. finish with **Save**

DELETE CONNECTION

1. select the connection in the connection list
2. click on the button **Delete**
3. the connection will be removed from the list

7. Creating variables

This is how you can create variables in the zenon Editor:

7.1 Creating variables in the Editor


Variables can be created:

- ▶ as simple variables
- ▶ in arrays (main.chm::/15262.htm)
- ▶ as structure variables (main.chm::/15278.htm)

VARIABLE DIALOG


To create a new variable, regardless of which type:

1. Select the **New variable** command in the **variables** node in the context menu



2. The dialog for configuring variables is opened
3. configure the variable

4. The settings that are possible depends on the type of variables



Parameters	Description
Name	<p>Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.</p> <p>Maximum length: 128 characters</p> <p>Attention: The characters # and @ are not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive.</p>
Drivers	<p>Select the desired driver from the drop-down list.</p> <p>Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.</p>
Driver object type (cti.chm::/28685.htm)	Select the appropriate driver object type from the drop-down list.

Data type	Select the desired data type. Click on the ... button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- ▶ derived from the datatype
- ▶ Automatically adapted if the data type is changed

Note for signal range: If a change is made to a data type that does not support the set signal range, the signal range is amended automatically. For example, for a change from **INT** to **SINT**, the signal range is changed to 127. The amendment is also carried out if the signal range was not inherited from the data type. In this case, the measuring range must be adapted manually.

7.2 Addressing

Group/Property	Description
General	
Name	<p>Freely definable name.</p> <p>Attention: For every zenon project the name must be unambiguous.</p>
Identification	Freely assignable identification, e.g. for resources label, comment ...
Addressing	
Net address	<p>Bus address or net address of the variable.</p> <p>This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides.</p>
Data block	Not used
Offset	Offset of the variable; states the ID of the variable in the PLC. Adjustable from 0 to 4294967295.
Alignment	not used for this driver
Bit number	not used for this driver
String length	Only available for String variables: Maximum number of characters that the variable can take.
Driver connection/Driver object type	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.
Driver connection/Data type	<p>Data type of the variable. Is selected during the creation of the variable; the type can be changed here later.</p> <p>ATTENTION: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.</p>

7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

7.3.1 Driver objects

The following object types are available in this driver:

Driver object type	Channel type	Read / Write	Supported data types	Description
PLC marker	8	R / W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, LREAL, STRING	SSCP variable in the control
Driver variable	35	R / W	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the statistical analysis of communication. Find out more in the chapter about the Driver variables (on page 29)

7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

Control	zenon	Data type
BOOL	BOOL	8
USINT	USINT	9
SINT	SINT	10
UINT	UINT	2
INT	INT	1
UDINT	UDINT	4
DINT	DINT	3
-	ULINT	27
-	LINT	26
REAL	REAL	5
LREAL	LREAL	6
STRING	STRING	12
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19

Data type: The property `Data type` is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



Information

You can find details on the import and export of variables in the Import-Export (main.chm::/13028.htm) manual in the Variables (main.chm::/13045.htm) section.

7.4.1 XML import

For the import/export of variables the following is true:

- ▶ The import/export must not be started from the global project.
- ▶ The start takes place via:
 - Context menu of variables or data typ in the project tree
 - or context menu of a variable or a data type
 - or symbol in the symbol bar variables



Attention

When importing/overwriting an existing data type, all variables based on the existing data type are changed.

Example:

There is a data type XYZ derived from the type `INT` with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type `STRING`. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer `INT` variables, but `STRING` variables.

7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.



Information

Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.

IMPORT DBF FILE

To start the import:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Import dBase** command
3. follow the import assistant

The format of the file is described in the chapter File structure.



Information

Note:

- ▶ Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Export dBase...** command
3. follow the export assistant



Attention

DBF files:

- ▶ must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ must not have dots (.) in the path name.
e.g. the path `C:\users\John.Smith\test.dbf` is invalid.
Valid: `C:\users\JohnSmith\test.dbf`
- ▶ must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



Information

dBase does not support structures or arrays (complex variables) at export.

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- ▶ conform with there name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- ▶ Be stored close to the root directory (Root)

STRUCTURE

Description	Type	Field size	Comment
KANALNAME	Char	128	Variable name. The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_R	C	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (field/column must be entered manually). The length can be limited using the MAX_LAENGE entry in project.ini .
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	C	128	Identification. The length can be limited using the MAX_LAENGE entry in project.ini .
Unit	C	11	Technical unit
DATENART	C	3	Data type (e.g. bit, byte, word, ...) corresponds to the data type.
KANALTYP	C	3	Memory area in the PLC (e.g. marker area, data area, ...) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADDRESS	N	5	Offset

BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipe Group Manager
LES_SCHR	R	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
MIT_ZEIT	R	1	time stamp in zenon zenon (only if supported by the driver)
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJEKTYP and DATENTYP
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
MENTIEFE	N	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	N	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST_MINUS	F	16	Negative hysteresis, from measuring range
PRIOR	N	16	Priority of the variable
REAMATRIZE	C	32	Allocated reaction matrix

ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks
RESOURCE	C	128	Resources label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: Non-linear value adaption is not used
ADJZENON	C	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	C	128	ed VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.



Attention

When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.

LIMIT DEFINITION

Limit definition for limit values 1 to 4, and status 1 bis 4:

Description	Type	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	hnical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Is not used
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Functions linking
ASK_FUNC1	R	1	Execution via Alarm Message List
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	C	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	C	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

EXPRESSIONS IN THE COLUMN "COMMENT" REFER TO THE EXPRESSIONS USED IN THE DIALOG BOXES FOR THE DEFINITION OF VARIABLES. FOR MORE INFORMATION, SEE CHAPTER VARIABLE DEFINITION.

7.5 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- ▶ Information
- ▶ Configuration
- ▶ Statistics and
- ▶ Error messages

The definitions of the variables defined in the driver kit are available in the import file `drvvar.dbf` (on the CD in the directory: `CD_Drive:/Predefined/Variables`) and can be imported from there.

Note: Variable names must be unique in zenon. If driver variables are to be imported from `drvvar.dbf` again, the variables that were imported beforehand must be renamed.



Information

Not every driver supports all driver variants.

For example:

- ▶ Variables for modem information are only supported by modem-compatible drivers
- ▶ Driver variables for the polling cycle only for pure polling drivers
- ▶ Connection-related information such as ErrorMessage only for drivers that only edit one connection at a time

INFORMATION

Name from import	Type	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon service pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	12:00 AM	Connection in hold
LineStateConferenced	BOOL	12:00 AM	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	12:00 AM	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown

ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped For <code>driver stop</code> , the variable has the value <code>TRUE</code> and an <code>OFF</code> bit. After the driver has started, the variable has the value <code>FALSE</code> and no <code>OFF</code> bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

CONFIGURATION

Name from import	Type	Offset	Description
ReconnectInRead	BOOL	27	If <code>TRUE</code> , the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method <code>SrvDrvVarApplyCom</code> being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method <code>SrvDrvVarApplyModem</code> . This closes the current connection and opens a new one according to the settings <code>PhoneNumberSet</code> and <code>ModemHwAdrSet</code> .
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	<code>TRUE</code> , if update time is global
TreiberSimul	BOOL	5	<code>TRUE</code> , if driver in sin simulation mode
TreiberProzab	BOOL	6	<code>TRUE</code> , if the variables update list should be

			kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver
Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	USINT	14	Number of bits per character of the serial interface Value = 0 if the driver cannot establish any serial connection.
StopBit	USINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UINT	54	Time in seconds (s) to establish a connection.

STATISTICS

Name from import	Type	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group High in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

ERROR MESSAGES

Name from import	Type	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	DINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	USINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

8. Driver-specific functions

The driver supports the following functions:


None

9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function **Driver commands**. To do this:

- ▶ create a new function
- ▶ select *Variables -> Driver commands*
- ▶ The dialog for configuration is opened



Parameters	Description
Drivers	Drop-down list with all drivers which are loaded in the project.
Current state	Fixed entry which has no function in the current version.
Driver commands	Drop-down list for the selection of the command.
▶ Start driver (online mode)	Driver is reinitialized and started.
▶ Stop driver (offline mode)	Driver is stopped. No new data is accepted. Note: If the driver is in offline mode, all variables that were created for this driver receive the status switched off (OFF; Bit 20).
▶ Driver in simulation	Driver is set into simulation mode. The values of all variables of the driver are simulated by the

mode	driver. No values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Activate driver write set value	Write set value to a driver is allowed.
▶ Deactivate driver write set value	Write set value to a driver is prohibited.
▶ Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
Show this dialog in the Runtime	The dialog is shown in Runtime so that changes can be made.

DRIVER COMMANDS IN THE NETWORK

If the computer, on which the **driver command** function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10. Service and protocol specification

SIMPLE SPONTANEOUS COMMUNICATION PROTOCOL

CONNECTING INDUSTRIAL CONTROLS TO A SCADA SYSTEM

Verion 1.0

Automation and Control Institute, TU-Wien

Ing. Punzenberger COPA-DATA GmbH

INHALT

- ▶ Tables
- ▶ Introduction
- ▶ Service specification
- ▶ Common service parameters
- ▶ Subscribe service
- ▶ Unsubscribe service
- ▶ Notification service
- ▶ Write service
- ▶ Ping service
- ▶ Service directions
- ▶ Protocol specification
- ▶ Encoding of PDU data types
- ▶ PDU encoding
- ▶ PDU header
- ▶ Service parameters
- ▶ Appendix

- ▶ Generic server implementation for IEC61499 based controls

TABLES

- ▶ Table 1: Service status codes
- ▶ Table 2: Service DP-Flags
- ▶ Table 3: Subscribe service - Service parameters
- ▶ Table 4: Unsubscribe service - Service parameters
- ▶ Table 5: Notification service - Service parameters
- ▶ Table 6: Write service - Service parameters
- ▶ Table 7: Ping service - Service parameters
- ▶ Tabelle 8: Service directions
- ▶ Table 9: PDU encoding - PDU data types
- ▶ Table 10: PDU encoding – PDU header
- ▶ Table 11: PDU encoding - Type of service
- ▶ Table 12: Parameter encoding - Subscribe request
- ▶ Table 13: Parameter encoding - Subscribe response
- ▶ Table 14: Parameter encoding - Notification
- ▶ Table 15: Parameter encoding - Unsubscribe request
- ▶ Table 16: Parameter encoding - Unsubscribe response
- ▶ Table 17: Parameter encoding - Write request
- ▶ Table 18: Parameter encoding - Write response
- ▶ Table 19: Parameter encoding - Ping request
- ▶ Table 20: Parameter encoding - Ping response

INTRODUCTION

The aim of this document is the specification of a simple communication protocol enabling a SCADA system to spontaneously read data-points from industrial controls and to write values to data points.

Data-points are implicitly or explicitly defined variables with a primitive data type (BOOL, USINT, SINT, UINT, INT, UDINT, DINT, REAL, LREAL or STRING). A data-point is addressed by a numerical ID, uniquely identifying the data-point inside a control.

This specification covers the layers 5 through 7 of the ISO/OSI reference model; it does not define any requirements for the layers 1 to 4, except that a reliable connection orientated transport protocol (like TCP) must be used.

10.1 Service specification

SERVICE SPECIFICATION

Services are initiated by a service request. The service is then executed on the remote host and the execution is either explicitly acknowledged by a service response or implicitly by the lower communication layers. Services must be executed sequentially (i.e. the next service must not be initiated before the last service has been completed).

The execution domain of the services is the ISO/OSI layer four connection. A device may support multiple connections. If a connection is terminated all resources allocated to that connection and the services executed are freed in the device.

COMMON SERVICE PARAMETERS

This section describes commonly used service parameters.

TIME-STAMP

The time is given in seconds since 1.1.1970 UTC. Time units smaller than seconds can be expressed using the fractional part.

The time stamp may be zero in case the device does not support time stamping.

STATUS

Service status codes

Value	Description
0	Success
1	Reserved
2	Invalid parameters
3	Invalid data point ID
4	Operation on data point failed
5	Operation not permitted
6 . . . 240	Reserved
241 . . . 255	Device specific

Table 1: Service status codes

DP-FLAGS

This parameter contains additional status information on the data-point. It is only present in positive responses (i.e. the error-code parameter contains zero)

Flag	Bit	Description
FLAG_NO_VALUE	0	The data point does not contain a valid value

Table 2: Service DP-Flags

SUBSCRIBE SERVICE

Register a data-point (DP) for change of value reporting. When a device receives a subscribe service request and the given DP exists the device includes the current value of the DP in the service responds and starts monitoring the DP. If the value of the DP changes the device compares its value (CV) with the last value transmitted (LV) to the SCADA system. If one of the equations below becomes true a notification service request is sent by the device. The last value transmitted either by the subscribe response or a notification request must be stored internally in the device.

1. $CV > LV + \text{positive hysteresis}$
2. $CV < LV - \text{negative hysteresis}$

Positive and negative hysteresis cannot be defined for data-points of the data type STRING. For strings each change of value is reported to the SCADA system.

If the ISO/OSI layer four connection is terminated all subscribed data-points are unsubscribed automatically when the devices frees the resources allocated by the connection.

If a subscribe service request is received for a data-point, which has been already subscribed, a positive response is sent including the current value of the data point. The second request does not change the DP's subscription state, i.e. possibly differing hysteresis information is ignored.

Parameter name	Data type	Req	Res
Data-point ID	UDINT	M	M (=)
Positive hysteresis	[ANY]	O	-
Negative hysteresis	[ANY]	O	-
Status	USINT	-	M
DP-Flags	USINT	-	O
Time-stamp	LREAL	-	O
Value	[ANY]	-	O

Table 3: Subscribe service - Service parameters

DATA-POINT ID

This parameter contains the unique ID of the data point.

POSITIVE HYSTERESIS

Optional - Positive hysteresis. If this parameter is omitted the positive hysteresis is set to zero.

NEGATIVE HYSTERESIS

Optional - Negative hysteresis. If this parameter is omitted the negative hysteresis is set to zero.

STATUS

See section "Common service parameters".

FLAGS

See section "Common service parameters".

This field is only present in positive responses (i.e. the error-code parameter contains zero)

TIME-STAMP

Time-stamp describing the time the data-point has been assigned the value contained in this notification.

This field is omitted if the notification does not contain a value.

See section "Common service parameters".

VALUE

This parameter contains the current value of the data-point. It is omitted if the data-point does not contain a valid value (The flags parameter contains FLAG_NO_VALUE flag) or in case of a negative response.

(*) If positive or negative hysteresis is used both parameters must be present and of the same data type.

UNSUBSCRIBE SERVICE

Unsubscribe a data-point previously registered for change of value reporting.

Parameter name	Data type	Req	Res
Data-point ID	UDINT	M	M (=)
Status	USINT	-	M

Table 4: Unsubscribe service - Service parameters

DATA-POINT ID

This parameter contains the unique ID of the data point.

STATUS

See section "Common service parameters".

NOTIFICATION SERVICE

A notification service request is sent by the device when a monitored data-point changes its value. See section "Subscribe service".

Parameter name	Data type	Req
Data-point ID	UDINT	M
Flags	USINT	M
Time-stamp	LREAL	O
Value	[ANY]	O

Table 5: Notification service - Service parameters

DATA-POINT ID

This parameter contains the unique ID of the data point.

FLAGS

See section "Common service parameters".

This field is only present in positive responses (i.e. the error-code parameter contains zero)

TIME-STAMP

Time-stamp describing the time the data-point has been assigned the value contained in this notification.

This field is omitted if the notification does not contain a value.

See section "Common service parameters".

VALUE

This parameter contains the current value of the data-point. It is omitted if the data-point does not contain a valid value (The flags parameter contains FLAG_NO_VALUE flag) or in case of a negative response.

WRITE SERVICE

The write service is initiated by the SCADA system. It is used to write a value defined by the SCADA to the specified data-point of the device.

Parameter name	Data type	Req	Res
Data-point ID	UDINT	M	M (=)
Value	[ANY]	M	-
Status	USINT	-	M

Table 6: Write service - Service parameters

DATA-POINT ID

This parameter contains the unique ID of the data-point.

VALUE

This parameter contains the value which should be written to the data-point.

STATUS

See section "Common service parameters".

PING SERVICE

The ping service can be used by a host to verify that the connection to the remote machine is still valid. This is especially important if the connection is not cyclically tested by the lower ISO/OSI layers. This service can be initiated by either the SCADA system or the device.

Parameter name	Data type	Req	Res
Cookie	UDINT	M	M (=)
Status	USINT	-	M

Table 7: Ping service - Service parameters

COOKIE

Arbitrary value repeated in the response.

STATUS

See section "Common service parameters".

SERVICE DIRECTIONS

	SCADA system	Industrial control / PLC
Subscribe	Initiate	Execute
Unsubscribe	Initiate	Execute
Notification	Execute	Initiate
Write	Initiate	Execute
Ping	Initiate, Execute	Initiate, Execute

Tabelle 8: Service directions

10.2 Protocol specification

This chapter defines the protocol data units (PDU) used to transmit the service requests and responses already described.

ENCODING OF PDU DATA TYPES

The following table describes the encoding of the PDU data types.

Type	Encoding
BOOL	8 bit 0 ... FALSE 1 ... TRUE 2 ... 255 Reserved
SINT, USINT	8 bit
INT, UINT	16 Bit, Big-endian
DINT, UDINT	32 Bit, Big-endian
LREAL	ANSI/IEEE-754 double precision floating point (64 Bit)
[ANY]	Encoding according to ASN.1 BER

Table 9: PDU encoding - PDU data types

PDU ENCODING

This section describes the encoding of the PDUs used to transmit the service requests and responses.

PDU HEADER

Each telegram transmitted starts with the PDU header defined in the table below.

Offset	Data type	Field
0	USINT	Reserved (0)
1	UINT	Length
3	UINT	Reserved (1)
5	UINT	Service
7	-	Service parameters

Table 10: PDU encoding – PDU header

RESERVED (0) [USINT]

Reserved for future use.

LENGTH [UINT]

This field defines the length of the service parameters in Bytes.

RESERVED (1) [UINT]

Reserved for future use.

SERVICE [UINT]

This field is used to identify the service type. The possible types are listed in the following table.

Value (hex)	Type of service
0000	Reserved
0001	Subscribe request
8001	Subscribe response
0002	Unsubscribe request
8002	Unsubscribe response
0003	Notification request
0004	Write request
8004	Write response
0005	Ping request
8005	Ping response
0006...8000	Reserved
8006...FFFF	Reserved

Table 11: PDU encoding - Type of service

SERVICE PARAMETERS

The tables below describe the encoding of the service parameters defined in the section "".

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Positive hysteresis	[ANY]
-	Negative hysteresis	[ANY]

Table 12: Parameter encoding - Subscribe request

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Status	USINT
5	Flags	USINT
6	Time-stamp	U64
14	Value	[ANY]

Table 13: Parameter encoding - Subscribe response

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Flags	USINT
5	Time-stamp	U64
13	Value	[ANY]

Table 14: Parameter encoding - Notification

Offset	Parameter name	Data type
0	Data-point ID	UDINT

Table 15: Parameter encoding - Unsubscribe request

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Status	USINT

Table 16: Parameter encoding - Unsubscribe response

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Value	[ANY]

Table 17: Parameter encoding - Write request

Offset	Parameter name	Data type
0	Data-point ID	UDINT
4	Status	USINT

Table 18: Parameter encoding - Write response

Offset	Parameter name	Data type
0	Cookie	UDINT

Table 19: Parameter encoding - Ping request


Offset	Parameter name	Data type
0	Cookie	UDINT
4	Status	USINT

Table 20: Parameter encoding - Ping response

10.3 Appendix

GENERIC SERVER IMPLEMENTATION FOR IEC61499 BASED CONTROLS

The communication is done via a separate SCADA resource. This SCADA resource multiplexes the data coming from the application and puts this data stream into the server block. This is for data to be presented in the SCADA system. In the other direction (e.g. set points from SCADA) the SCADA sends a data stream to the IEC 61499 server function block. The connected de-multiplexer extracts the data and provides it to the application.



11. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

11.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.11 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder **LOG** in directory **ProgramData**, example:
 C:\ProgramData\zenon\zenon7.11\LOG for zenon Version 7.11. Log files

are text files with a special structure.

Attention: With the default settings, a driver only logs error information. With the **Diagnosis Viewer** you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- ▶ customize the logging settings
- ▶ change the folder in which the log files are saved

Hints:

1. In Windows CE even errors are not logged per default due to performance reasons.
2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
4. If you only use **Error logging**, the problem description is in column **Error text**. For other diagnosis level the description is in column **General text**.
5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** and/or **Error code** and/or **Driver error parameter (1 and 2)**. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
6. At the end of your test set back the diagnosis level from **Debug** or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the **Diagnosis Viewer**.



Information

You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.

11.2 Check list

Checks after communication errors:

- ▶ Is the PLC connected to the power supply?
- ▶ Are the participants available in the **TCP/IP** network?
- ▶ Can the PLC be reached via the **Ping** command?
- ▶ Can the PLC be reached at the respective port via **TELNET**?
- ▶ Did you configure the net address correctly, both in the driver dialog and in the address properties of the variables?
- ▶ Did you use the right object type for the variable?
- ▶ Does the offset addressing of the variable match the ID in the PLC?
- ▶ Analysis with the Diagnosis Viewer: Which messages are displayed?