

# zenon driver manual

## MODRTU32

v.7.20





©2015 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. Technical data is only used for product description and are not guaranteed qualities in the legal sense. Subject to change, technical or otherwise.

# Contents

<b>1. Welcome to COPA-DATA help .....</b>	<b>5</b>
<b>2. MODRTU32 .....</b>	<b>5</b>
<b>3. MODRTU32 - Data sheet .....</b>	<b>6</b>
<b>4. Driver history .....</b>	<b>7</b>
<b>5. Requirements.....</b>	<b>8</b>
5.1 PC .....	8
<b>6. Configuration .....</b>	<b>8</b>
6.1 Creating a driver.....	9
6.2 Settings in the driver dialog .....	10
6.2.1 General .....	11
6.2.2 Com .....	14
6.2.3 Settings .....	16
6.2.4 Connection TCP/IP.....	21
<b>7. Creating variables.....</b>	<b>23</b>
7.1 Creating variables in the Editor.....	23
7.2 Addressing.....	26
7.3 Driver objects and datatypes .....	27
7.3.1 Driver objects .....	28
7.3.2 Mapping of the data types .....	31
7.4 Creating variables by importing .....	31
7.4.1 XML import.....	32
7.4.2 DBF Import/Export .....	32
7.5 Driver variables .....	38
<b>8. Driver-specific functions .....</b>	<b>45</b>
<b>9. Driver commands .....</b>	<b>46</b>
<b>10. Error analysis.....</b>	<b>48</b>

10.1	Analysis tool .....	48
10.2	Error numbers .....	49
10.3	Check list .....	50

# 1. Welcome to COPA-DATA help

## GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to [documentation@copadata.com](mailto:documentation@copadata.com) (<mailto:documentation@copadata.com>).

## PROJECT SUPPORT

You can receive support for any real project you may have from our Support Team, who you can contact via email at [support@copadata.com](mailto:support@copadata.com) (<mailto:support@copadata.com>).

## LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email [sales@copadata.com](mailto:sales@copadata.com) (<mailto:sales@copadata.com>).

# 2. MODRTU32

The driver understands the "Modbus ASCII" protocol for serial connections, the "Modbus RTU" protocol for serial and TCP/IP connections and the "Open Modbus TCP" protocol for TCP/IP connections. The driver is a Modbus Master. (Process Gateway is available for Modbus slave).

### 3. MODRTU32 - Data sheet

General:	
Driver file name	MODRTU32.exe
Driver name	Modbus RTU and Open Modbus TCP
PLC types	All PLCs supporting Modbus RTU, Open Modbus TCP/IP or Modbus ASCII(serial)
PLC manufacturer	ABB; Gantner; GE Fanuc; Modbus RTU; Mondial; Schiele; Telemecanique; Schneider; Wago; Areva; GE Multilin; CIMON;

Driver supports:	
Protocol	Modbus RTU - serial; Open Modbus TCP; Modbus RTU over TCP; Modbus ASCII - serial;
Addressing: Address-based	x
Addressing: Name-based	-
Spontaneous communication	-
Polling communication	x
Online browsing	-
Offline browsing	-
Real-time capable	-
Blockwrite	x
Modem capable	-
Serial logging	x
RDA numerical	x
RDA String	x

Requirements:	
Hardware PC	RS 232 interface or standard network card
Software PC	-
Hardware PLC	-
Software PLC	-
Requires v-dll	x

Platforms:	
Operating systems	Windows CE 6.0, Embedded Compact 7; Windows 7, 8, 8.1 Server 2008R2, Server 2012, Server 2012R2;
CE platforms	x86; ARM;

## 4. Driver history

Date	Driver version	Change
07.07.08	4400	Created driver documentation

### DRIVER VERSIONING

The versioning of the drivers was changed with zenon 7.10. There is a cross-version build number as of this version. This is the number in the 4th position of the file version,  
For example: 7.10.0.4228 means: The driver is for version 7.10 service pack 0, and has the build number 4228.

Expansions or error rectifications will be incorporated into a build in the future and are then available from the next consecutive build number.



### Example

*A driver extension was implemented in build 4228. The driver that you are using is build number 8322. Because the build number of your driver is higher than the build number of the extension, the extension is included. The version number of the driver (the first three digits of the file version) do not have any significance in relation to this. The drivers are version-agnostic*

## 5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

### 5.1 PC

In order to establish a serial connection to the PLC, a serial COM port is required at the PC. The port must not be used and therefore blocked by other software (e.g. modem drivers, PLC software, ...) during Runtime.

This driver supports a connection via the standard network card of the PC. Make sure that the PLC and the PC are in the same network range and that the subnet masks are set accordingly on both devices.

## 6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.



### Information


*Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.*



## 6.1 Creating a driver

In order to create a new driver:

1. Right-click on **Driver** in the Project Manager and select **Driver new** in the context menu.
2. In the following dialog the control system offers a list of all available drivers.



3. Select the desired driver and give it a name:
  - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, a new name has to be given each time.

- The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (\_).
  - **Attention:** This name cannot be changed later on.
4. Confirm the dialog with **OK**. In the following dialog the single configurations of the drivers are defined.

Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.



### Information

*For new projects and for existing projects which are converted to version 6.21 or higher, the following drivers are created automatically:*

- ▶ Internal
- ▶ MathDr32
- ▶ SysDrv.


▶

## 6.2 Settings in the driver dialog

You can change the following settings of the driver:

### 6.2.1 General

The configuration dialog is opened when a driver is created. In order to be able to open the dialog later for editing, double click on the driver in the list or click on the **Configuration** property.



Parameters	Description
<b>Mode</b>	<p>Allows to switch between hardware mode and simulation mode</p> <ul style="list-style-type: none"> <li>▶ Hardware: <p>A connection to the control is established.</p> </li> <li>▶ Simulation static <p>No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.</p> </li> <li>▶ Simulation - counting <p>No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically.</p> </li> <li>▶ Simulation - programmed <p>N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).</p> </li> </ul>
<b>Keep update list in the memory</b>	<p>Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.</p>
<b>Output can be written</b>	<p>Active: Outputs can be written.</p> <p>Inactive: Writing of outputs is prevented.</p> <p><b>Note:</b> Not available for every driver.</p>
<b>Variable image remanent</b>	<p>This option saves and restores the current value, time stamp and the states of a data point.</p> <p>Fundamental requirement: The variable must have a valid value and time stamp.</p>

	<p>The variable image is saved in mode hardware if:</p> <ul style="list-style-type: none"> <li>▶ one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active</li> </ul> <p>The variable image is always saved if:</p> <ul style="list-style-type: none"> <li>▶ the variable is of the object type <b>Driver variable</b></li> <li>▶ the driver runs in simulation mode. (not programmed simulation)</li> </ul> <p>The following states are not restored at the start of the Runtime:</p> <ul style="list-style-type: none"> <li>▶ SELECT(8)</li> <li>▶ WR-ACK(40)</li> <li>▶ WR-SUC(41)</li> </ul> <p>The mode <b>Simulation - programmed</b> at the driver start is not a criterion in order to restore the remanent variable image.</p>
<b>Stop on Standby Server</b>	<p>Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.</p> <p><b>Attention:</b> If this option is active, the gapless archiving is no longer guaranteed.</p> <p><b>Active:</b> Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status <b>switched off</b> (<a href="#">statusverarbeitung.chm::/24150.htm</a>) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.</p> <p><b>Note:</b> Not available if the CE terminal serves as a data server. You can find further information in the zenon Operator manual in the CE terminal as a data server chapter.</p>
<b>Global Update time</b>	<p><b>Active:</b> The set <b>Global update time</b> in ms is used for all variables in the project. The priority set at the variables is not used.</p> <p><b>Inactive:</b> The set priorities are used for the individual variables.</p>
<b>Priority</b>	<p>The polling times for the individual priority classes are set here. All variables with the according priority are polled in the set time.</p> <p>The allocation to the variables takes place separately in the settings of the variable properties.</p> <p>The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities.</p>

	Thus the communication load is distributed better. <b>Attention:</b> Priority classes are not supported by each driver For example, drivers that communicate spontaneously do not support it.
--	--

CLOSE DIALOG


Parameters	Description
OK	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.

UPDATE TIME FOR CYCLICAL DRIVERS

The following applies for cyclical drivers:

For **Set value**, **Advising** of variables and **Requests**, a read cycle is immediately triggered for all drivers - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

6.2.2 Com



Parameters	Description
Com	Select serial interface COM1 - COM64
Data bit	Data word size in Bit: 5,6,7,8
Stop bit	1, 1.5, 2
Baud rate	Data transfer rate 110; 300; 1200; 2400; 4800; 9600; 19200; 38400; 57600; 115200
Parity	even/uneven/none
Protocol	RTS/CTS/none

#### DEFAULT CONFIGURATION

Parameters	Description
Com	COM1
Baud rate	Adjust after setting on PLC
Data bit	8
Stop bit	1
Parity	Adjust after setting on PLC
Protocol	NO

6.2.3 Settings

Configuration

General

Com

Settings

Conn. TCP/IP

Connection

☒ Serial

☐ ASCII

☐ TCP/IP

☐ RTU Frame

General

TCP configuration file

MODRTU32\_Modbus RTU and Open Mod

Maximum block size

32

☐ RTS Handshake

☐ Offset 1

☐ Skip not existing registers

Byte order for DWORD

☐ Intel Format (Little-Endian)

☒ Motorola Format (Big-Endian)

Byte order for FLOAT

☐ HB-Controller (Little-Endian)

☒ Modbus Standard (Big-Endian)

Byte order for STRING

☒ PC-Format (Little-Endian)

☐ Modbus Standard (Big-Endian)

Error handling

Connection timeout

3000 ms

Connection retries

6

Reconnection delay

20000 ms

Send delay

10 ms

OK

Cancel

Help



## CONNECTION

Parameters	Description
<b>Connection</b>	Definition of which connection is used.
<b>Serial</b>	For serial mode, both <b>Modbus RTU</b> and <b>Modbus ASCII</b> can be selected.
<b>ASCII</b>	Active: The driver communicates using the Modbus ASCII protocol. Inactive: The driver communicates using <b>Modbus RTU</b> .
<b>TCP/IP</b>	Requires a configuration file. This file stores the TCP/IP settings.
<b>RTU Frame</b>	Active: Serial information is transferred to the TCP protocol exactly.

## GENERAL

Parameters	Description
<b>General</b>	General settings.
<b>TCP configuration file</b>	The name of the TCP configuration file is defined here. Default: <b>MODRTU32_[Treiberbezeichnung].txt</b>
<b>Maximum block size</b>	Maximum block size of a data telegram in WORDs. <b>Attention zenon before 5.50 SP6:</b> Block size must be less than 64. (1-125, Default 32)
<b>RTS Handshake</b>	Some PLCs need the RTS handshake for correct communication.
<b>Offset 1</b>	The "Offset 1" affects the addressing of all variables. Active: The driver subtracts 1 when the variable addresses (coils, register) are sent and adds 1 when they are received.
<b>Skip non-existent tabs</b>	The driver reads data in a block. If there is no data between two address areas close to each other, the driver will still try to access these non-existent areas. This option will avoid that.

## BYTE SEQUENCE FOR DWORD

Parameters	Description
<b>Byte sequence for DWORD</b>	Defines the sequence of lower-value and higher-value words for double word objects (DINT/UDINT). You can choose between Motorola (Big-Endian) and Intel (Little-Endian).

<b>Motorola Format (Big-Endian)</b>	Active: DWORD ordering in accordance with Motorola format.
<b>Intel Format (Little-Endian)</b>	Active: DWORD ordering in accordance with Intel format.

#### BYTE SEQUENCE FOR FLOAT

Parameters	Description
Byte sequence for FLOAT	Defines the sequence of lower-value and higher-value words for FLOAT objects (REAL). You can choose between Modbus Standard (Big-Endian) and HB-Controller (Little-Endian).
<b>Modbus Standard (Big-Endian)</b>	Active: Float ordering in accordance with Modbus standard.
<b>HB Controller Float (Little-Endian)</b>	Active: Float ordering in accordance with HB controller.

#### BYTE SEQUENCE FOR STRING

Parameters	Description
Byte sequence for STRING	Defines display of the byte sequence.  <b>Note:</b> If there is relevant information in the documentation of a PLC the following is usually applicable: MSB-first = Motorola = Big-Endian = Modbus. And: Intel = Little-Endian = PC. This can be handled differently in some documentation however.
<b>Modbus Standard (Big-Endian)</b>	Active: Display in accordance with Modbus standard with switched characters.
<b>PC Format (Little-Endian)</b>	Active: Display in PC format with ascending sequence.

#### TROUBLESHOOTING

Parameters	Description
Error treatment	
<b>Connection timeout</b>	<p>Time in milliseconds to wait for a response from the slave. A communication error will be displayed if there is no response within this time.</p> <p>Only available with serial connection. For a TCP/IP connection, the setting for the <b>Timeout [s]</b> property in the <b>Network</b> node is used for the connection time-out.</p> <p><b>Note:</b> The <b>communication time-out</b> time must at any rate be higher than the maximum response time of the Modbus RTU Slave. Otherwise</p>


	misinterpretation of the responses can occur. Default: 3000 ms
<b>Retries on error</b>	Number of send repetitions when there is no answer from the slave after the set <b>communication time-out</b> . 1: a connection attempt, no repetitions 0: constant repetition Default: 6
<b>Delay after connection termination</b>	Time in milliseconds to wait after a communication error has occurred before trying to re-establish the connection. Default: 20000 ms
<b>Send delay</b>	Time delay in milliseconds for "send" orders. Affects the whole driver. Can only be selected with a serial connection.
<b>OK</b>	Applies changes and closes dialog.
<b>Cancel</b>	Discards changes and closes dialog.
<b>Help</b>	Opens online help.

## TIME OUT BEHAVIOR


With TCP connections, the communication time out is predefined by the system-dependent **Timeout [s]**.

After the timeout has expired, the driver attempts - with default settings - to send the request again up to 5 times. If these 5 attempts are not successful, no additional attempt to connect is made during the **reconnect time out**.

With serial connection the times from the driver configuration are used for the time out behavior. The sent delay time must pass before a request is sent. After a request has been sent, the time period which is waited for an answer is as long as the connection timeout. If there is no answer in this time period, the request is sent again up to 5 times. (a default of 6 means 5 additional attempts). After that no new connection establishment is tried for the set reconnect time out. See also the following graphic.



6.2.4 Connection TCP/IP



Parameters	Description
Connection file	<p>Name of the file in which the settings for each of the TCP/IP participants are saved.</p> <p>Display only. Changes to the file name are made in the <b>Options</b> (on page 16) tab.</p>
Connections	Settings of the connections.
Connection list	List of defined connections to PLCs.
Net address	<p>Each connection is assigned a network address. This must correspond to the settings in the <b>Net address</b> property of the variable definition.</p> <p>The value 0 is reserved for broadcasts.</p> <p><b>Note:</b> For MODBUS TCP communication via a gateway (TCP/IP on RS485) the address of the destination station (the Modbus unit ID or slave address) must be used.</p> <p>With a direct MODBUS TCP connection, the <b>unit ID</b> address field is ignored by some devices, because the TCP/IP address of the controller is sufficient in principle. In this case, any desired value can be set.</p>
Connection name	Name of the connection as it is displayed in the connection list.
Remote IP address	Address of the PLC.
Remote port	<p>Port address of PLC. You can find details in the manual of your PLC.</p> <p>Standard port: 502</p>
New	Establishes a new connection.
Clear	Deletes highlighted connection from the list.
Edit	Opens highlighted connection for editing.
Save	Accepts all changes for edited connection and closes editing option.
Cancel	Discards all changes for edited connection and closes editing option.
Ping	Sends a ping to the IP address that is configured for this connection. Allows the connection to the device to be tested. If the ping is concluded with a negative response, check the IP address and check to see if the device is online.
OK	<p>Accept changes in the dialog and close dialog.</p> <p>Only available if no connection is in the "edit" state.</p>
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

## CREATE NEW CONNECTION

1. click on the button **New**
2. Enter the connection details.

3. Click on **Save**

### **EDIT CONNECTION**

1. select the connection in the connection list
2. click on the button **Edit**
3. change the connection parameters
4. finish with **Save**

### **DELETE CONNECTION**

1. select the connection in the connection list
2. click on the button **Delete**
3. the connection will be removed from the list

## **7. Creating variables**

This is how you can create variables in the zenon Editor:

### **7.1 Creating variables in the Editor**


Variables can be created:

- ▶ as simple variables
- ▶ in arrays (main.chm::/15262.htm)
- ▶ as structure variables (main.chm::/15278.htm)

### **VARIABLE DIALOG**

To create a new variable, regardless of which type:

1. Select the **New variable** command in the **variables** node in the context menu



2. The dialog for configuring variables is opened
3. configure the variable



4. The settings that are possible depends on the type of variables



The screenshot shows the 'Create variable' dialog box with the following settings:

- Settings**
  - Name: S\_Variable
  - Driver: SIMUL32 - SIMUL\_WIZ
  - Driver object type: PLC marker
  - Datatype: REAL
- Array settings**
  - ☐ Start index is 0
  - ☒ Start index is 1
  - Dim 1: 0
  - Dim 2: 0
  - Dim 3: 0
- Addressing options**
  - ☒ Automatic addressing
  - ☐ Addressing according to data type offset and start offset
  - ☐ Manual addressing
  - ☒ Each datatype starts with new offset
- Automatic addressing**
  - ☒ Activate all elements
  - ☐ Activate element manually

Buttons at the bottom: Back, Finish, Cancel, Help.

Property	Description
<b>Name</b>	<p>Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.</p> <p>Maximum length: 128 Zeichen</p> <p><b>Attention:</b> The characters # and @ are not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the <b>Finish</b> button remains inactive.</p> <p>Note: For some drivers, the addressing is possible over the property <b>Symbolic address</b>, as well.</p>
<b>Driver</b>	<p>Select the desired driver from the drop-down list.</p> <p><b>Note:</b> If no driver has been opened in the project, the driver for internal variables (Intern.exe (Main.chm::/Intern.chm::/Intern.htm)) is automatically loaded.</p>
<b>Driver object type</b> (cti.chm::/28685.htm)	Select the appropriate driver object type from the drop-down list.
<b>Data type</b>	Select the desired data type. Click on the ... button to open the selection dialog.
<b>Array settings</b>	Expanded settings for array variables. You can find details in the Arrays chapter.
<b>Addressing options</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.
<b>Automatic element activation</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.

## INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- ▶ derived from the datatype
- ▶ Automatically adapted if the data type is changed

**Note for signal range:** If a change is made to a data type that does not support the set **signal range**, the **signal range** is amended automatically. For example, for a change from **INT** to **SINT**, the **signal range** is changed to 127. The amendment is also carried out if the **signal range** was not inherited from the data type. In this case, the **measuring range** must be adapted manually.

## 7.2 Addressing

Property	Description
<b>Name</b>	Any name can be chosen; <b>ATTENTION:</b> the name must be unique within each project.
<b>Reference</b>	Any text can be entered here, e.g. for resource labels, comments ...
<b>Net address</b>	<p>Bus address (slave address) or net address of the variable.</p> <p>This address relates to serial communication to the Modbus address of the PLC - the address of the recipient. For communication via Ethernet, it also relates to the connection configuration in the driver. This defines the PLC/connection on which the variable resides.</p> <p>If a gateway (e.g. TCP/IP on RS485) is used for communicating with the Modbus stations, you have to create a separate TCP/IP connection for each Modbus station. Use the address of the gateway as the IP address and the address of the Modbus station as the Net address of the connection and in the variables.</p> <p>The highest possible Modbus address, according to the protocol specification, is 247. The address 0 is used for Broadcast messages (write only).</p>
<b>Data block</b>	not used for this driver
<b>Offset</b>	Offset of the variable; the memory address of the variable in the PLC. Configurable [0.. 4294967295]
<b>Alignment</b>	The driver uses word-based addressing (16 bit). If only one Byte is read, you can configure here whether the HiByte or the LowByte will be addressed.
<b>Bit number</b>	<p>Number of the bit within the configured offset.</p> <p>Valid input [0.. 65535] Working range [0-15]</p>
<b>String length</b>	Only available for String variables: Maximum number of characters that the variable can take.
<b>Driver object type</b>	Depending on the employed driver, an object type is selected during the creation of the variable; the type can be changed here later.
<b>Data type</b>	<p>Data type of the variable, which is selected during the creation of the variable; the type can be changed here later.</p> <p><b>ATTENTION:</b> If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.</p>

## 7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

### 7.3.1 Driver objects

The following object types are available in this driver:

Driver-object type	Channel type	Read: Modbus function (hex/dec code)	Write: Modbus function (hex/dec code)	Supported data types	Comment
Alarm stack	97	0x03 / 3	N/A	STRING	Read special events from Secheron PLC.  Addressing: <ul style="list-style-type: none"> <li>▶ Event type = <b>data block</b></li> <li>▶ Sub-type = <b>offset</b>.</li> </ul>
Analog Input	10	0x04 / 4	N/A	REAL, LREAL, BOOL, DINT, UDINT, USINT, INT, UINT, SINT, STRING	Class 1 - input register.  Linear addressing as with holding register.
Byte aligned Coil	69	0x01 / 1	0x0F/15	BOOL	Class 1 - coil.  Linear addressing one-step via <b>offset</b> .
Coil	65	0x01 / 1	0x05 / 5	BOOL	Class 1 - coil.  Linear addressing one-step via <b>offset</b> .
Device status	24	0x11 / 17	N/A	BOOL, USINT	PLC specific.
Device identification	68	0x2B / 43	N/A	STRING	PLC specific.
Input status	66	0x02/2	N/A	BOOL	Class 1 - input discretes.  Linear addressing one-step via <b>offset</b> .
Holding Register	8	0x03 / 3	0x10 / 16	REAL, LREAL, BOOL, DINT, UDINT, USINT, INT, UINT, SINT, STRING	Class 0 - multiple register.  Linear addressing: <ul style="list-style-type: none"> <li>▶ Bit: one-step via <b>Offset</b> and <b>bit number</b></li> <li>▶ Byte (8 bits): one-step via <b>Offset</b> and <b>Orientation</b></li> <li>▶ Word (16 bits) Double word (32 bits)</li> </ul>

					Float (32 bits) String(n*Byte): one-step via <b>Offset</b>
Holding Register 32 Bit	70	0x03 / 3	0x10 / 16	REAL	32 bits (4 bytes) are read per offset.
Holding Register 64 Bit	71	0x03 / 3	0x10 / 16	LREAL	64 bits (8 bytes) are read per offset.
Preset Single Register (FC 6)	67	N/A	0x06 / 6	UINT	Class 1 - single register.
Driver variable	35	Y	Y	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the statistical analysis of communication.  <b>Note:</b> Transfers between Runtime and driver not to the PLC.  Find out more in the chapter about the Driver variables (on page 38)

## MODBUS FUNCTION CODES

Function code hex/dec	Modbus identifier	Comment
0x01 / 1	Read coils	This function code is used to read from 1 to 2000 contiguous status of coils (bits) in a remote device
0x02/2	Read discrete inputs	This function code is used to read from 1 to 2000 contiguous status of discrete inputs (bits) in a remote device
0x03 / 3	Read multiple registers	This function code is used to read a block of contiguous holding registers (1 to 125 words) in a remote device.
0x04 / 4	Read input registers	This function code is used to read a block of contiguous input registers (1 to 125 words) in a remote device.
0x05 / 5	Write coil	This function code is used to write a single output (one bit) to either ON or OFF in a remote device.
0x06 / 6	Write single register	This function code is used to write a single (one word) holding register in a remote device.
0x10 / 16	Write multiple registers	This function code is used to write a block of contiguous holding registers (1 to approx. 120 words) in a remote device.

0x11 / 17	Report Slave ID	This function code is used to read the description of the type, the current status, and other information specific to a remote device.
0x2B / 43	Read Device Identification	This function code allows reading the identification and additional information relative to the physical and functional description of a remote device.

### 7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

#### EXAMPLE FOR ALL POSSIBLE ZENON DATA TYPES:

Control	zenon	Data type
BOOL	BOOL	8
BYTE	SINT	10
BYTE	USINT	9
WORD	INT	1
WORD	UINT	2
DWORD	DINT	3
DWORD	UDINT	4
FLOAT	REAL	5
FLOAT	LREAL	6
STRING	STRING	12

**Data type:** The property **Data type** is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

## 7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



### Information

You can find details on the import and export of variables in the Import-Export (main.chm::/13028.htm) manual in the Variables (main.chm::/13045.htm) section.

## 7.4.1 XML import

For the import/export of variables the following is true:

- ▶ The import/export must not be started from the global project.
- ▶ The start takes place via:
  - Context menu of variables or data typ in the project tree
  - or context menu of a variable or a data type
  - or symbol in the symbol bar variables



### Attention

*When importing/overwriting an existing data type, all variables based on the existing data type are changed.*

#### **Example:**

*There is a data type XYZ derived from the type `INT` with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type `STRING`. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer `INT` variables, but `STRING` variables.*

## 7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.





### Information

*Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.*

## IMPORT DBF FILE

To start the import:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Import dBase** command
3. follow the import assistant

The format of the file is described in the chapter File structure.



### Information

*Note:*

- ▶ Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

## EXPORT DBF FILE

To start the export:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Export dBase...** command
3. follow the export assistant



### Attention

DBF files:

- ▶ must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ must not have dots (.) in the path name.  
e.g. the path `C:\users\John.Smith\test.dbf` is invalid.  
Valid: `C:\users\JohnSmith\test.dbf`
- ▶ must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



### Information

*dBase does not support structures or arrays (complex variables) at export.*

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:



### Attention

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- ▶ conform with there name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- ▶ Be stored close to the root directory (Root)

## STRUCTURE

Description	Type	Field size	Comment
KANALNAME	Char	128	Variable name. The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
KANAL_R	C	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (field/column must be entered manually). The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	C	128	Identification. The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
EINHEIT	C	11	Technical unit
DATENART	C	3	Data type (e.g. bit, byte, word, ...) corresponds to the data type.
KANALTYP	C	3	Memory area in the PLC (e.g. marker area, data area, ...) corresponds to the driver object type.
HWKANAL	Num	3	Bus address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADDRESS	N	5	Offset
BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipe Group Manager
LES_SCHR	R	1	Write-Read-Authorization

			0: Not allowed to set value. 1: Allowed to set value.
MIT_ZEIT	R	1	time stamp in zenon zenon (only if supported by the driver)
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJEKTYP and DATENTYP
SIGMIN	Float	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
MEMTIEFE	N	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	N	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST_MINUS	F	16	Negative hysteresis, from measuring range
PRIOR	N	16	Priority of the variable
REAMATRIZE	C	32	Allocated reaction matrix
ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks
RESOURCE	C	128	Resources label. Free string for export and display in lists.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: Non-linear value adaption is not used

ADJZENON	C	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	C	128	ed VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

**Attention**

*When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.*

**LIMIT DEFINITION**

Limit definition for limit values 1 to 4, and status 1 bis 4:

Description	Type	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	technical value or ID number of a linked variable for a dynamic limit (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit
HYSTERESE1	F	14	Is not used
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Functions linking
ASK_FUNC1	R	1	Execution via Alarm Message List
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/event group
A_KLASSE1	N	10	Alarm/event class
MIN_MAX1	C	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	C	66	Limit text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

**EXPRESSIONS IN THE COLUMN "COMMENT" REFER TO THE EXPRESSIONS USED IN THE DIALOG BOXES FOR THE DEFINITION OF VARIABLES. FOR MORE INFORMATION, SEE CHAPTER VARIABLE DEFINITION.**

## 7.5 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- ▶ Information
- ▶ Configuration
- ▶ Statistics and
- ▶ Error message

The definitions of the variables defined in the driver kit are available in the import file `drvvar.dbf` (on the CD in the directory: `CD_Drive:/Predefined/Variables`) and can be imported from there.

**Note:** Variable names must be unique in zenon. If driver variables are to be imported from `drvvar.dbf` again, the variables that were imported beforehand must be renamed.



### Information

*Not every driver supports all driver variants.*

*For example:*

- ▶ Variables for modem information are only supported by modem-compatible drivers
- ▶ Driver variables for the polling cycle only for pure polling drivers
- ▶ Connection-related information such as ErrorMessage only for drivers that only edit one connection at a time

## INFORMATION

Name from import	Type	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon Service Pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy



LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped  For <code>driver stop</code> , the variable has the value <code>TRUE</code> and an <b>OFF</b> bit. After the driver has started, the variable has the value <code>FALSE</code> and no <b>OFF</b> bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

## CONFIGURATION

Name from import	Type	Offset	Description
ReconnectInRead	BOOL	27	If <code>TRUE</code> , the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method <code>SrvDrvVarApplyCom</code> being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method <code>SrvDrvVarApplyModem</code> . This closes the current connection and opens a new one according to the settings <b>PhoneNumberSet</b> and <b>ModemHwAdrSet</b> .

PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver
Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baud rate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	USINT	14	Number of bits per character of the serial interface  Value = 0 if the driver cannot establish any serial connection.
StopBit	USINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)

WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UINT	54	Time in seconds (s) to establish a connection.

## STATISTICS

Name from import	Type	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts

MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group <b>Normal</b> in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group <b>Higher</b> in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group <b>High</b> in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group <b>Highest</b> in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

## ERROR MESSAGE

Name from import	Type	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.

RdErrHwAdresse	DINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	USINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

## 8. Driver-specific functions

The driver supports the following functions:

### BLOCKWRITE

You can activate blockwrite to make the sending of a large number of set value (e.g. recipes) more efficient. Variables that reside next to each other in the PLC memory will then be written into one write telegram; for larger areas, the variables will be packed into a few telegrams instead of writing every single variable.

Activating blockwrite

The following entry must be added to the project.ini :

```
[MODRTU32]
```

```
BLOCKWRITE=1
```

### TRANSACTION IDENTIFICATION


The driver increases the transaction identifier for each packet sent and expects a response from the slave with the same identifier or 0.

## 9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function **Driver commands**. To do this:

- ▶ create a new function
- ▶ select *Variables -> Driver commands*
- ▶ The dialog for configuration is opened



Parameters	Description
<b>Drivers</b>	Drop-down list with all drivers which are loaded in the project.
<b>Current state</b>	Fixed entry which has no function in the current version.
Driver commands	Drop-down list for the selection of the command.
▶ Start driver (online mode)	Driver is reinitialized and started.
▶ Stop driver (offline mode)	Driver is stopped. No new data is accepted. <b>Note:</b> If the driver is in offline mode, all variables that were created for this driver receive the status <code>switched off</code> (OFF; Bit 20).
▶ Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Activate driver write set value	Write set value to a driver is allowed.
▶ Deactivate driver write set value	Write set value to a driver is prohibited.
▶ Establish connection with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
<b>Show this dialog in the Runtime</b>	The dialog is shown in Runtime so that changes can be made.

## DRIVER COMMANDS IN THE NETWORK

If the computer, on which the **driver command** function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

## 10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

### 10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under *Start/All programs/zenon/Tools 7.20 -> Diagviewer*.

zenon driver log all errors in the log files. The default folder for the log files is subfolder `LOG` in directory `ProgramData`, example:

`C:\ProgramData\COPA-DATA\LOG`. Log files are text files with a special structure.

**Attention:** With the default settings, a driver only logs error information. With the **Diagnosis Viewer** you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ follow currently created entries live
- ▶ customize the logging settings
- ▶ change the folder in which the log files are saved

#### Note:

1. In Windows CE even errors are not logged per default due to performance reasons.
2. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
3. The Diagnosis Viewer does not display all columns of a log file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
4. If you only use **Error logging**, the problem description is in column **Error text**. For other diagnosis level the description is in column **General text**.
5. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** and/or **Error code** and/or **Driver error parameter (1 and 2)**. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
6. At the end of your test set back the diagnosis level from **Debug** Or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the **Diagnosis Viewer**.



You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) chapter.

## 10.2 Error numbers

The following error codes apply ONLY for the error messages

CallSPSread FAMLED ! ERROR:' and

'CallSPSwrite FAMLED ! ERROR:'

<b>-1</b>	Invalid function
<b>-2</b>	Invalid MW address
<b>-3</b>	Invalid date
<b>-4</b>	Slave error
<b>-7</b>	Slave cannot execute function
<b>-8</b>	Slave memory parity error
<b>-10</b>	Timeout while communicating with Slave
<b>-11</b>	Read request failed! Communication with PLC impossible.

The fields Para1 and Para2 contain additional information about the variable that cannot be read:

The number relate to the internal ID

Para1: Channel type (e.g.: 8=Holding Register)

8: Holding Register

10 Input Register

24 Status

65 COIL

66 Input Status

67 Preset Single Register

Para2: Data type (e.g: 2= Word, UINT)

- 1: INT
- 2: UINT
- 3: DINT
- 4: UDINT
- 5: REAL
- 8: BOOL
- 9: SINT
- 10: USINT

### 10.3 Check list

- ▶ Is the COM port in use by another application or are the settings incorrect?
- ▶ Is the device (PLC) that you are trying to communicate with connected to the power supply?
- ▶ Is the cable between PLC and PC/IPC connected correctly?
- ▶ Do the used addresses exist in the PLC ?
- ▶ Was the log file analyzed with the help of the Diagnosis Viewer? (Which errors occurred)?
- ▶ For communication via TCP: is the port that has been set free and not blocked by a firewall?
- ▶ Test with telnet: can you establish a connection?