




**COPADATA**  
do it your way

# zenon driver manual

## MODBUS\_ENERGY

v.7.50





©2016 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. Technical data is only used for product description and are not guaranteed qualities in the legal sense. Subject to change, technical or otherwise.

# Contents

<b>1. Welcome to COPA-DATA help .....</b>	<b>5</b>
<b>2. MODBUS_ENERGY .....</b>	<b>5</b>
<b>3. MODBUS_ENERGY - Data sheet.....</b>	<b>6</b>
<b>4. Driver history .....</b>	<b>8</b>
<b>5. Requirements.....</b>	<b>9</b>
5.1 Control .....	9
<b>6. Configuration .....</b>	<b>9</b>
6.1 Creating a driver.....	10
6.2 Settings in the driver dialog .....	12
6.2.1 General .....	12
6.2.2 Settings.....	15
6.2.3 Connections.....	19
<b>7. Creating variables.....</b>	<b>21</b>
7.1 Creating variables in the Editor.....	22
7.2 Addressing.....	25
7.3 Driver objects and datatypes .....	27
7.3.1 Driver objects .....	27
7.3.2 Mapping of the data types .....	37
7.4 Creating variables by importing .....	38
7.4.1 XML import.....	39
7.4.2 DBF Import/Export .....	39
7.5 Driver variables .....	48
<b>8. Driver-specific functions .....</b>	<b>54</b>
8.1 ICE NPx800 .....	57
8.2 GE Multilin UR series.....	61
8.3 COSTRONIC DFB .....	62
<b>9. Driver commands .....</b>	<b>64</b>

<b>10. Error analysis.....</b>	<b>66</b>
10.1 Analysis tool .....	66
10.2 Check list .....	68

# 1. Welcome to COPA-DATA help

## GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to [documentation@copadata.com](mailto:documentation@copadata.com) (<mailto:documentation@copadata.com>).

## PROJECT SUPPORT

You can receive support for any real project you may have from our Support Team, who you can contact via email at [support@copadata.com](mailto:support@copadata.com) (<mailto:support@copadata.com>).

## LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email [sales@copadata.com](mailto:sales@copadata.com) (<mailto:sales@copadata.com>).

# 2. MODBUS\_ENERGY

The Open Modbus TCP/IP driver supports Sequence of Events for energy projects and in addition (also for non energy projects) communication via a TCP/IP gateway with several slaves connected to the same serial bus.

When using a Modbus gateway, the driver can be configured so that only one TCP connection to the gateway will be established, even with several devices (slaves) behind the gateway.

The driver supports the reading of the event buffer (events) of:

- AREVA MiCOM P125/P126/P127

- ▶ COSTRONIC DFB: supports the reading of events from the Schneider Modicon TSX Premium PLC with the "lynxPileHorodatageV3a" function block (DFB) created by Costronic SA ([www.costronic.ch](http://www.costronic.ch) (<http://www.costronic.ch>)).
- ▶ GE Multilin F650 and UR series controls
- ▶ IEC NPx800
- ▶ Schneider SEPAM

### 3. MODBUS\_ENERGY - Data sheet

General:	
Driver file name	MODBUS_ENERGY.exe
Driver name	Modbus Energy driver
PLC types	All controllers and gateways supporting Open Modbus TCP/IP. Sequence of Events is only available for AREVA MiCOM P126/P127, GE Multilin F650, GE Multilin UR-series, ICE NPI 800, ICE NPID 800 and Schneider MODICON TSX (Premium, M340, Quantum) with Function block (DFB) from Costronic and Schneider Sepam Protection Relais.
PLC manufacturer	ABB; GE Automation&Controls; Modbus RTU; Mondial; Schiele; Telemecanique; Schneider; Wago; SE Elektronik; Areva; GE Multilin; ICE; Costronic;

Driver supports:	
Protocol	Modbus RTU over TCP;
Addressing: Address-based	X
Addressing: Name-based	--
Spontaneous communication	X
Polling communication	X
Online browsing	--
Offline browsing	--
Real-time capable	X
Blockwrite	X
Modem capable	--
Serial logging	--
RDA numerical	X
RDA String	--

Requirements:	
Hardware PC	--
Software PC	--
Hardware PLC	--
Software PLC	For Schneider MODICON TSX Premium: Function block (DFB) "cosZenonPileHorodatageV2c" from Costronic
Requires v-dll	--

Platforms:	
Operating systems	Windows CE 6.0, Embedded Compact 7; Windows 7, 8, 8.1, 10, Server 2008R2, Server 2012, Server 2012R2;
CE platforms	x86; ARM;

## 4. Driver history

Date	Driver version	Change
26.03.09	500	Created driver documentation  The first release test has been conducted (GE Multilin F650 and Areva MiCOM P127 )
14.10.09	900	Added COSTRONIC DFB and IEC NPx800.
07.01.10	1100	GE Multilin UR series added
09.06.10	1699	Schneider SEPAM added
15.01.2016	25506	New driver object type File record

### DRIVER VERSIONING

The versioning of the drivers was changed with zenon 7.10. There is a cross-version build number as of this version. This is the number in the 4th position of the file version,  
For example: **7.10.0.4228** means: The driver is for version **7.10** service pack **0**, and has the build number **4228**.

Expansions or error rectifications will be incorporated into a build in the future and are then available from the next consecutive build number.



#### Example

*A driver extension was implemented in build **4228**. The driver that you are using is build number **8322**. Because the build number of your driver is higher than the build number of the extension, the extension is included. The version number of the driver (the first three digits of the file version) do not have any significance in relation to this. The drivers are version-agnostic*



## 5. Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

### 5.1 Control

For the use of the Modbus Energy Driver, the following conditions apply:

- ▶ The PLC must support the Open Modbus TCP/IP protocol in the conformity class 0
- ▶ The reading of the event buffer is only possible with the PLCs mentioned in chapter MODBUS\_ENERGY (on page 5).
- ▶ The PLCs should be set to UTC time. The driver assumes that all incoming time stamps are in UTC time.

#### AREVA MICOM P125/P126/P127

The time format in Areva MiCOM P12/P125/P127 Register 012Fh should be set to "Internal format" (not to "IEC format").

#### COSTRONIC DFB

The block should be carried out by task "FAST" and should be configured as follows.

- ▶ **ControleVie**, **IndiceEchange** and **balEvenements** must be behind one another, for example %MW900 and %MW901 and %MW902:56
- ▶ **balEvenements** must be 56 registers large
- ▶ **NombreMaxEven...** must lie between 1 and 7 (number of events in the mailbox)
- ▶ The stack for buffering of events is connected to **pile**
- ▶ **tableEvenements** contains the status of all events (1 bit per event)
- ▶ **numeroPremierEvenement** must be 0.

## 6. Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.



### Information


*Find out more about further settings for zenon variables in the chapter Variables (main.chm::/15247.htm) of the online manual.*

## 6.1 Creating a driver

In order to create a new driver:

1. Right-click on **Driver** in the Project Manage and select **Driver new** in the context menu.

2. In the following dialog the control system offers a list of all available drivers.



3. Select the desired driver and give it a name:
  - The driver name has to be unique, i.e. if one and the same driver is to be used several times in one project, a new name has to be given each time.
  - The driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (\_).
  - Attention: This name cannot be changed later on.

4. Confirm the dialog with **OK**. In the following dialog the single configurations of the drivers are defined.

Only the respective required drivers need to be loaded for a project. Later loading of an additional driver is possible without problems.



### Information

*For new projects and for existing projects which are converted to version 6.21 or higher, the following drivers are created automatically:*

- ▶ Internal
- ▶ MathDr32
- ▶ SysDrv.


▶

## 6.2 Settings in the driver dialog

You can change the following settings of the driver:

### 6.2.1 General

The configuration dialog is opened when a driver is created. In order to be able to open the dialog later for editing, double click on the driver in the list or click on the **Configuration** property.



Parameters	Description
<b>Mode</b>	<p>Allows to switch between hardware mode and simulation mode</p> <ul style="list-style-type: none"> <li>▶ Hardware: <p>A connection to the control is established.</p> </li> <li>▶ Simulation static <p>No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.</p> </li> <li>▶ Simulation - counting <p>No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically.</p> </li> <li>▶ Simulation - programmed <p>N communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).</p> </li> </ul>
<b>Keep update list in the memory</b>	<p>Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.</p>
<b>Output can be written</b>	<p>Active: Outputs can be written.</p> <p>Inactive: Writing of outputs is prevented.</p> <p>Note: Not available for every driver.</p>
<b>Variable image remanent</b>	<p>This option saves and restores the current value, time stamp and the states of a data point.</p> <p>Fundamental requirement: The variable must have a valid value and time stamp.</p>

	<p>The variable image is saved in mode hardware if:</p> <ul style="list-style-type: none"> <li>▶ one of the states S_MERKER_1(0) up to S_MERKER8(7), REVISION(9), AUS(20) or ERSATZWERT(27) is active</li> </ul> <p>The variable image is always saved if:</p> <ul style="list-style-type: none"> <li>▶ the variable is of the object type <b>Driver variable</b></li> <li>▶ the driver runs in simulation mode. (not programmed simulation)</li> </ul> <p>The following states are not restored at the start of the Runtime:</p> <ul style="list-style-type: none"> <li>▶ SELECT(8)</li> <li>▶ WR-ACK(40)</li> <li>▶ WR-SUC(41)</li> </ul> <p>The mode <b>Simulation - programmed</b> at the driver start is not a criterion in order to restore the remanent variable image.</p>
<b>Stop on Standby Server</b>	<p>Setting for redundancy at drivers which allow only on communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.</p> <p><b>Attention:</b> If this option is active, the gapless archiving is no longer guaranteed.</p> <p><b>Active:</b> Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status <b>switched off (statusverarbeitung.chm::/24150.htm)</b> but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.</p> <p><b>Note:</b> Not available if the CE terminal serves as a data server. You can find further information in the zenon Operator manual in the CE terminal as a data server chapter.</p>
<b>Global Update time</b>	<p><b>Active:</b> The set <b>Global update time</b> in ms is used for all variables in the project. The priority set at the variables is not used.</p> <p><b>Inactive:</b> The set priorities are used for the individual variables.</p>
<b>Priority</b>	<p>The polling times for the individual priority classes are set here. All variables with the according priority are polled in the set time.</p> <p>The allocation to the variables takes place separately in the settings of the variable properties.</p> <p>The communication of the individual variables are graduated in respect of importance or necessary topicality using the priorities.</p>

	<p>Thus the communication load is distributed better.</p> <p>Attention: Priority classes are not supported by each driver For example, drivers that communicate spontaneously do not support it.</p>
--	--

#### CLOSE DIALOG

Parameters	Description
<b>OK</b>	Applies all changes in all tabs and closes the dialog.
<b>Cancel</b>	Discards all changes in all tabs and closes the dialog.
<b>Help</b>	Opens online help.

#### UPDATE TIME FOR CYCLICAL DRIVERS

The following applies for cyclical drivers:


For **Set value**, **Advising** of variables and **Requests**, a read cycle is immediately triggered for all drivers - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. Update times can therefore be shorter than pre-set for cyclical drivers.

### 6.2.2 Settings

You can configure the general settings for all Open Modbus TCP/IP connections in the tab **Settings**. To do this:

- ▶ click on the property **Configuration** in the group **General**
- ▶ now the dialog for the configuration of the driver opens.

- select the Settings tab





## COMMUNICATION PARAMETER

Parameters	Description
<b>Communication parameter</b>	
<b>Maximum block size</b>	<p>Defines the maximum number of registers that can be queried or written using a data telegram. The configured value applies for both read and write requests. If you configure a value bigger than 100, a maximum number of 100 registers will be used for write requests.</p> <p>Allowed value range: 1 - 125.</p>
<b>Offset 1</b>	<p>Active: The driver subtracts 1 when the variable addresses (coils, register) are sent and adds 1 when they are received.</p> <p>Affects the addressing of all variables.</p>
<b>Grouping connections to PLCs with the same IP address</b>	<p>Active: Connections with the same IP address and port number will be grouped.</p> <p>If you want to establish only one TCP connection to a gateway, activate this option.</p>

## BYTE SEQUENCE FOR DWORD

Parameters	Description
<b>Byte sequence for DWORD</b>	Defines the sequence of lower-value and higher-value words for double word objects (DINT/UDINT). You can choose between Motorola (Big-Endian) and Intel (Little-Endian).
<b>Motorola Format (Big-Endian)</b>	Active: DWORD ordering in accordance with Motorola format.
<b>Intel Format (Little-Endian)</b>	Active: DWORD ordering in accordance with Intel format.

## BYTE SEQUENCE FLOAT

Parameters	Description
<b>Byte sequence FLOAT</b>	Defines the sequence of lower-value and higher-value words for FLOAT objects (REAL). You can choose between Modbus Standard (Big-Endian) and HB-Controller (Little-Endian).
<b>Modbus Standard (Big-Endian)</b>	Active: Float ordering in accordance with Modbus standard.

<b>HB Controller Float (Little-Endian)</b>	Active: Float ordering in accordance with HB controller.
--	--

#### BYTE SEQUENCE FOR STRING

Parameters	Description
<b>Byte sequence for STRING</b>	<p>Defines display of the byte sequence.</p> <p><b>Note:</b> If there is relevant information in the documentation of a PLC the following is usually applicable:</p> <p>MSB-first =</p> <ul style="list-style-type: none"> <li>▶ Motorola = Big-Endian = Modbus.</li> <li>▶ Intel = Little-Endian = PC.</li> </ul> <p>This can be handled differently in some documentation however.</p>
<b>Modbus Standard (Big-Endian)</b>	Display in accordance with Modbus standard with switched characters.
<b>PC-Format (Little-Endian)</b>	Display in accordance with Modbus standard with switched characters.

#### ERROR HANDLING

Parameters	Description
<b>Connection timeout</b>	Time in milliseconds to wait for a response from the Slave. A communication error will be displayed if there is no response within this time.
<b>Retries on error</b>	<p>Number of send repetitions when there is no answer from the slave after the set communication timeout.</p> <ul style="list-style-type: none"> <li>▶ 1: a connection attempt, no repetitions</li> <li>▶ 0: constant repetition</li> <li>▶ Default: 6</li> </ul>
<b>Delay after connection termination</b>	Time in milliseconds to wait after a communication error before trying to reestablish the connection.
<b>Target folder</b>	Folder for file transfer.

#### CLOSE DIALOG

##### Parameters

##### OK

##### Description

Applies all changes in all tabs and closes the dialog.

## Parameters

## Description

### Cancel

Discards all changes in all tabs and closes the dialog.

### Help

Opens online help.




### Information

*Sequences of Events: If a variable is created for a connection in the event area, SOE is used. Otherwise SOE is not used.*

## 6.2.3 Connections

You can configure the connections to the PLCs via Open Modbus TCP/IP in the tab **Connections**: To do this:

- ▶ click on the property **Configuration** in the group **General**
- ▶ now the dialog for the configuration of the driver opens.
- ▶ select the tab **Connections**



The screenshot shows the 'Configuration' dialog box with the 'Connections' tab selected. The dialog has three tabs: 'General', 'Settings', and 'Connections'. The 'Connections' tab contains a table with two columns: 'Connection name' and 'Net address'. The table has one row with 'Default name' and '0'. Below the table are buttons for 'New', 'Edit', and 'Delete'. To the right of the table is the 'Edit connection' section, which includes fields for 'Connection name' (with 'Default name' as a hint), 'Net address' (with '0' as a hint), 'Primary IP address' (with '192 . 168 . 0 . 1' as a hint), 'Port number' (with '502' as a hint), 'Secondary IP address' (with a hint '- . - . -'), 'Modbus Unit ID' (with '1' as a hint), and 'IED type' (with a dropdown menu showing 'None (disabled)'). At the bottom of the 'Edit connection' section are 'Save' and 'Cancel' buttons. On the far right of the dialog are 'OK', 'Cancel', and 'Help' buttons.

Parameters	Description
<b>Connection list</b>	Displays the connection names with the corresponding hardware addresses. To display the connection parameters of a name, click on the according connection name.
<b>Net address</b>	<p>The net address identifies the connection. Therefore, every connection must have a unique net address. Variables are assigned to a connection via the net address.</p> <p>At the creation of a new variable the net address with the highest existing address + 1 is initialized.</p>
<b>Connection name</b>	<p>Freely definable name for the easier distinction of connections.</p> <p><b>Attention:</b> The connection name must not contain any of the following characters: { }   &amp; ~ ! [ ] ( ) " ' ; =</p>
<b>Primary IP address</b>	Primary IP address of the PLC with which you are communicating.
<b>Port number</b>	<p>The port number of the PLC.</p> <p>Default for Open Modbus TCP/IP: 502</p>
<b>Secondary IP address</b>	Secondary IP address of the PLC with which you are communicating. If a connection to the first address cannot be achieved, a connection to the secondary IP address is tried.
<b>Modbus Unit ID</b>	Modbus unit ID (slave address) - the address of the recipient
<b>IED type</b>	<p>Selection of the IED type (IED = Intelligent Electronic Device). A left-click opens the drop-down list for selection:</p> <ul style="list-style-type: none"> <li>▶ AREVA MiCOM P126/127</li> <li>▶ COSTRONIC DFB</li> <li>▶ GE Multilin F650</li> <li>▶ GE Multilin UR series</li> <li>▶ ICE NPx800</li> <li>▶ Schneider SEPAM</li> <li>▶ None (disabled) - Standard Modbus TCP/IP</li> </ul> <p><b>Default:</b> None (disabled)</p>
<b>New</b>	Creates a new connection with default settings.
<b>Clear</b>	Deletes the connection selected in the connection list.
<b>Edit</b>	Opens the selected connection for editing.
<b>Save</b>	Saves a new or edited connection.
<b>Cancel</b>	Cancels the editing of connection settings without saving changes.

## ENHANCEMENT WHEN SELECTING COSTRONIC DFB

Parameters	Description
<b>Base register Mailbox</b>	Address of <code>ControleVie</code> .
<b>Base register Events</b>	Base address of <code>tableEvenments</code> .
<b>Number of registers</b>	Length of the array which is connected to <code>tableEvenments</code> (number of the Event bit/16).

### CREATE NEW CONNECTION

1. click on the button **New**
2. enter the connection parameters **Net address**, **Connection name** and **Modbus Unit ID**
3. Choose the **IED type** if necessary
4. Click on **Save**

Note: If a established connection is selected at the creation, its configuration is copied.

### DISPLAY CONNECTION PARAMETERS OF A CONNECTION

1. select the desired connection in the connection list with the mouse pointer.
2. the parameters will be displayed

### EDIT CONNECTION

1. select the connection in the connection list
2. click on the button **Edit**
3. change the connection parameters
4. finish with **Save**

### DELETE CONNECTION

1. select the connection in the connection list
2. click on the button **Delete**
3. the connection will be removed from the list

## 7. Creating variables

This is how you can create variables in the zenon Editor:

## 7.1 Creating variables in the Editor


Variables can be created:

- ▶ as simple variables
- ▶ in arrays (main.chm::/15262.htm)
- ▶ as structure variables (main.chm::/15278.htm)

### VARIABLE DIALOG


To create a new variable, regardless of which type:

1. Select the **New variable** command in the **Variables** node in the context menu



2. The dialog for configuring variables is opened
3. configure the variable

4. The settings that are possible depends on the type of variables



The screenshot shows the 'Create variable' dialog box with the following settings:

- Settings**
  - Name: S\_Variable
  - Driver: SIMUL32 - SIMUL\_WIZ
  - Driver object type: PLC marker
  - Datatype: REAL
- Array settings**
  - ☐ Start index is 0
  - ☒ Start index is 1
  - Dim 1: 0
  - Dim 2: 0
  - Dim 3: 0
- Addressing options**
  - ☒ Automatic addressing
  - ☐ Addressing according to data type offset and start offset
  - ☐ Manual addressing
  - ☒ Each datatype starts with new offset
- Automatic addressing**
  - ☒ Activate all elements
  - ☐ Activate element manually

Buttons at the bottom: Back, Finish, Cancel, Help.

Property	Description
<b>Name</b>	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.  Maximum length: 128 character  <b>Attention:</b> The characters <b>#</b> and <b>@</b> are not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the <b>Finish</b> button remains inactive. <b>Note:</b> For some drivers, the addressing is possible over the property <b>Symbolic address</b> , as well.
<b>Drivers</b>	Select the desired driver from the drop-down list.  <b>Note:</b> If no driver has been opened in the project, the driver for internal variables ( <b>Intern.exe (Main.chm::/Intern.chm::/Intern.htm)</b> ) is automatically loaded.
<b>Driver object type</b> (cti.chm::/28685.htm)	Select the appropriate driver object type from the drop-down list.
<b>Data type</b>	Select the desired data type. Click on the ... button to open the selection dialog.
<b>Array settings</b>	Expanded settings for array variables. You can find details in the Arrays chapter.
<b>Addressing options</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.
<b>Automatic element activation</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.

## SYMBOLIC ADDRESS

The **Symbolic address** property can be used for addressing as an alternative to the **Name** or **Identification** of the variables. Selection is made in the driver dialog; configuration is carried out in the variable property. When importing variables of supported drivers, the property is entered automatically.

Maximum length: 1024 characters.

## INHERITANCE FROM DATA TYPE

**Measuring range**, **Signal range** and **Set value** are always:

- ▶ derived from the datatype
- ▶ Automatically adapted if the data type is changed

**Note for signal range:** If a change is made to a data type that does not support the set **signal range**, the **signal range** is amended automatically. For example, for a change from **INT** to **SINT**, the **signal range** is changed to 127. The amendment is also carried out if the **signal range** was not inherited from the data type. In this case, the **measuring range** must be adapted manually.



## 7.2 Addressing

You define the addressing of the variables in the property window:

Group/Property	Description
<b>General</b>	
<b>Name</b>	Freely definable name. <b>Attention:</b> For every zenon project the name must be unambiguous.
<b>Identification</b>	Any text can be entered here, e.g. for resource labels, comments ...
<b>Addressing</b>	
<b>Net address</b>	This address refers to the bus address in the connection configuration of the driver. Specifies, on which PLC the variable resides.
<b>Data block</b>	not used for this driver
<b>Offset</b>	<p>The meaning is dependent on the setting of the driver object types.</p> <ul style="list-style-type: none"> <li>▶ For variables of the driver object type <b>Register</b> or <b>SOE - Register event</b>: Reference number of the register [0 to 65535]</li> <li>▶ For variables of the driver object type <b>SOE - Numbered event</b>: Identifies the event. Value range depends on control unit, for example: <ul style="list-style-type: none"> <li>- AREVA MiCOM P125/P126/P127: 1 to 127 o. 162</li> <li>- Costronic DFB: 0 to (number of registers)*bit-1 Example with 63 registers: <b>63*16-1=1007</b>; range <b>0</b> to <b>1007</b></li> <li>- GE Multilin F650: 0 to 191</li> <li>- GE Multilin UR: 0 to number of FlexOperandStates</li> <li>- ICE NPx800: to 8000h</li> <li>- Schneider SEPAM: 1000h to 105Fh</li> </ul> </li> </ul>
<b>Alignment</b>	Alignment for variables with byte length 1. You can choose between low byte and high byte.
<b>Bit number</b>	<p>Number of the bit within the configured offset.</p> <p>Possible entries: 0 ... 15</p>
<b>String length</b>	<p>Only available for String variables:</p> <p>Maximum number of characters that the variable can take.</p>
<b>Driver connection/Driver Object Type</b>	Allows you to change the driver object type which was selected during the creation of the variable.
<b>Driver connection/Data Type</b>	<p>Allows you to change the data type which was selected during the creation of the variable.</p> <p><b>Attention:</b> If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.</p>
<b>Driver connection/Priority</b>	<p>Setting the priority class. The variable of the priority class is thus assigned as it was configured in the driver dialog in the <b>General</b> tab. The priority classes are only used if the <b>global update time</b> is deactivated.</p> <p>If the <b>global update time</b> option is activated and the priority classes are used, there is an error entry in the log file of the system. The driver uses the highest</p>

	possible priority.
--	--------------------

## 7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

### 7.3.1 Driver objects

The following object types are available in this driver:

Driver-object type	Channel type	Read: Modbus function (hex/dec code)	Write: Modbus function (hex/dec code)	Supported data types	Comment
Register	8	0x03 / 3	0x10 / 16	BOOL, DINT, UDINT, INT, UINT, LINT, ULINT, REAL, LREAL, SINT, USINT, STRING	<p>Class 0 - multiple registers.</p> <p>Linear addressing:</p> <ul style="list-style-type: none"> <li>▶ Bit: one-step via <b>offset</b> and <b>bit number</b></li> <li>▶ Byte (8 bits): one-step via <b>Offset</b> and <b>Orientation</b></li> <li>▶ Word (16 bits) Double word (32 bits) Float (32 bits) String(n*Byte): one-step via <b>Offset</b></li> </ul>
File record	68	0x14	0x15	String	<p>Addressing:</p> <p>The string is addressed using the net address (connection number), the data block (file record number) and the offset (number of the record in the file record).</p> <p><b>Note:</b> Please note the information in the file record (on page 32) chapter.</p>
Coil	65	0x01 / 1	0x05 / 5	BOOL	<p>Class 1 - coils.</p> <p>Linear addressing one-step via <b>offset</b>.</p>
File transfer	12	X	X	STRING	PLC specific.
Input discrete	66	0x02/2	N/A	BOOL	<p>Class 1 - input discretes.</p> <p>Linear addressing one-step via <b>offset</b>.</p>

Driver-object type	Channel type	Read: Modbus function (hex/dec code)	Write: Modbus function (hex/dec code)	Supported data types	Comment
Input register	64	0x04 / 4	N/A	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, LREAL, STRING	Class 1 - input registers. Linear addressing as with registers.
SOE - Numbered event	10	X	N/A	BOOL, STRING	PLC specific. Sequence of Events (read event buffer): Addressing of events takes place according to event number.
SOE - Register event	11	X	N/A	BOOL, USINT, UINT	PLC specific. Sequence of Events (read event buffer): Addressing according to the address of the corresponding Modbus register allocated to the event.  Not suitable for COSTRONIC.
Status	67	X	N/A	UINT, INT	Status variables. For more details see chapter Driver-specific functions (on page 54).
Treibervariable	35	X	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, LREAL, STRING	Variables for the statistical analysis of communication.  <b>Note:</b> Transfers between Runtime and driver not to the PLC.  Find out more in the chapter about the Driver variables (on page 48)



### Attention

Driver- object type	Chann el type	Read: Modbus function (hex/dec code)	Write: Modbus function (hex/dec code)	Supported data types	Comment
------------------------	---------------------	--	---	-------------------------	---------

Please note:

If values are written to a string variable in zenon, with a configured **String length** of approximately 130 characters, only one character length of 129 characters is transferred to the PLC. The last character is replaced with a zero terminator.

## Function codes

### MODBUS FUNCTION CODES

Function code hex/dec	Modbus identifier	Comment
0x01 / 1	Read coils	This function code is used to read from 1 to 2000 contiguous status of coils (bits) in a remote device
0x02/2	Read discrete inputs	This function code is used to read from 1 to 2000 contiguous status of discrete inputs (bits) in a remote device
0x03 / 3	Read multiple registers	This function code is used to read a block of contiguous holding registers (1 to 125 words) in a remote device.
0x04 / 4	Read input registers	This function code is used to read a block of contiguous input registers (1 to 125 words) in a remote device.
0x05 / 5	Write coil	This function code is used to write a single output (one bit) to either ON or OFF in a remote device.
0x06 / 6	Write single register	This function code is used to write a single (one word) holding register in a remote device.
0x10 / 16	Write multiple registers	This function code is used to write a block of contiguous holding registers (1 to approx. 120 words) in a remote device.
0x11 / 17	Report Slave ID	This function code is used to read the description of the type, the current status, and other information specific to a remote device.
0x14/20	Read File Record	<p>This function code is used to perform a file record read. All Request Data Lengths are provided in terms of number of bytes and all Record Lengths are provided in terms of registers.</p> <p><b>Note:</b> This Functioncode is supported by the MODBUS_ENERGY driver only.</p>

0x15/21	Write File Record	<p>This function code is used to perform a file record write. All Request Data Lengths are provided in terms of number of bytes and all Record Lengths are provided in terms of the number of 16-bit words.</p> <p><b>Note:</b> This Functioncode is supported by the MODBUS_ENERGY driver only.</p>
0x2B/43	Read Device Identification	<p>This function code allows reading the identification and additional information relative to the physical and functional description of a remote device.</p>

## File Record

### READ AND WRITE ACCESS

The content of a „File Record" is provided by the driver as a hexadecimal string when writing or received as such for writing:

- ▶ If the „File Record" contains the string "12345", the driver will forward this to the application as a hexadecimal string "3132333435".
- ▶ If the „File Record" contains the string "abcde", the application must pass the string "6162636465" on to the driver.

### DRIVER OBJECT TYPE

The string is addressed using the net address (connection number), the data block (file record number) and the offset (number of the record in the file record).

### READ VARIABLE

File record variables are read as polling.

It is always the defined length of the string that is read by the PLC:

- ▶ With a given string length of 10, 5 bytes are read from the PLC, coded as a hexadecimal string (thus resulting in the length of 10) and forwarded to the application.
- ▶ If the string length is an uneven number, it is rounded up for the reading of data by the PLC, but the lower-value nibble of the last byte is discarded.



## WRITING VARIABLES

When writing, the length of the string passed on to the driver determines the amount of data that is actually written.

It must be noted that the smallest data unit that can be written is one word – 2 bytes or 16 bits. The string length should therefore always be a multiple of 4. If this is not the case, excess data bytes in the string are ignored!

It must also be noted that the string must be coded in hexadecimal. Only the figures 0 to 9 (values 0 to 9) and the letters A to F (values 10 to 15) are permitted. The characters can be written with small letters or capital letters. If a character that cannot be used is detected during conversion, there is no write access to the PLC.

## CONSTANT

Constant	Value	Description
<b>MB_MIN_FREQ_FILENO</b>	1	Lowest valid file number
<b>MB_MAX_FREQ_FILENO</b>	65535	Highest valid file number
<b>MB_MIN_FREQ_RECNO</b>	0	Lowest valid record number
<b>MB_MAX_FREQ_RECNO</b>	65535	Highest valid record number
<b>MB_FREQ_MINSTRLEN</b>	4	Minimum string length – this value must not be gone below if data is to be written.
<b>MB_FREQ_MAXSTRLEN</b>	476	Maximum string length

## LOG entries

The following LOG entries are created for file records:

Parameters	Description
Write File record failed [NETx1: 's']. TCP connection failure (error x2) .	<p>Write access failed due to a connection error. Possible causes: general write error; not enough data was forwarded to the PLC; the transaction could not be completed within the permitted timeout.</p> <p>The following replacements were undertaken when creating the error message:</p> <ul style="list-style-type: none"> <li>▶ x1 with the net address</li> <li>▶ s with the string that is to be transferred</li> <li>▶ x2 with the socket error code</li> </ul>

**Parameters**

Write File record failed  
[NETx1: 's']. Invalid  
values (e.g. FileNo.[x2],  
RecNo. [x3], ...).

**Description**

Protocol data  
that has been  
set is not valid  
(e.g. file  
number/data  
block, record  
number/offset,  
...).

The following  
replacements  
were  
undertaken  
when creating  
the error  
message:

- ▶ x1  
with the  
net  
address
- ▶ x2  
with the  
file  
number  
(or data  
block  
number)
- ▶ x3  
with the  
record  
number  
(or offset)
- ▶ s  
with the  
string that  
is to be  
transferred

**Parameters**

Write File record failed  
[NETx1: 's']. MODBUS  
exception x2

**Description**

The PLC  
responds to a  
command with  
an exception.

The following  
replacements  
were  
undertaken  
when creating  
the error  
message:

- ▶ x1  
with the  
net  
address
- ▶ s  
with the  
string that  
is to be  
transferred
- ▶ x2  
the  
exception  
code of  
the PLC

### Parameters

Reading 's' failed [NETx1:  
RefNum=x2, Count=x3].  
Invalid values.

### Description

The protocol data that has been set is not valid, e.g. file number/data block, record number/offset, ...

The following replacements were undertaken when creating the error message:

- ▶ x1  
with the net address
- ▶ x2  
with the marker number
- ▶ x3  
with the number
- ▶ s  
Name of the data object



### Information

All LOG messages are written with the general module assignment and the ERROR level.

## 7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

PLC	zenon	Data type
Register / Event	BOOL	8
Register	USINT	9
Register	SINT	10
Register	UINT	2
Register	INT	1
Register	UDINT	4
Register	DINT	3
Register	ULINT	27
Register	LINT	26
Register	REAL	5
Register	LREAL	6
Register	STRING	12
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19

**Data type:** The property **Data type** is the internal numerical name of the data type. It is also used for the extended DBF import/export of the variables.

## 7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



### Information

*You can find details on the import and export of variables in the Import-Export (main.chm::/13028.htm) manual in the Variables (main.chm::/13045.htm) section.*

### 7.4.1 XML import

For the import/export of variables the following is true:

- ▶ The import/export must not be started from the global project.
- ▶ The start takes place via:
  - Context menu of variables or data typ in the project tree
  - or context menu of a variable or a data type
  - or symbol in the symbol bar variables



#### Attention

*When importing/overwriting an existing data type, all variables based on the existing data type are changed.*

*Example:*

*There is a data type XYZ derived from the type `INT` with variables based on this data type. The XML file to be imported also contains a data type with the name XYZ but derived from type `STRING`. If this data type is imported, the existing data type is overwritten and the type of all variables based on it is adjusted. I.e. the variables are now no longer `INT` variables, but `STRING` variables.*

### 7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.



#### Information

*Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.*

#### IMPORT DBF FILE

To start the import:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Import dBase** command
3. follow the import assistant

The format of the file is described in the chapter File structure.



### Information

*Note:*

- ▶ Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

## EXPORT DBF FILE

To start the export:

1. right-click on the variable list
2. in the drop-down list of **Extended export/import...** select the **Export dBase...** command
3. follow the export assistant



### Attention

DBF files:

- ▶ must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ must not have dots (.) in the path name.  
e.g. the path C:\users\John.Smith\test.dbf is invalid.  
Valid: C:\users\JohnSmith\test.dbf
- ▶ must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.



### Information

*dBase does not support structures or arrays (complex variables) at export.*

File structure of the dBase export file

The dBaseIV file must have the following structure and contents for variable import and export:





### Attention

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- ▶ conform with their name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- ▶ Be stored close to the root directory (Root)

## STRUCTURE

Identification	Type	Field size	Comment
<b>KANALNAME</b>	Char	128	Variable name.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
<b>KANAL_R</b>	C	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (field/column must be entered manually).  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
<b>KANAL_D</b>	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).

<b>TAGNR</b>	C	128	<p>Identification.</p> <p>The length can be limited using the MAX_LAENGE entry in <b>project.ini</b>.</p>
<b>EINHEIT</b>	C	11	Technical unit
<b>DATENART</b>	C	3	<p>Data type (e.g. bit, byte, word, ...)</p> <p>corresponds to the data type.</p>
<b>KANALTYP</b>	C	3	<p>Memory area in the PLC (e.g. marker area, data area, ...)</p> <p>corresponds to the driver object type.</p>
<b>HWKANAL</b>	Num	3	Bus address
<b>BAUSTEIN</b>	N	3	<p>Datablock address (only for variables from the data area of the PLC)</p>
<b>ADRESSE</b>	N	5	Offset
<b>BITADR</b>	N	2	<p>For bit variables: bit address</p> <p>For byte variables: 0=lower, 8=higher byte</p> <p>For string variables: Length of string (max. 63 characters)</p>

<b>ARRAYSIZE</b>	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipegroup Manager
<b>LES_SCHR</b>	L	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
<b>MIT_ZEIT</b>	L	1	time stamp in zenon (only if supported by the driver)
<b>OBJEKT</b>	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJE KTTYP and DATENTYP
<b>SIGMIN</b>	Float	16	Non-linearized signal - minimum (signal resolution)
<b>SIGMAX</b>	F	16	Non-linearized signal - maximum (signal resolution)
<b>ANZMIN</b>	F	16	Technical value - minimum (measuring range)

<b>ANZMAX</b>	F	16	Technical value - maximum (measuring range)
<b>ANZKOMMA</b>	N	1	Number of decimal places for the display of the values (measuring range)
<b>UPDATERATE</b>	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
<b>MENTIEFE</b>	N	7	Only for compatibility reasons
<b>HDRATE</b>	F	19	HD update rate for historical values (in sec, one decimal possible)
<b>HDTIEFE</b>	N	7	HD entry depth for historical values (number)
<b>NACHSORT</b>	L	1	HD data as postsorted values
<b>DRRATE</b>	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)

<b>HYST_PLUS</b>	F	16	Positive hysteresis, from measuring range
<b>HYST_MINUS</b>	F	16	Negative hysteresis, from measuring range
<b>PRIOR</b>	N	16	Priority of the variable
<b>REAMATRIZE</b>	C	32	Allocated reaction matrix
<b>ERSATZWERT</b>	F	16	Substitute value, from measuring range
<b>SOLLMIN</b>	F	16	Minimum for set value actions, from measuring range
<b>SOLLMAX</b>	F	16	Maximum for set value actions, from measuring range
<b>VOMSTANDBY</b>	L	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks

<b>RESOURCE</b>	C	128	Resources label. Free string for export and display in lists.  The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
<b>ADJWVBA</b>	L	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: Non-linear value adaption is not used
<b>ADJZENON</b>	C	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
<b>ADJWVBA</b>	C	128	ed VBA macro for writing the variable value for non-linear value adjustment.
<b>ZWREMA</b>	N	16	Linked counter REMA.
<b>MAXGRAD</b>	N	16	Gradient overflow for counter REMA.



### Attention

*When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.*

## LIMIT VALUE DEFINITION

Limit definition for limit values 1 to 4, or status 1 to 4:

Identification	Type	Field size	Comment
<b>AKTIV1</b>	L	1	Limit value active (per limit value available)
<b>GRENZWERT1</b>	F	20	technical value or ID number of a linked variable for a dynamic limit value (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
<b>SCHWWERT1</b>	F	16	Threshold value for limit value
<b>HYSTERESE1</b>	F	14	Is not used
<b>BLINKEN1</b>	L	1	Set blink attribute
<b>BTB1</b>	L	1	Logging in CEL
<b>ALARM1</b>	L	1	Alarm
<b>DRUCKEN1</b>	L	1	Printer output (for CEL or Alarm)
<b>QUITTTIER1</b>	L	1	Must be acknowledged
<b>LOESCHE1</b>	L	1	Must be deleted
<b>VARIABLE1</b>	L	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
<b>FUNC1</b>	L	1	Functions linking
<b>ASK_FUNC1</b>	L	1	Execution via Alarm Message List
<b>FUNC_NR1</b>	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
<b>A_GRUPPE1</b>	N	10	Alarm/Event Group
<b>A_KLASSE1</b>	N	10	Alarm/Event Class
<b>MIN_MAX1</b>	C	3	Minimum, Maximum
<b>FARBE1</b>	N	10	Color as Windows coding
<b>GRENZTXT1</b>	C	66	Limit value text
<b>A_DELAY1</b>	N	10	Time delay
<b>INVISIBLE1</b>	L	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.

## 7.5 Driver variables

The driver kit implements a number of driver variables. These are divided into:

- ▶ Information
- ▶ Configuration
- ▶ Statistics and
- ▶ Error message

The definitions of the variables implemented in the driver kit are available in the import file **drvvar.dbf** (on the installation medium in the \Predefined\Variables folder) and can be imported from there.

**Note:** Variable names must be unique in zenon. If driver variables are to be imported from **drvvar.dbf** again, the variables that were imported beforehand must be renamed.





### Information

*Not every driver supports all driver variants.*

*For example:*

- ▶ Variables for modem information are only supported by modem-compatible drivers
- ▶ Driver variables for the polling cycle only for pure polling drivers
- ▶ Connection-related information such as ErrorMessage only for drivers that only edit one connection at a time

## INFORMATION

Name from import	Type	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon Service Pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy

LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped  For <code>driver stop</code> , the variable has the value <code>TRUE</code> and an <b>OFF</b> bit. After the driver has started, the variable has the value <code>FALSE</code> and no <b>OFF</b> bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.

## CONFIGURATION

Name from import	Type	Offset	Description
ReconnectInRead	BOOL	27	If <code>TRUE</code> , the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method <code>SrvDrvVarApplyCom</code> being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method <code>SrvDrvVarApplyModem</code> . This closes the current connection and opens a new one according to the settings <b>PhoneNumberSet</b> and <b>ModemHwAdrSet</b> .

PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver
Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baudrate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	USINT	14	Number of bits per character of the serial interface  Value = 0 if the driver cannot establish any serial connection.
StopBit	USINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)

WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UINT	54	Time in seconds (s) to establish a connection.

## STATISTICS

Name from import	Type	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts

MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group <b>Normal</b> in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group <b>Higher</b> in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group <b>High</b> in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group <b>Highest</b> in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

## ERROR MESSAGE

Name from import	Type	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.

RdErrHwAdresse	DINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	USINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

## 8. Driver-specific functions

The driver supports the following functions:

### BLOCKWRITE

Blockwrite allows for the efficient sending of multiple set values (e.g. recipes). Variables that lie next to each other in the PLC memory will be written to with a single write telegram or combined into a few telegrams (for larger areas).

Attention: If blockwrite is activated, the write sequence of the variables does not necessarily have to match their sending sequence.

Blockwrite can be activated with an entry in the project.ini file:

1. select the project in Project Manager
2. Press the keyboard short cut `Ctrl+Alt+E`
3. the SQL folder of zenon opens in the Windows Explorer  
`C:\ProgramData\COPA-DATA\[SQL folder]\[UID]FILES`
4. Go to `\zenon\system\`
  - open the file `project.ini` with a text editor.
  - add the following entry:

[MODBUS\_ENERGY]  
BLOCKWRITE=1

## SEQUENCE OF EVENTS

The driver contains functions for reading out the event buffer of the PLCs mentioned in chapter MODBUS\_ENERGY (on page 5). This functionality can be activated via the driver dialog Settings (on page 15). The type of PLC can only be set globally for the driver.

## READ PROCEDURE

The MODBUS protocol does not give the slave any possibility to report without querying the master. The controller must therefore save spontaneous events and the exact time they occurred and only transfer these once the master has queried this.

Sequence of Events (SOE) is a buffer with events (values and time stamp) that are stored in a special memory section in the PLCs. The address, the size, the format, and the procedure of reading from the buffer is manufacturer-specific as the MODBUS protocol does not have any guidelines for this.

spontaneous communication only supports the driver for events that are read from the buffer. In doing so, only these values receive a time stamp in the controller. These can therefore be allocated as spontaneous events in the control system at all points (such as alarms, in the CEL, archives).

The driver checks the occurrence of new events cyclically with the highest priority used in the driver configuration.

## THE INITIAL STATUS OF THE EVENT VARIABLE

When connecting to the PLC the driver gets the initial status for events from the event buffer (PLC-specific). If an event equals a distinct address in the MODBUS register and it was engineered as `SOE register event`, it is possible for the driver to adjust the possible initial values with the respective register. If however the initial status of the event variable was read out from the register (and not from the event buffer) and the original time stamp of the event is not available in the PLC anymore, this variable receives the local PC time as time stamp and receives the status bit `T_INTERN` (real time internal).

## STATUS OF THE TCP/IP CONNECTION

The status of the TCP/IP connection to the controller can be read with the help of a `Status` object type variable. The variables have a data type, **Offset** 0 and corresponding **Net address**. The variables relate to both IP addresses if the secondary connection was defined in the driver configuration: Type: INT or UINT:

Bit	Meaning
Bit 1	Displays whether the primary connection is active (is used for communication).
Bit 2	Establishing a connection to the primary IP-address.
Bit 3	Failed to establish a connection to the primary IP address.
Bit 5	Displays whether the secondary connection is active (is used for communication).
Bit 6	Establishing a connection to the alternative IP address.
Bit 7	Failed to establish a connection to the alternative IP address.

## DRIVER-SPECIFIC COMMAND "SWITCHCONNECTION"

The active IP address for a **Net address** is closed without setting an INVALID bit with the driver-specific command (on page 64) `SwitchConnection <HwNb>`. A connection is then established for the selected connection. If the connection is not successfully established, the INVALID bit is set and a switch back to the active connection is made.

Example: `SwitchConnection 1`

## AREVA MICOM P125/P126/P127

After the communication has started the driver fetches all events which are available in the PLC from the buffer (Register Page 35H). After that the retrieval (with acknowledgment) of the saved event recording of the Page 36H takes place.

For register events which are not available in the buffer the initial value - if available on Page 0H - is read out from the respective MODBUS register and stamped with the local PC time.

`Numbered Events` which are not available in the buffer receive initial value 0 and are stamped with the local PC time.

## GE MULTILIN F650

After the communication has started the driver fetches the initial status of the events from the register (address 0xF000). After that the retrievals from the ring buffer (0xFD00) take place.

The events reported by the PLC arrive with the time stamp of the PLC and also receive the status bit `T_EXTERN` (real time external).



## SCHNEIDER SEPAM

Events are created in area "SOE Numbered Events". As offset the coil bit address of the setting is stated which should be read spontaneously. Supported are addresses 1000h - 105Fh. The read out of the initial state after a new connection is supported.

## THE DRIVER OBJECT TYPE OF THE EVENTS

For the events two **Driver object types** are possible: `SOE - Numbered event` and `SOE - Register event` whereas not both have a function for each PLC.

### AREVA MICOM P125/P126/P127

For Areva MiCOM both object types - `Numbered event` and `Register event` - are supported.

The `SOE - Numbered event` matches an event which is only generated if a condition occurs (and not if a condition disappears). The identification of an event is defined with the help of the **Offset** setting in the variable addressing (e.g. offset 5 for event 05). If there is an event in the PLC, the associated `BOOL` variable will be set to 1 and then immediately set to 0 by the driver. The coming value can be evaluated by creating an alarm/CEL/archive or a function for a limit value violation.

The `Register events` match the rest of the events. The `Register events` are assigned to one or several bits in a special register of the Page 0 in the AREVA PLC (e.g. offset 20h, bit 0). This means that the PLC makes sure that the event reflects the change of a status in a register. In the variable addressing the identification of the event takes place via **Offset** and **Bit** and describes the associated data points in a Page 0 register. You can use the datatypes `BOOL`, `USINT` and `UINT`.

Consult the documentation of the AREVA PLC to find out about the event types and which events are supported by the AREVA PLC.

### GE MULTILIN F650

For GE Multilin F650 only object type `SOE - Numbered event` is supported.

Via the driver object type `SOE - Numbered event`, you can assign a `BOOL` variable to every event. The identification of the event is defined via the **Offset** setting of the variables (0 - 191).

The driver object type `SOE - Register event` has no function for the GE Multilin F650 PLC.

## 8.1 ICE NPx800

The reading of the events is only supported for the simplified event mode of the NPx800: only On events or Wiper events but no Status events (on/off).

Event variables are created under the driver object type `SOE-Numbered events` as `BOOL` variables. The event parameters can be read by creating a string variable with the same driver object type and offset.

**Attention:** The string variable only has a valid value when the event has just been triggered. Otherwise the value of the string variable is an empty string. It behaves in the same way as a `BOOL` variable, i.e. just like a Wiper event. The zenon AML/CEL entry can be triggered either by the `BOOL` variables or by the string variable. The display of the string is only possible via dynamic limit texts (`Variablen.chm::/15311.htm`).

The event number is configured with the help of the offset.

## VALUE OF THE EVENT VARIABLE

The process if an event occurs:

1. The parameters are written in a possibly existing string variable.
2. The possibly existing `BOOL` variable is set to 1.
3. The possibly existing `BOOL` variable is set to 0.
4. The length of the possibly existing string variable with the parameters is set to 0.

## PARAMETER STRING

In string variables, the parameter string consists of integer values that are separated by semicolons (;). These integer values correspond to the following data of the event:

- ▶ 1: Event data at word offset 2
- ▶ 2: Event data at word offset 7 (parameter 0)
- ▶ 3: Event data at word offset 8 (parameter 1)
- ▶ 4: Event data at word offset 9 (parameter 2)
- ▶ 5: Event data at word offset 10 (parameter 3)
- ▶ 6: Event data at word offset 11 (parameter 4)
- ▶ 7: Event data at word offset 12 (parameter 5)
- ▶ 8: Event data at word offset 13 (parameter 6)
- ▶ 9: Event data at word offset 14

## PROCEDURE OF EVENTS

Procedure for an event:

- ▶ When Runtime is started or when the driver connection is restored, all events are initialized with 0.

- ▶ If an event is received, then:
  - A string variable is filled with the **event parameters** (if these have been created)
  - The status of the **A/D** bits of the **BOOL** variable are allocated
 

If, once Runtime has started or if the driver connection is reinstated, a 0 event is received, this change of value cannot be perceived.  
If a 1 event is sent twice consecutively (without a 0 event), the second event cannot be perceived.
  - The string variable reset (empty string)

The string variable can also be evaluated with the event parameters. In the first parameter, the value of the **A/D** bit is present. All events in the RT can be perceived using the string variable.

## CHECKING THE EV FLAG

The driver checks the EV flag for the IECLEC alarm stack. If the value `false` is returned, the read data is ignored and no other event are read.

## FILE TRANSFER DISTURBANCE RECORDS

A string variable can be created for the file transfer of **disturbance records**. It is possible to read and delete data with these.

A file is identified in the process by means of the number of the **disturbance record descriptor**.

Possible values: 1, 2, 3, 4

The records are in **COMTRADE**-format and have a serial number (0 - 255). The description of the records is stored in the descriptors (1 - 4). These contain the date, time, serial number, source and position. A maximum of 4 disturbance records can be created.

the target folder is defined in the driver configuration in the Settings (on page 15) tab.

## UPLOAD AND DELETE

- ▶ Upload file: The **GET x** entry in the string variables uploads the corresponding file.
- ▶ Delete file: The **DEL x** entry in the string variables deletes the corresponding file.

**x** means **Disturbance record descriptor** number (1 - 4)

## FILE NAME

The file is named according to the following schematics

**A\_yyyy-mm-dd\_hh-mm-ss-MMM\_DescriptorZ\_(x-y)**

Meaning:

- ▶ **A:** Hardware address of the device
- ▶ **yyyy:** Year of creation.
- ▶ **mm:** Month of creation.
- ▶ **hh:** Hour of creation.
- ▶ **mm:** Minute of creation.
- ▶ **ss:** Second of creation.
- ▶ **MMM:** Millisecond of creation.
- ▶ **Z:** serial number of the record
- ▶ **x:** Source
- ▶ **y:** Position

For example:


**1\_2009-09-07\_14-01-36-690\_Disturbance\_109\_(19-420).HDR**

**1\_2009-09-07\_14-01-36-690\_Disturbance\_109\_(19-420).CFG**

**1\_2009-09-07\_14-01-36-690\_Disturbance\_109\_(19-420).DAT**

## 8.2 GE Multilin UR series

The IEC type is selected in the Connections (on page 19) tab of the driver configuration:



Click on the drop-down list in the **IED type** section to open the selection of the IEC types. Select **GE Multilin UR series** there.

### SOE SUPPORT

Via the SOE functionality of the driver events can be read from the device. For this file **EVT.TXT** is analyzed at the device. Events must be created of driver object type `SOE - Numbered event` and of data type `BOOL`. The addressing takes places via the offset setting.

A list of event numbers and their meaning can be called up via the web server of the UR series.

**`http://IP_Address_of_UR_unit/FlexOperandStates.htm`** (e.g.:

**`http://192.168.37.67/FlexOperandStates.htm`** ).

The `SOE - Numbered event` matches an event which is only generated if a condition occurs (and not if a condition disappears). The identification of an event is defined with the help of the **Offset** setting in the variable addressing (e.g. offset 5 for event cause 5). If there is an event in the PLC, the associated `BOOL` variable will be set to 1 and then immediately set to 0 by the driver. The coming value can be evaluated by creating an alarm/CEL/archive or a function for a limit value breach.

## FILE TRANSFER

Via a command variable of the driver object type **File transfer** (see file transfer description for ICE devices) the file is transferred to the local computer. The command consists of: **GET** followed by a blank space and the file name: **GET EVT.TXT**

The file is copied to the file transfer folder (as defined on tab Settings (on page 15) of the configuration).

Format of the file name: Net address+underscore+file name.

The net address is taken over from the driver/variable and is only used for saving so that the data are not overwritten for several controls.


Example: **0\_EVT.TXT**

## 8.3 COSTRONIC DFB

### ALIVE TIMEOUT: DETECTION OF A PLC STOP

It is possible to detect if the PLC has stopped for COSTRONIC DFB. To do this, the counter for the event communication in the Costronics communication mailbox is monitored. If this counter does not change during a configurable waiting period, a status variable for the connection is set to 1. the next time the counter is changed, it is set to 0 again.

Configuration is carried out using the **Alive timeout** option in the driver configuration.



The screenshot shows the 'Configuration' dialog box with the 'Connections' tab selected. On the left, a table lists connections:

Connection name	Net address
COSTRONIC DFB	0

Below the table are buttons for 'New', 'Edit', and 'Delete'. On the right, the 'Edit connection' panel is active for 'COSTRONIC DFB'. It contains the following fields:

- Connection name: COSTRONIC DFB
- Net address: 0
- Primary IP address: 127 . 0 . 0 . 1
- Port number: 502
- Secondary IP address: 192 . 168 . 241 . 27
- Modbus Unit ID: 1
- IED type: COSTRONIC DFB (dropdown menu)
- Mailbox base register: 100
- Event base register: 200
- Event register count: 60
- Alive timeout: 5000

Buttons for 'Save' and 'Cancel' are at the bottom of the 'Edit connection' panel. On the far right of the dialog are 'OK', 'Cancel', and 'Help' buttons.

The status variable must be of the driver object type and have the **Offset** 1. The following values are available:

Value	Meaning
0	Event mailbox has not been read yet.
1	Alive Counter is increased.
2	Alive Counter waiting time has expired.

Attention: The **Alive** counter is part of the event mailbox. If the event mailbox is not read off (no variables are active), the status is not updated. That means: In order for the **Alive** status to be monitored, at least one event variable must be active.

## DRIVER-SPECIFIC COMMAND FOR UPDATE EVENT STATUS

With a driver-specific command (on page 64), it is possible to force the reading in of the current values of event-controlled values.

- ▶ **Command:** `UpdateEventState <HwNb>`  
Forces the driver to read all event statuses from the PLC.


**Example:** `UpdateEventState 1`

## 9. Driver commands

This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

Driver commands are used to influence drivers using zenon; start and stop for example. The engineering is implemented with the help of function **Driver commands**. To do this:

- ▶ create a new function
- ▶ select Variables -> Driver commands
- ▶ The dialog for configuration is opened





Parameter	Description
<b>Drivers</b>	Drop-down list with all drivers which are loaded in the project.
<b>Current status</b>	Fixed entry which has no function in the current version.
Driver command	Drop-down list for the selection of the command.
▶ Start driver (online mode)	Driver is reinitialized and started.
▶ Stop driver (offline mode)	Driver is stopped. No new data is accepted. <b>Note:</b> If the driver is in offline mode, all variables that were created for this driver receive the status <code>switched off (OFF; Bit 20)</code> .
▶ Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
▶ Driver-specific command	Enter driver-specific commands. Opens input field in order to enter a command.
▶ Driver - activate set setpoint value	Write set value to a driver is allowed.
▶ Driver - deactivate set setpoint value	Write set value to a driver is prohibited.
▶ Establish connecton with modem	Establish connection (for modem drivers) Opens the input fields for the hardware address and for the telephone number.
▶ Disconnect from modem	Terminate connection (for modem drivers)
<b>Show this dialog in the Runtime</b>	The dialog is shown in Runtime so that changes can be made.

## DRIVER COMMANDS IN THE NETWORK

If the computer, on which the **driver command** function is executed, is part of the zenon network, additional actions are carried out. A special network command is sent from the computer to the project server, which then executes the desired action on its driver. In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

## 10. Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

### 10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under Start/All programs/zenon/Tools 7.50 -> Diagviewer.

zenon driver log all errors in the LOG files. The default folder for the LOG files is subfolder **LOG** in directory `ProgramData`, example:

```
%ProgramData%\COPA-DATA\LOG. LOG files are text files with a special structure.
```

**Attention:** With the default settings, a driver only logs error information. With the **Diagnosis Viewer** you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ Follow newly-created entries in real time
- ▶ customize the logging settings
- ▶ change the folder in which the LOG files are saved

Note:

1. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
2. The Diagnosis Viewer does not display all columns of a LOG file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
3. If you only use **Error-Logging**, the problem description is in the column **Error text**. For other diagnosis level the description is in the column **General text**.
4. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** or **Error code** or **Driver error parameter (1 and 2)**. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
5. At the end of your test set back the diagnosis level from **Debug** or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the **Diagnosis Viewer**.

**Attention**

In Windows CE errors are not logged per default due to performance reasons.

You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) manual.

## 10.2 Check list

Problem	Diagnostics	Reason
Values can be read or written by the controller.	The controller can be contacted by 'pinging'?	<ul style="list-style-type: none"> <li>▶ The controller is not connected to the power supply or the network.</li> <li>▶ The PC is not connected to the network.</li> <li>▶ The controller is connected but is in a different subnetwork and the network gateway is not entered in the controller or the subnetmask is not set correctly.</li> <li>▶ Is the firewall activated? Port 502 is used for communication as standard; add it to the exceptions. Enter accordingly for individual port numbers.</li> </ul>
	The controller can be contacted by 'pinging'?	<ul style="list-style-type: none"> <li>▶ The communication parameters are not set correctly?</li> <li>▶ The port must be set according to the configuration of the controller (Modbus Slave).</li> <li>▶ The network address in the addressing of the variable does not correspond to the network address of the connection in the driver. Attention: Network address 0 must not be used. Address 0 is reserved as a broadcast address in Modbus.</li> <li>▶ The driver configuration file was not transferred to the target computer?</li> </ul>
	The PLC is connected serially	<ul style="list-style-type: none"> <li>▶ The controller is not connected to the power supply or the bus system.</li> <li>▶ The serial cable is not connected to the correct interface (COM1...64), or the interface was set incorrectly.</li> <li>▶ The serial interface is blocked by another application.</li> <li>▶ The network address in the addressing of the variable does not correspond to the Modbus address (device address).</li> <li>▶ The cable is assigned incorrectly or defective.</li> </ul>
Certain values cannot be read or written by the controller.	Has an analysis with the Diagnosis Viewer been carried out to see which errors have occurred?	<ul style="list-style-type: none"> <li>▶ See the following chapter: Error numbers</li> <li>▶ Are the variables correctly addressed?</li> <li>▶ Are the correct object types used in the</li> </ul>

	See Analysis tool (on page 66) chapter.	variable? The object types determine the function code to be used in the Modbus telegram.
Incorrect values are displayed.	<p>Has an analysis with the Diagnosis Viewer been carried out to see which errors have occurred?</p> <p>See Analysis tool (on page 66) chapter.</p>	<ul style="list-style-type: none"> <li>▶ Are the variables correctly addressed?</li> <li>▶ Are the correct data types used?</li> <li>▶ Is the value calculation correct?</li> </ul>