

zenon driver manual INTEGRA

v.8.10



© 2019 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. Technical data is only used for product description and are not guaranteed qualities in the legal sense. Subject to change, technical or otherwise.



Contents

1	Welcome to COPA-DATA help	4
2	INTEGRA	4
3	INTEGRA - data sheet	5
4	Driver history	6
5	Requirements	7
6	Configuration	7
	6.1 Creating a driver	8
	6.2 Settings in the driver dialog	11
	6.2.1 General	12
	6.2.2 Options	16
7	Creating variables	20
	7.1 Creating variables in the Editor	20
	7.2 Addressing	24
	7.3 Driver objects and datatypes	25
	7.3.1 Driver objects	25
	7.3.2 Mapping of the data types	30
	7.4 Creating variables by importing	31
	7.4.1 XML import	
	7.4.2 DBF Import/Export	
	7.5 Communication details (Driver variables)	38
8	Driver-specific functions	44
9	Driver command function	44
10	Error analysis	49
	10.1 Analysis tool	49
	10.2Check list	50



1 Welcome to COPA-DATA help

ZENON VIDEO-TUTORIALS

You can find practical examples for project configuration with zenon in our YouTube channel (https://www.copadata.com/tutorial_menu). The tutorials are grouped according to topics and give an initial insight into working with different zenon modules. All tutorials are available in English.

GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to documentation@copadata.com.

PROJECT SUPPORT

You can receive support for any real project you may have from our Support Team, who you can contact via email at support@copadata.com.

LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email sales@copadata.com.

2 INTEGRA

INTEGRA CONTROL ROOM DRIVER

Driver to communicate with controllers via the INTEGRA standard control room interface. This driver only includes the functionality for use in a control center. Therefore not all functions of the INTEGRA standards are available.

The following are supported:

Standard data



- Structure, Function group definition Default: *DB2*
- Errors, warnings
 Default: DB3
- Errors with time stamp (spontaneous) Default: DB4
- Additional data (spontaneous with time stamp) Default:DB6, DB7
- Control commands Default: *DB8*

Comment: **Data block** is abbreviated to **DB** in this documentation.

3 INTEGRA - data sheet

General:	
Driver file name	INTEGRA.exe
Driver name	integra Treiber
PLC types	Simatic S7 controllers with integra modules
PLC manufacturer	Siemens; Daimler

Driver supports:	
Protocol	TCP/IP - RFC1006
Addressing: Address-based	Address based
Addressing: Name-based	
Spontaneous communication	X
Polling communication	X
Online browsing	
Offline browsing	X
Real-time capable	X



Driver supports:	
Blockwrite	
Modem capable	
RDA numerical	
RDA String	
Hysteresis	
extended API	
Supports status bit WR-SUC	X
alternative IP address	

Requirements:	
Hardware PC	Standard network card
Software PC	
Hardware PLC	
Software PLC	integra control stand data blocks.
Requires v-dll	

Platforms:	
Operating systems	Windows 10; Windows 7; Windows 8; Windows 8.1; Windows Server 2008 R2; Windows Server 2012; Windows Server 2012 R2; Windows Server 2016

4 Driver history

Date	Build number	Change
24.11.14	15919	Driver was created newly
02.11.201	32554	New REAL data type for driver object types Data Point (Data



Date	Build number	Change
6		Block), Data Point (Inst. Data Block) and Data Point (Marker)
11/10/201 6	32613	Extension of alarm handling, Alarm bit driver object removed, restructuring of the configuration dialog: Server 2 uses the same configuration as Server 1

DRIVER VERSIONING

The versioning of the drivers was changed with zenon 7.10. There is a cross-version build number as of this version. This is the number in the 4th position of the file version,

For example: **7.10.0.4228** means: The driver is for version **7.10** service pack **0**, and has the build number **4228**.

Expansions or error rectifications will be incorporated into a build in the future and are then available from the next consecutive build number.

Example

A driver extension was implemented in build **4228**. The driver that you are using is build number **8322**. Because the build number of your driver is higher than the build number of the extension, the extension is included. The version number of the driver (the first three digits of the file version) do not have any significance in relation to this. The drivers are version-agnostic

5 Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

6 Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.

Information

Find out more about further settings for zenon variables in the chapter Variables



(main.chm::/15247.htm) of the online manual.

6.1 Creating a driver

In the **Create driver** dialog, you create a list of the new drivers that you want to create.

	Create driver
	Driver information Description: Data exchange with external programs on file basis. Values are read from a file and displayed resp. archived in zenon. Values can also be written into a file by zenon. Supported PLC types:
Image: Constraint of the second sec	Local Supported communication protocols: unknown The driver is available for the following operating systems: Windows 7, 8, 8. 1, 10, Server 2008R2, Server 2012, Server 2012R2 The driver is available for the following CE processors: - Necessary additional hardware on the PC:
CAN CAN CAN CAN CAN CAN CAN CAN	Necessary additional software on the PC: Necessary additional software on the PLC:
🗄 🖳 Ganther	OK Cancel H

Parameter	Description
Available drivers	List of all available drivers.
	The display is in a tree structure: [+] expands the folder structure and shows the drivers contained therein. [-] reduces the folder structure Default: <i>no selection</i>
Driver name	Unique Identification of the driver. Default: <i>Empty</i> The input field is pre-filled with the pre-defined Identification after selecting a driver from the list of available drivers.



Parameter	Description
Driver information	Further information on the selected driver. Default: <i>Empty</i> The information on the selected driver is shown in this area after selecting a driver.

CLOSE DIALOG

Option	Description
ОК	Accepts all settings and opens the driver configuration dialog of the selected driver.
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

Information

The content of this dialog is saved in the file called Treiber_[Language].xml. You can find this file in the following folder: C:\ProgramData\COPA-DATA\zenon[version number].

CREATE NEW DRIVER

In order to create a new driver:

 Right-click on Driver in the Project Manager and select New driver in the context menu. Optional: Select the New driver button from the toolbar of the detail view of the Variables. The Create driver dialog is opened.



2. The dialog offers a list of all available drivers.

	Create driver
Available drivers	Driver information
Sprecher Automation	
🕀 🧰 3S	
🔬 💼 ABB	
Actisense	
😥 🧰 Allen-Bradley	
🕀 💼 Alstom	
🗄 👘 💼 Areva	
Bachmann	
BACnet	
Beckhoff	
⊕ Bernecker + Rainer ⊕ Biffi-Tyco Flow Control	
Bosch Rexroth	
Brodersen	
Buderus	
⊞ CAN	
COPA-DATA	
E Copalp	
Costronic	
👜 🛅 СП	
🐵 💼 Daimler	
🕀 💼 Database	
🚊 💼 Dateien	
👜 ·· 🧰 DNP3	
🗄 💼 Echelon	
EIB EIB	
🖲 💼 Elau	
B- BA	
Esser	
B Euchner	
ie in Festo ie in Files	
Burger Ganther	
⊕ - GE Automation&Controls	
Gossen Metrawatt	
🗄 📲 Helmholz	
🗄 🚈 Hilscher	
🐵 💼 Hitachi	
Hydrometer	
IBH V	
Driver name	
	· · · · · · · · · · · · · · · · · · ·
	OK Cancel Help
	on taite nep

- Select the desired driver and name it in the Driver name input field. This input field corresponds to the Identification property. The name of the selected driver is automatically inserted into this input field by default. The following is applicable for the Driver name:
 - The Driver name must be unique.
 If a driver is used more than once in a project, a new name has to be given each time.
 This is evaluated by clicking on the OK button. If the driver is already present in the project,
 - The Driver name is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (_).
 - Attention: This name cannot be changed later on.

this is shown with a warning dialog.

Confirm the dialog by clicking on the OK button.
 The configuration dialog for the selected driver is opened.

Note: The language of driver names cannot be switched. They are always shown in the language in which they have been created, regardless of the language of the Editor. This also applies to driver object types.



DRIVER NAME DIALOG ALREADY EXISTS

If there is already a driver in the project, this is shown in a dialog. The warning dialog is closed by clicking on the **OK** button. The driver can be named correctly.

	zenon Energy Edition	×
	This driver name already exists! Please enter an unique driver name!	
	ОК	

ZENON PROJECT

The following drivers are created automatically for newly-created projects:

- Intern
- MathDr32
- SysDrv

Information

Only the required drivers need to be present in a zenon project. Drivers can be added at a later time if required.

6.2 Settings in the driver dialog

You can change the following settings of the driver:



6.2.1 General

The configuration dialog is opened when a driver is created. In order to be able to open the dialog later for editing, double click on the driver in the list or click on the **Configuration** property.

			X
General			
			ОК
Mode:			Cancel
Hardware	•		Help
🔲 Keep updat	te list in memory		
Outputs wri	teable		
Variable ima	age remanent		
Stopped on	n Standby-Server		
🔽 Update time	e global		
Vpdate time Global updatet	e global		
Update time Global updatet 1000	e global		
Update time Global updatet 1000 Priority	e global ime in ms:	ns	
Update time Global updatet 1000 Priority no	e global ime in ms: mat: 1000 r	ns ns	
Update time Global updatet 1000 Priority no	e global ime in ms: mat: 1000 r high: 500 r		

Option	Description
Mode	Allows to switch between hardware mode and simulation mode
	 Hardware: A connection to the control is established.
	 Simulation - static: No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.
	 Simulation - counting: No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values



Option	Description
	within a value range automatically.
	 Simulation - programmed: No communication is established to the PLC. The values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation (main.chm::/25206.htm).
Keep update list in the memory	Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.
Output can be written	 Active: Outputs can be written.
	 Inactive: Writing of outputs is prevented.
	Note: Not available for every driver.
Variable image remanent	This option saves and restores the current value, time stamp and the states of a data point.
	Fundamental requirement: The variable must have a valid value and time stamp.
	The variable image is saved in hardware mode if one of these statuses is active:
	► User status <i>M1</i> (0) to <i>M8</i> (7)
	► REVISION(9)
	► AUS(20)
	► ERSATZWERT(27)
	The variable image is always saved if:
	• the variable is of the object type Driver variable
	• the driver runs in simulation mode. (not



Option	Description
	programmed simulation)
	The following states are not restored at the start of the Runtime:
	► SELECT(8)
	► WR-ACK(40)
	► WR-SUC(41)
	The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image.
Stop on Standby Server	Setting for redundancy at drivers which allow only one communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.
	Attention: If this option is active, the gapless archiving is no longer guaranteed.
	 Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off (statusverarbeitung.chm::/24150.htm) but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.
	Default: inactive
	Note: Not available if the CE terminal serves as a data server. You can find further information in the zenon Operator manual in the CE terminal as a data server chapter.
Global Update time	Setting for the global update times in milliseconds:
	 Active: The set Global update time is used for all variables in the project. The priority set at the variables is not used.
	 Inactive: The set priorities are used for the individual variables.



Option	Description		
	Exceptions: Spontaneous drivers ignore this option. They generally use the shortest possible update time. For details, see the Spontaneous driver update time section.		
Priority	The polling times for the individual priority classes are set here. All variables with the according priority are polled in the set time.		
	The variables are allocated separately in the settings of the variable properties. The communication of the individual variables can be graded according to importance or required topicality using the priority classes. Thus the communication load is distributed better.		
	Attention: Priority classes are not supported by each driver, e.g. spontaneously communicating zenon drivers.		

CLOSE DIALOG

Option	Description	
ОК	Applies all changes in all tabs and closes the dialog.	
Cancel	Discards all changes in all tabs and closes the dialog.	
Help	Opens online help.	

UPDATE TIME FOR SPONTANEOUS DRIVERS

With spontaneous drivers, for **Set value**, **advising** of variables and **Requests**, a read cycle is triggered immediately - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. The update time is generally 100 ms.

Spontaneous drivers are ArchDrv, BiffiDCM, BrTcp32, DNP3, Esser32, FipDrv32, FpcDrv32, IEC850, IEC870, IEC870_103, Otis, RTK9000, S7DCOS, SAIA_Slave, STRATON32 and Trend32.



6.2.2 Options

Configuration of the options for the connection.

General Options General Local TSAP: 192.168.0.1 01.00 Remote TSAP: D2.02 20000 02.02 Integra DB configuration Struktur DB Struktur DB 2 Aam DB 3 Aam with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Aam ning buffer 512 entry count 1024 Write max.entry 64 count 64	Configuration			×
General IP address: 192.168.0.1 01.00 Remote TSAP: Error wait time [ms]: 02.02 20000 Integra DB configuration Struktur DB 2 Alarm DB 3 Alarm with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Alarm ing buffer entry count 512 Read ing buffer entry count 1024 Write max. entry	General Options			
IP address: Local TSAP: 19216801 01.00 Remote TSAP: Error wait time [ms]: 02.02 20000 Integra DB configuration Struktur DB 2 Aiam DB 3 Aiam with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Aiam ring buffer entry count 512 Read ing buffer 512 Read ing buffer for the start offset 2070 Read ing buffer for the start offset Read ing buffer for the	General			
Error wait time [ms]: 02.02 20000 02.02 Integra DB configuration 02.02 Struktur DB 2 Aarm DB 3 Aarm MB 4 Read script DB 6 Read DB 7 Write DB 8 Alarm ing buffer entry count 512 Read ing buffer start offset 2070 Read ing buffer entry count 1024 Write max. entry 64				Cancel
Error wait time [ms]: 02.02 20000 Integra DB configuration Struktur DB 2 Alam DB 3 Alam with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Alam ning buffer 512 entry count 512 Read ing buffer 2070 start offset 2070 Read ing buffer 1024 entry count 1024	192 . 168 . 0 .	1	01.00	
Struktur DB 2 Alarm DB 3 Alarm with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Alarm ring buffer entry count 512 Read ing buffer start offset 2070 Read ing buffer entry count 1024 Write max. entry 64				
Alarm DB 3 Alarm with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Alarm ning buffer entry count 512 Read ning buffer start offset 2070 Read ning buffer entry count 1024 Write max. entry 64	Integra DB configuration			
Alarm with time DB 4 Read script DB 6 Read DB 7 Write DB 8 Alarm ting buffer entry count 512 Read ning buffer start offset 2070 Read ning buffer entry count 1024 Write max. entry 64	Struktur DB	2		
Read script DB 6 Read DB 7 Write DB 8 Alarm ring buffer entry count 512 Read ring buffer start offset 2070 Read ring buffer entry count 1024 Write max. entry 64	Alarm DB	3		
Read DB 7 Write DB 8 Alarm ring buffer entry count 512 Read ring buffer start offset 2070 Read ring buffer entry count 1024 Write max. entry 64	Alarm with time DB	4		
Write DB 8 Alarm ring buffer entry count 512 Read ring buffer start offset 2070 Read ring buffer entry count 1024 Write max. entry 64	Read script DB	6		
Alarm ring buffer 512 Read ring buffer 2070 start offset 1024 Read ring buffer 1024 write max. entry 64	Read DB	7		
entry count 2070 Read ring buffer 2070 Read ring buffer 1024 entry count 1024 Write max. entry 64	Write DB	8		
start offset Read ring buffer entry count Write max. entry 64		512		
entry count Write max. entry 64		2070		
		1024		
		64		

GENERAL

General settings.



Parameter	Description
IP address	PI address of the PLC that is to be communicated with. Note: Entry is limited to valid numbers only. Configuration with a number greater than 255 is automatically corrected to the counter value 255.
Local TSAP	 TSAP for the local station. The configured value consists of two groups (bytes). Each group is formed of two hexadecimal characters. The two groups are separated from each other by spaces or a period. First group: can contain a device identification
	 Second group: is always 00
	Default: 01.00
	Recommended setting: 01.00
	Example: 01.00: PG communicates directly with the connected SIMATIC components
Remote TSAP	TSAP for the partner station (S7 CPU). It consists of two groups (bytes). Each group is formed of two hexadecimal characters. The two groups are separated from each other by spaces or a period.
	 First group: Contains a device identification, for which resources are reserved in the SIMATIC-S7. Possible device identifications: 01: PG 02: OS (operate & watch) 03: Miscellaneous
	 Second group: Contains the addressing of the SIMATIC station, with which communication should be established. Divided into: (Bit 75): Rack (Subsystem) (Bit 40): CPU socket Attention: The addressing is not the communication processor slot, but the CPU slot on which the PLC program is also running. Usually: Slot 2.



Parameter	Description		
	Default:02.02 Example:		
	<i>02.43</i> : OS communicates with the assembly group in rack 2, slot 3 by means of the SIMATIC.		
	Help rule for rack/slot group:		
	Left character: Rack * 2		
	 Right character: Slot 		
	Special case:		
	If the device connected to the net is addressed directly, the group contains <i>00</i> . Hint: In order to avoid incorrect interpretations from the labeling on the device, read the Remote TSAP directly in the Hardware Manager.		
Error wait time [ms]	Error wait time in milliseconds.		
	Default: 20000		

INTEGRA DB CONFIGURATION

In this dialog, the block numbers of the INTEGRA blocks are configured.

The standard assignment is as follows:

Blocks	Number
Definition of the function groups	2
Message module, errors:	3
Message module, errors with time stamp:	4
Read script:	6
Read data:	7
DFI module (write control room data):	8

Configuration of the properties:



Parameter	Description
DB structure	Data block number for function group definition.
	The program structure from <i>DB2</i> (DB structure) is to determine the assignment of the alarm bits from <i>DB3</i> (Alarm DB) to the alarms from <i>DB4</i> (Alarm with time DB) addressed via the DB number and offset.
	Default: 2
Alarm DB	Data block number for message module: Errors and warnings. Default: <i>3</i> Note: DB3 is used to read the initial values.
Alarm with time DB	Data block number for message module: Errors with time stamp.
	Default: 4
Read script DB	Data block number for read script.
	Default: 6
Read DB	Data block number for read data.
	Default: 7
Write DB	Data block number for DFI module: Write wait data.
	Default: 8
Alarm ring buffer entry count	Number of entries in the ring buffer for alarms with time stamp.
	Default: 512
Read ring buffer start offset	Offset to the start of the ring buffer for the reading of variables.
	Default: 2070
Read ring buffer entry count	Number of entries in the ring buffer for the reading of variables.
	Default: 1024
Write max. entry count	Maximum number of variables that can be written in a cycle by means of the Write data block.



Parameter	Description
	Default: 64

CLOSE DIALOG

Option	Description
ОК	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.

Attention

Redundant operation is only permitted if the following conditions have been met:

- The **Stop on Standby Server** option (**General** (on page 12) tab) must be activated.
- The data block numbers are configured together for **Server 1** and **Server 2**.

7 Creating variables

This is how you can create variables in the zenon Editor:

7.1 Creating variables in the Editor

Variables can be created:

- as simple variables
- in arrays (main.chm::/15262.htm)
- as structure variables (main.chm::/15278.htm)

VARIABLE DIALOG

To create a new variable, regardless of which type:



🖃 🚰 VARIABLE (Start pr	1 -) E	🖻 🐘 🗙 🎛 🔸 (W W 15	XML 43 43	🖣 🕇 10	🖌 ्र 🐴		
😑 🔷 Variables	Status	$Name \bigtriangleup$	đ	h Unit	Net address	Data block	Offset I	Bit num	Alignm.
Driver	- 7			T Filter	Filter text 🖬	Filter text 🛛 🔽	Filter text 📘	Filter 🔽	Filter
A Datatypes Reaction m		drv_arith			0	0	0	0	0
Allocations		drv_C	Variable new		Ins	0	0	0	0
🗈 🕛 Alarm		drv_E	Create standard fun	oction		0	0	0	0
👽 Units		drv_N	Links distance whe			0	0	0	0
Screens		drv_№	Linked elements		•	0	0	0	0
⊕		drv_N	Copy		Ctrl+C	0	0	0	0
		drv_N	Paste		Ctrl+V	0	0	0	0
Recipes		drv_N				0	0	0	0
- e Time control		drv_S	Delete		Del	0	0	0	0
🗉 🌏 Programming interfa	+-	Interr	Expand/collapse no	de	•	0	0	0	0
	+-	Interr	Activate all			0	0	0	0
Production & Facilit	+-	Interr				0	0	0	0
Interlockings			Activate						
Energy Managemer			Deactivate						
Message Control			Export XML selected	4					
- 🔄 Menus				1					
- 🏭 Report Generator			Import XML						
🗈 🥵 User administrati			Extended import/exp	port	•				
SAP interface			Extended filter						
⊕ ☐ Files ☐ History of chang	1				,				
Projektsicherun			Remove all filter						
T PBI	•		Edit selected cell		F2				

1. Select the **New variable** command in the **Variables** node in the context menu

The dialog for configuring variables is opened

- 2. Configure the variable
- 3. The settings that are possible depends on the type of variables



CREATE VARIABLE DIALOG

Settings	
Name: S_Variable	
Driver	
SIMUL32 - SIMUL_WIZ	▼
Driver object type PLC marker	
Datatype	
REAL	
Array settings	
Start index is 0 Start index is 1	
Dim 1 Dim 2	Dim 3
	0
Addressing options	
Automatic addressing	
Addressing according to data type offset and st	tart offset
Manual addressing Each datatype starts with new offset	
Level data ype starts with new offset	
Automatic addressing	
) Activate all elements) Activate element manually	
Prevence clement manually	
Back Finish	Cancel Help
roperty	Description
ame	Distinct name of the variable. If a variable w
	already exists in the project, no additional v
	with this name.
	Maximum length: 128 characters
	Attention: the characters # and @ are not
	names. If non-permitted characters are used
	cannot be completed and the Finish button
	Note: For some drivers, the addressing is n
	Note: For some drivers, the addressing is p
	Note: For some drivers, the addressing is property Symbolic address , as well.
iver	property Symbolic address , as well.
ivers	5 1
ivers	property Symbolic address , as well. Select the desired driver from the drop-dow
ivers	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the
rivers	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int
rivers	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the
	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int is automatically loaded.
river Object Type	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int
iver Object Type	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int is automatically loaded.
iver Object Type i.chm::/28685.htm)	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int is automatically loaded. Select the appropriate driver object type from
	property Symbolic address , as well. Select the desired driver from the drop-dow Note: If no driver has been opened in the internal variables (Intern.exe (Main.chm::/Int is automatically loaded.



Property	Description
	selection dialog.
Array settings	Expanded settings for array variables. You can find details in the Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic addressing	Expanded settings for arrays and structure variables. You can find details in the respective section.

SYMBOLIC ADDRESS

The **Symbolic address** property can be used for addressing as an alternative to the **Name** or **Identification** of the variables. Selection is made in the driver dialog; configuration is carried out in the variable property. When importing variables of supported drivers, the property is entered automatically.

Maximum length: 1024 characters.

The following drivers support the **Symbolic address**:

- ► 3S_V3
- AzureDrv
- BACnetNG
- ► IEC850
- KabaDPServer
- OPCUA32
- Phoenix32
- POZYTON
- RemoteRT
- S7TIA
- SEL
- SnmpNg32
- PA_Drv

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- Automatically adapted if the data type is changed



Note for signal range: If a change is made to a data type that does not support the set **signal range**, the **signal range** is amended automatically. For example, for a change from **INT** to **SINT**, the **signal range** is changed to *127*. The amendment is also carried out if the **signal range** was not inherited from the data type. In this case, the **measuring range** must be adapted manually.

1.2 Audressii	
Group/Property	Description
General	General properties of the variables.
Name	Freely definable name.
	Attention: For every zenon project the name must be unambiguous.
Identification	Freely definable identification. E.g. for Resources label, comments,
Addressing	Addressing of the variables.
Net address	not used for this driver
Data block	For <i>Data point (Data block), Data point (Inst. data block)</i> object variables and <i>Alarm with time stamp</i> variables, the data block number must be provided.
	Adjustable from 0 to 4294967295. You can take the exact maximum area for data blocks from the manual of the PLC.
Offset	For <i>Data point ()</i> object variables and <i>Alarm with time stamp</i> variables: Offset of the variables. The save address of the variable in the PLC.
	For <i>Alarm bit</i> object variables: The defined data points are addressed by means of the offset. In the process, Offset <i>0</i> corresponds to 1. Byte of the 1st function group. The first byte of the 2nd function group can be addressed using Offset <i>10.</i>
	Adjustable from <i>0</i> to <i>4294967295</i> .
Alignment	not used for this driver
Bit number	Number of the bit within the configured offset.
	Possible entries: 0 to 65535.
String length	Only available for String variables. Maximum number of characters that the variable can take.

7.2 Addressing



Group/Property	Description
Driver connection	Driver connection of the variables.
Driver connection/Driver Object Type	Object type of the variables. Depending on the driver used, is selected when the variable is created and can be changed here.
Driver connection/Data Type	Data type of the variable. Is selected during the creation of the variable; the type can be changed here. Attention: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.
Driver connection/Priority	Setting the priority class. The variable of the priority class is thus assigned as it was configured in the driver dialog in the General tab. The priority classes are only used if the global update time is deactivated. If the global update time option is activated and the priority classes are used, there is an error entry in the log file of the system. The driver uses the highest possible priority.

7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

7.3.1 Driver objects

The following object types are available in this driver:

Driver Object Type	Cha nnel type	Read	Write	Supported data types	Description
Alarm with time stamp	65	Х		BOOL, USINT	Errors with time stamp: Spontaneous. Default: DB4.
					Note: Variables of this driver object type are installed each time a



Driver Object Type	Cha nnel type	Read	Write	Supported data types	Description
					connection is established.
Data point (Marker)	66	Х	Х	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL	Additional data with time stamp (spontaneous) Source data point: <i>PLC marker</i>
Data point (Intput)	67	X	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT	Additional data with time stamp (spontaneous) Source data point: <i>Input</i>
Data point (Output)	68	Х	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT	Additional data with time stamp (spontaneous) Source data point: <i>Output</i>
Data point (Data block)	69	X	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL	Additional data with time stamp (spontaneous) Source data point: <i>Data block</i>
Data point (Inst. data block)	70	Х	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL	Additional data with time stamp (spontaneous) Source data point: <i>Data block instance</i>
Data point (Local data)	71	Х	Х	BOOL, SINT, USINT, INT, UINT, DINT, UDINT	Additional data with time stamp (spontaneous) Source data point: <i>Local data</i>
Data point (Previous local data)	72	Х	Х	BOOL, SINT, USINT, INT, UINT, DINT, UDINT	Additional data with time stamp (spontaneous) Source data point:



Driver Object Type	Cha nnel type	Read	Write	Supported data types	Description
					Previous local data
Communication details	35	X	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the static analysis of the communication; is transferred between driver and Runtime (not to the PLC).
					Note : The addressing and the behavior is the same for most zenon drivers.
					You can find detailed information on this in the Communication details (Driver variables) (on page 38) chapter.

Key:

X: supported

--: not supported

ALARM BIT DRIVER OBJECT TYPE (DB3 MESSAGE MODULE - ERRORS)

The DB3 collects a maximum of 24000 (80 bit x 300 function groups) of defined, fixed variables:

- Errors
- Warnings
- Emergency off
- Q stop
- Feeder/consumer
- Not automatic
- Deselection



- Stop at the end of a cycle
- Idle
- Planned downtime
- Special operation
- Emergency operation
- Error suppression

Each bit in the DB3 can be assigned to a function group. Addressing is linear by means of the settings for offset bit of the variable. Offset *0* corresponds to the 1st Function group. Offset 10 corresponds to the 1st byte of the 2nd function group (a function group consists of 80 bis or 10 bytes).

DB4 ALARM DRIVER OBJECT TYPE (DB4 MESSAGE MODULE - COLLECTIVE MESSAGES WITH TIME STAMP)

The DB4 is for the entry of collective messages with a precise (cycle) time stamp. An entry is created for each error, status error, warning, additional warning or emergency stop. Which messages are collected is pre-defined (controller).

The driver reads the ring buffer cyclically. After the driver has restarted, the driver starts with the next event. Past events are ignored. After a connection has been lost, the driver attempts to start the last entry that was read when starting up again. If that is not possible, (ring buffer overflow) the action corresponds to that of a driver restart.

Each entry consists of a DB number, byte address, bit address, flank change, production-related and time stamp.

The attendant variable is searched for using the DB number, byte address and bit address. The time stamp contained in the event is assigned to the variable. The **SPONT** bit is set for values read from the ring buffer. The image to the value depends on the data type:

BOOL variables:

The variables are assigned the value from the flank change.

• USINT variables:

Bit 0 is assigned the value from the flank change, bit 1 is assigned the production-related bit

Variables for which no value has been received (not contained in the ring buffer) are assigned 0. The **GA** bit is also set. This allows a distinction of the initial value from the spontaneous value.



Attention

The size of the ring buffer can be configured and must correspond to the actual size in the controller.

The polling interval must be configured so that there are no overflows. If the ring buffer overruns, values are lost and the correctness of the assignment sequence is no longer guaranteed.

DATA POINT DRIVER OBJECT VARIABLES - ADDITIONAL DATA WITH TIME STAMP (SPONTANEOUS)

READ

The additional data is cached by the PLC in a ring buffer with time stamp. The driver receives values spontaneously by means of cyclical reading of the ring buffer, including the time stamp form the controller.

The data points that are buffered are defined in the PLC by the read script (Default: DB6). 512 data points can be entered in the read script as a maximum.

After establishing or reestablishing the connection after communication has been interrupted, the driver automatically enters all variables of the following object types configured for the driver into the read script:

- Data point (Merker)
- Data point (Input)
- Data point (Output)
- Data point (Data block)
- Data point (Inst. data block)
- Data point (Local data)
- Data point (Previous local data)

After the variables have been entered, the driver reads initial values for all data points and the cyclically reads the value changes from the ring buffer (Default: DB7).

The polling interval for the cyclical reading of the ring buffer results from the shortest update time of the currently-registered variables.



Attention

- The ring buffer in the controller is reinitialized after a connection has been lost by reinitializing the read script. Spontaneous values that may be present are lost in this process.
- The size of the ring buffer can be configured and must correspond to the actual size in the controller. The polling interval must be configured so that there are no overflows. If the ring buffer overruns, values are lost and the correctness of the assignment sequence is no longer guaranteed.

WRITE

A

Value changes are written by the DFI module (Default:: *DB8*) of the PLC. Several write commands can be compiled; the number of write commands that can be compiled can be configured. The values written are all applied for *site* operating mode.

7.3.2 Mapping of the data types

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

PLC	zenon	Data type
BIT	BOOL	8
USINT	USINT	9
SINT	SINT	10
UINT	UINT	2
INT	INT	1
UDINT	UDINT	4
DINT	DINT	3
-	ULINT	27
-	LINT	26
-	REAL	5
-	LREAL	6
-	STRING	12



PLC	zenon	Data type
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19

DATA TYPE

The term **data type** is the internal numerical identification of the data type. It is also used for the extended DBF import/export of the variables.

7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.

Information

You can find details on the import and export of variables in the Import-Export (main.chm::/13028.htm) manual in the Variables (main.chm::/13045.htm) section.

7.4.1 XML import

During XML import of variables or data types, these are first assigned to a driver and then analyzed. Before import, the user decides whether and how the respective element (variable or data type) is to be imported:

Import:

The element is imported as a new element.

- Overwrite: The element is imported and overwrites a pre-existing element.
- Do not import:

The element is not imported.

Note: The actions and their durations are shown in a progress bar during import. The import of variables is described in the following documentation. Data types are imported along the same lines.



REQUIREMENTS

The following conditions are applicable during import:

Backward compatibility

At the XML import/export there is no backward compatibility. Data from older zenon versions can be taken over. The handover of data from newer to older versions is not supported.

<u>Consistency</u>

The XML file to be imported has to be consistent. There is no plausibility check on importing the file. If there are errors in the import file, this can lead to undesirable effects in the project.

Particular attention must be paid to this, primarily if not all properties exist in the XML file and these are then filled with default values. E.g.: A binary variable has a limit value of *300*.

Structure data types

Structure data types must have the same number of structure elements. Example: A structure data type in the project has 3 structure elements. A data type with the same name in the XML file has 4 structure elements. Then none of the variables based on this data type in the file are imported into the project.

🗉 🖌 Hint

You can find further information on XML import in the **Import - Export** manual, in the **XML import (main.chm::/13046.htm**) chapter.

7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.

Information

Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list
- 2. in the drop-down list of Extended export/import... select the Import dBase command
- 3. follow the import assistant



The format of the file is described in the chapter File structure.

Information

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:

- 1. right-click on the variable list
- 2. in the drop-down list of Extended export/import... select the Export dBase... command
- 3. follow the export assistant



DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.
 e.g. the path C:\users\John.Smith\test.dbf is invalid.
 Valid: C:\users\JohnSmith\test.dbf
- must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.

Information

dBase does not support structures or arrays (complex variables) at export.

FILE STRUCTURE OF THE DBASE EXPORT FILE

The dBaseIV file must have the following structure and contents for variable import and export:



Attention

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- conform with their name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- Be stored close to the root directory (Root)

STRUCTURE

Identification	Тур е	Field size	Comment
KANALNAME	Cha	128	Variable name.
	r		The length can be limited using the MAX_LAENGE entry in the project.ini file.
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (variable name) (field/column must be entered manually). The length can be limited using the MAX_LAENGE entry in the project.ini file.
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	С	128	Identification. The length can be limited using the MAX_LAENGE entry in the project.ini file.
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Nu m	3	Net address
BAUSTEIN	Ν	3	Datablock address (only for variables from the data area



Identification	Тур e	Field size	Comment
			of the PLC)
ADRESSE	Ν	5	Offset
BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipegroup Manager
LES_SCHR	L	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)
OBJEKT	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJEKTTYP and DATENTYP
SIGMIN	Floa t	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	Ν	1	Number of decimal places for the display of the values (measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
MEMTIEFE	Ν	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	Ν	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values



Identification	Тур e	Field size	Comment
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST_MINUS	F	16	Negative hysteresis, from measuring range
PRIOR	N	16	Priority of the variable
REAMATRIZE	С	32	Allocated reaction matrix
ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks
RESOURCE	С	128	Resources label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini .
ADJWVBA	R	1	Non-linear value adaption: <i>0</i> : Non-linear value adaption is used <i>1</i> : Non-linear value adaption is not used
ADJZENON	С	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	С	128	ed VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

Attention

When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.



LIMIT VALUE DEFINITION

Limit definition for limit values 1 to 4, or status 1 to 4:

Identification	Туре	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	technical value or ID number of a linked variable for a dynamic limit value (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit value
HYSTERESE1	F	14	Is not used
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Functions linking
ASK_FUNC1	R	1	Execution via Alarm Message List
FUNC_NR1	Ν	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/Event Group
A_KLASSE1	Ν	10	Alarm/Event Class
MIN_MAX1	С	3	Minimum, Maximum
FARBE1	Ν	10	Color as Windows coding
GRENZTXT1	С	66	Limit value text
A_DELAY1	Ν	10	Time delay



Identification	Туре	Field size	Comment
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.

7.5 Communication details (Driver variables)

The driver kit implements a number of driver variables. This variables are part of the driver object type *Communication details*. These are divided into:

- Information
- Configuration
- Statistics and
- Error message

The definitions of the variables implemented in the driver kit are available in the import file **DRVVAR.DBF** and can be imported from there.

Path to file: %ProgramData%\COPA-DATA\zenon<Versionsnummer>\PredefinedVariables

Note: Variable names must be unique in zenon. If driver variables of the driver object type *Communication details* are to be imported from **DRVVAR.DBF** again, the variables that were imported beforehand must be renamed.

Information

Not every driver supports all driver variables of the driver object type *Communication details*.

For example:

- Variables for modem information are only supported by modem-compatible drivers.
- Driver variables for the polling cycle are only available for pure polling drivers.
- Connection-related information such as ErrorMSG is only supported for drivers that only edit one connection at a a time.

INFORMATION

Name from import	Туре	Offset	Description
MainVersion	UINT	0	Main version number of the driver.



Name from import	Туре	Offset	Description
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon Service Pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfe r	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped
			For <i>driver stop</i> , the variable has the value <i>TRUE</i> and an OFF bit. After the driver has



Name from import	Туре	Offset	Description
			started, the variable has the value <i>FALSE</i> and no OFF bit.
SimulRTState	UDINT	60	Informs the status of Runtime for driver simulation.
ConnectionStates	STRING	61	Internal connection status of the driver to the PLC.
			Connection statuses:
			0: Connection OK
			1: Connection failure
			2: Connection simulated
			Formating:
			<netzadresse>:<verbindungszustand>;;;</verbindungszustand></netzadresse>
			A connection is only known after a variable has first signed in. In order for a connection to be contained in a string, a variable of this connection must be signed in once.
			The status of a connection is only updated if a variable of the connection is signed in. Otherwise there is no communication with the corresponding controller.

CONFIGURATION

Name from import	Туре	Offset	Description
ReconnectInRead	BOOL	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem.



Name from import	Туре	Offset	Description
			This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet .
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver
Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baudrate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	USINT	14	Number of bits per character of the serial interface Value = 0 if the driver cannot establish any serial connection.
StopBit	USINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)



Name from import	Туре	Offset	Description
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UINT	54	Time in seconds (s) to establish a connection.

STATISTICS

Name from import	Туре	Offse t	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).



Name from import	Туре	Offse t	Description
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group High in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

ERROR MESSAGE

Name from import	Туре	Offse t	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	DINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	USINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file



8 Driver-specific functions

READING OF THE INITIAL ALARM VALUES FROM DB3

With a new connection, there is first a check to see whether a new alarm has been generated since the interruption of the connection. Exception: when the driver starts.

- If no new alarm is generated, the actual values from the internal image of the driver are written to the variables; the I-bit of the variable is deleted in the process.
- When the driver is restarted or with newly-created alarms, there is an attempt to read the initial alarm values whilst the connection has been interrupted.

To do this, the function group blocks are read from **DB2** first. The actual initial values are then read from **DB3**. The function group blocks are needed for the assignment of the initial values.

Information

If the pointer changes during the read process, the existing/saved initial values are invalid. This is the case if new alarms have been generated.

In this case, the read process is repeated up to 50 times. If the fiftieth read process was also not successful, a corresponding error message is created in the LOG.

The initial values are nevertheless assigned; in this case, there can be inconsistencies in the alarm administration.

9 Driver command function

The zenon **Driver commands** function is to influence drivers using zenon. You can do the following with a driver command:

- Start
- Stop
- Shift a certain driver mode
- Instigate certain actions

Note: This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.



Attention

The zenon **Driver commands** function is not identical to driver commands that can be executed in the Runtime with Energy drivers!

CONFIGURATION OF THE FUNCTION

Configuration is carried out using the **Driver commands** function. To configure the function:

1. Create a new function in the zenon Editor.

The dialog for selecting a function is opened

Select a function	×
Functions selection	
Favorites	
Screen switch	
S Write/modify set value	
ia- instantia and CEL	
E - B Batch Control	
. Message Control	
🗄 🖓 Network	
• Recipes	
E Report Generator/Report Viewer/Analyzer	
🗄 📲 🖅 Screens	
🗄 💼 Script	
🗄 🔤 Shift Management	
ianse Administration ianse Variable	
terret vanable terret vanable	
₩··· 🐼 VSTA	
How Windows	
	_
Quick help	
	-
· · · · · · · · · · · · · · · · · · ·	4
1	
OK Cancel Help	
Current Prep	

- 2. Navigate to the node Variable.
- 3. Select the **Driver commands** entry.



The dialog for configuration is opened

Drivers	×
Driver commands	
Settings	ОК
Drivers	Cancel
InternDriver for internal variables $~~$	
Current status	Help
Drivers	
Driver command	
<no command=""></no>	
Show this dialog in the Runtime	

- 4. Select the desired driver and the required command.
- 5. Close the dialog by clicking on **OK** and ensure that the function is executed in the Runtime. Heed the notices in the **Driver command function in the network** section.

DRIVER COMMAND DIALOG

rivers Driver commands	>
Settings Drivers INTERNDriver for internal variables Current status Drivers Driver command Driver-specific command Currentsettic command	OK Cancel Help
Show this dialog in the Runtime	

Option	Description
Driver	Selection of the driver from the drop-down list. It contains all drivers loaded in the project.
Current condition	Fixed entry that is set by the system. Has no function in the current version.
Driver command	Selection of the desired driver command from a drop-down list.
	For details on the configurable driver commands, see the available driver commands section.
Driver-specific command	Entry of a command specific to the selected driver.



Option	Description
	Note: Only available if, for the driver command option, the <i>driver-specific command</i> has been selected.
Show this dialog in the Runtime	Configuration of whether the configuration can be changed in the Runtime:
	• Active: This dialog is opened in the Runtime before executing the function. The configuration can thus still be changed in the Runtime before execution.
	• <i>Inactive</i> : The Editor configuration is applied in the Runtime when executing the function.
	Default: inactive

CLOSE DIALOG

Options	Description
ОК	Applies settings and closes the dialog.
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

AVAILABLE DRIVER COMMANDS

These driver commands are available - depending on the selected driver:

Driver command	Description
<no command=""></no>	No command is sent. A command that already exists can thus be removed from a configured function.
Start driver (online mode)	Driver is reinitialized and started. Note: If the driver has already been started, it must be stopped. Only then can the driver be re-initialized and started.
Stop driver (offline mode)	Driver is stopped. No new data is accepted. Note: If the driver is in offline mode, all variables that were created for this driver receive the status <i>switched</i> <i>off</i> (<i>OFF</i> ; Bit <i>20</i>).



Driver command	Description
Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver-specific command	Entry of a driver-specific command. Opens input field in order to enter a command.
Activate driver write set value	Write set value to a driver is possible.
Deactivate driver write set value	Write set value to a driver is prohibited.
Establish connection with modem	Establish connection (for modem drivers)
	Opens the input fields for the hardware address and for the telephone number.
Disconnect from modem	Terminate connection (for modem drivers)
Driver in counting simulation mode	Driver is set into counting simulation mode. All values are initialized with <i>0</i> and incremented in the set update time by <i>1</i> each time up to the maximum value and then start at <i>0</i> again.
Driver in static simulation mode	No communication to the controller is established. All values are initialized with <i>0</i> .
Driver in programmed simulation mode	The values are calculated by a freely-programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in the zenon Logic Runtime.

DRIVER COMMAND FUNCTION IN THE NETWORK

If the computer on which the **Driver commands** function is executed is part of the zenon network, further actions are also carried out:

- A special network command is sent from the computer to the project server. It then executes the desired action on its driver.
- In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.



This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10 Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer (main.chm::/12464.htm) program that was also installed with zenon. You can find it under **Start/All programs/zenon/Tools 8.10 -> Diagviewer**.

zenon driver log all errors in the LOG files.LOG files are text files with a special structure. The default folder for the LOG files is subfolder **LOG** in the folder **ProgramData**. For example:

%ProgramData%\COPA-DATA\LOG.

Attention: With the default settings, a driver only logs error information. With the Diagnosis Viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- Follow newly-created entries in real time
- customize the logging settings
- change the folder in which the LOG files are saved

Note:

- 1. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.
- 2. The Diagnosis Viewer does not display all columns of a LOG file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
- 3. If you only use **Error-Logging**, the problem description is in the column **Error text**. For other diagnosis level the description is in the column **General text**.
- 4. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** or **Error code** or **Driver error parameter (1** and **2)**. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 5. At the end of your test set back the diagnosis level from **Debug** or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and



which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.

Attention

In Windows CE errors are not logged per default due to performance reasons.

You can find further information on the Diagnosis Viewer in the Diagnose Viewer (main.chm::/12464.htm) manual.

10.2 Check list

Questions and hints for fault isolation:

GENERAL TROUBLESHOOTING

- ▶ Is the PLC connected to the power supply?
- Analysis with the Diagnosis Viewer (on page 49):
 -> Which messages are displayed?
- Are the participants available in the **TCP/IP** network?
- Can the PLC be reached via the *Ping* command?

Ping: Open command line -> ping <IP address > (e.g.: ping 192.168.0.100) -> Press the Enter key.

Do you receive an answer with a time or a timeout?

• Can the PLC be reached at the respective port via *TELNET*?

Telnet: Command line: enter: telent <IP address port number> (for example for Modbus: telnet 192.168.0.100 502) -> Press the Enter key.

If the monitor display turns black, a connection could be established.

- Did you use the right object type for the variable?
 Example: Driver variables based on driver object type Communication details are purely statistics variables. They do not communicate with the PLC.
 You can find detailed information on this in the Communication details (Driver variables) (on page 38) chapter.
- Does the offset addressing of the variable match the one in the PLC?

SOME VARIABLES REPORT INVALID.

- INVALID bits always refer to a net address.
- At least one variable of the net address is faulty.



VALUES ARE NOT DISPLAYED, NUMERIC VALUES REMAIN EMPTY

Driver is not working. Check the:

- Installation of zenon
- the driver installation
- The installation of all components
 - -> Pay attention to error messages during the start of the Runtime.

VARIABLES ARE DISPLAYED WITH A BLUE DOT

The communication in the network is faulty:

- With a network project: Is the network project also running on the server?
- With a stand-alone project or a network project which is also running on the server: Deactivate the property Read from Standby Server only in node Driver connection/Addressing.

VALUES ARE DISPLAYED INCORRECTLY

Check the information for the calculation in node **Value calculation** of the variable properties.

DRIVER FAILS OCCASIONALLY

Analysis with the Diagnosis Viewer (on page 49): -> Which messages are displayed?