



© 2020 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. Technical data is only used for product description and are not guaranteed properties in the legal sense. Subject to change, technical or otherwise.



Contents

1	Welcome to COPA-DATA help	5
2	KDNP1	5
3	KDNP1 - data sheet	7
4	Driver history	8
5	Requirements	8
	5.1 PC	8
6	Configuration	9
	6.1 Creating a driver	
	6.2 Settings in the driver dialog	
	6.2.1 General	
	6.2.2 Com	18
	6.2.3 Options	19
	6.2.4 Connections	23
7	Creating variables	33
	7.1 Creating variables in the Editor	33
	7.2 Addressing	37
	7.3 Driver objects and datatypes	38
	7.3.1 Driver objects	
	7.3.2 Mapping of the data types	39
	7.4 Creating variables by importing	45
	7.4.1 XML import	45
	7.4.2 DBF Import/Export	46
	7.5 Communication details (Driver variables)	51
8	Driver-specific functions	57
9	Driver command function	59
10) Error analysis	64
	10.1 Analysis tool	64
	10.2 Driver monitoring	65
	10.3 Check list	66





1 Welcome to COPA-DATA help

ZENON VIDEO TUTORIALS

You can find practical examples for project configuration with zenon in our YouTube channel (https://www.copadata.com/tutorial_menu). The tutorials are grouped according to topics and give an initial insight into working with different zenon modules. All tutorials are available in English.

GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to documentation@copadata.com.

PROJECT SUPPORT

You can receive support for any real project you may have from our customer service team, which you can contact via email at support@copadata.com.

LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email sales@copadata.com.

2 KDNP1

The **KDNP1** driver is for communication with Kepco's **KDNP1** protocol, which is based on the DNP3 standard. In doing so, the driver acts as a Master. At protocol level, serial communication and IP communication to several Outstations are supported via TCP.

- ▶ The **KDNP1** driver polls for objects. This polling is cyclical. In addition, this polling can be activated or deactivated with a driver command.
- In addition, the driver supports communication with Confirmed Data link layer. To do this, the **Data link confirm** property in the **Outstation** driver dialog can be activated. Timeout and the number of attempts can be configured for this property.



DEFINITION OF TERMS

In order for you to understand this document better, please find the definition of important terms in the following list.

Term	Definition	
Master	Controlling station. A Master sends read queries and control queries to the Outstation .	
Objekt Group	Data type or data type in the Outstation with a defined functionality.	
	Examples of assignments:	
	• Object Group 30 is a statistical analog entry.	
	• A value change for an analog input is assigned to <i>Object Group 32</i> .	
	▶ Object Group 40 is for reading an analog output.	
	► Object Group 41 is for writing to an analog output.	
Outstation	SPS or RTU in KDNP1. An Outstation is a slave at protocol level and sends data to the Master on request.	
Point	Equivalent of a variable in the Outstation. A Point is addressed with a Point Number (Offset) per Objekt Group , whereby the following is applicable: <i>Point</i> 12 for Object Group 30 and <i>Point</i> 12 for Object Group 32 both have the same analog input as a basis, but <i>Point</i> 12 for Object Group 1 is a completely-independent binary input. The general term for a value, time or status change is DNP Object .	
Variation	Format in which the Oustation saves a static value or a value change in Class 0 or Class 1, 2 or 3. This can be configured in the Outstation for each Object Group or for each Point .	
	The Variation defines (e.g.)	
	• a static value (Class 0) or a value change, if this is an integer or a floating point.	
	a time stamp is saved or not, or whether Object Flags are saved or not.	

COMMUNICATION

The communication is mainly polling. In doing so, the driver carries out a corresponding Class Poll. Different polling intervals can be defined for binary inputs, binary outputs and analog inputs.

The driver processes the received values and sends them to the Runtime.



3 KDNP1 - data sheet

General:	
Driver file name	KDNP1.exe
Driver name	Kepco KDNP1 Driver
PLC types	Outstations that support the KDNP1 protocol
PLC manufacturer	KEPCO

Driver supports:	
Protocol	KDNP1
Addressing: Address-based	Address based
Addressing: Name-based	
Spontaneous communication	
Polling communication	X
Online browsing	
Offline browsing	
Real-time capable	
Blockwrite	
Modem capable	
RDA numerical	
RDA String	
Hysteresis	X
extended API	
Supports status bit WR-SUC	X
alternative IP address	



Requirements:	
Hardware PC	Serial connection, standard network card
Software PC	-
Hardware PLC	-
Software PLC	-
Requires v-dll	X

Platforms:	
Operating systems	Windows 10; Windows 7; Windows 8; Windows 8.1; Windows Server 2008 R2; Windows Server 2012; Windows Server 2012 R2; Windows Server 2016

4 Driver history

Date	Build number	Change
15.08.15	21913	Created driver documentation

5 Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

5.1 PC

HARDWARE

- Serial interface
- Ethernet TCP



CE

The KDNP1 driver is not available for CE.

6 Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.


Information

Find out more about further settings for zenon variables in the chapter Variables of the online manual.



6.1 Creating a driver

In the Create driver dialog, you create a list of the new drivers that you want to create.



Parameter	Description
Available drivers	List of all available drivers.
	The display is in a tree structure: [+] expands the folder structure and shows the drivers contained therein. [-] reduces the folder structure Default: No selection
	Default. No selection
Driver name	Unique Identification of the driver.
	Default: empty
	The input field is pre-filled with the pre-defined



Parameter	Description
	Identification after selecting a driver from the list of available drivers.
Driver information	Further information on the selected driver. Default: <i>empty</i> The information on the selected driver is shown in this area after selecting a driver.

Option	Description
ОК	Accepts all settings and opens the driver configuration dialog of the selected driver.
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

Information

The content of this dialog is saved in the file called Treiber_[Language].xml. You can find this file in the following folder:

C:\ProgramData\COPA-DATA\zenon[version number].

CREATE NEW DRIVER

In order to create a new driver:


1. Right-click on **Driver** in the Project Manager and select **New driver** in the context menu.

Optional: Select the **New driver** button from the toolbar of the detail view of the **Variables**. The Create driver dialog is opened.

The Create simple data type dialog is opened.



2. The dialog offers a list of all available drivers.



3. Select the desired driver and name it in the **Driver name** input field.

This input field corresponds to the **Identification** property. The name of the selected driver is automatically inserted into this input field by default.

The following is applicable for the **Driver name**:

The **Driver name** must be unique.

If a driver is used more than once in a project, a new name has to be given each time. This is evaluated by clicking on the **OK** button. If the driver is already present in the project, this is shown with a warning dialog.

- The **Driver name** is part of the file name.

 Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (_).
- **Attention:** This name cannot be changed later on.
- Confirm the dialog by clicking on the OK button.
 The configuration dialog for the selected driver is opened.



Note: The language of driver names cannot be switched. They are always shown in the language in which they have been created, regardless of the language of the Editor. This also applies to driver object types.

DRIVER NAME DIALOG ALREADY EXISTS

If there is already a driver in the project, this is shown in a dialog. The warning dialog is closed by clicking on the **OK** button. The driver can be named correctly.



ZENON PROJECT

The following drivers are created automatically for newly-created projects:

- Intern
- MathDr32
- SysDrv



Only the required drivers need to be present in a zenon project. Drivers can be added at a later time if required.


6.2 Settings in the driver dialog

You can change the following settings of the driver:



6.2.1 General

The configuration dialog is opened when a driver is created. In order to be able to open the dialog later for editing, double click on the driver in the list or click on the **Configuration** property.



Option	Description
Mode	Allows to switch between hardware mode and simulation mode
	Hardware:A connection to the control is established.
	No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.
	 Simulation - counting: No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically.
	 Simulation - programmed: No communication is established to the PLC. The



Option	Description
	values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver. For details see chapter Driver simulation.
Keep update list in the memory	Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.
Output can be written	Active: Outputs can be written.
	Inactive: Writing of outputs is prevented.
	Note : Not available for every driver.
Variable image remanent	This option saves and restores the current value, time stamp and the states of a data point.
	Fundamental requirement: The variable must have a valid value and time stamp.
	The variable image is saved in hardware mode if one of these statuses is active:
	• User status <i>M1</i> (0) to <i>M8</i> (7)
	► REVISION(9)
	► AUS(20)
	► ERSATZWERT(27)
	The variable image is always saved if:
	the variable is of the Communication details object type
	 the driver runs in simulation mode. (not programmed simulation)
	The following states are not restored at the start of the Runtime:



Option	Description
	► SELECT(8)
	▶ WR-ACK(40)
	▶ WR-SUC(41)
	The mode Simulation - programmed at the driver start is not a criterion in order to restore the remanent variable image.
Stop on Standby Server	Setting for redundancy at drivers which allow only one communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.
	Attention: If this option is active, the gapless archiving is no longer guaranteed.
	Active: Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status switched off but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.
	Default: inactive
	Note: Not available if the CE terminal serves as a data server. You can find further information in the zenon Operator manual in the CE terminal as a data server chapter.
Global Update time	Setting for the global update times in milliseconds:
	 Active: The set Global update time is used for all variables in the project. The priority set at the variables is not used.
	Inactive: The set priorities are used for the individual variables.
	Exceptions: Spontaneous drivers ignore this option. They generally use the shortest possible update time. For details, see the Spontaneous driver update time section.



Option	Description
Priority	The polling times for the individual priority classes are set here. All variables with the according priority are polled in the set time.
	The variables are allocated separately in the settings of the variable properties. The communication of the individual variables can be graded according to importance or required topicality using the priority classes. Thus the communication load is distributed better.
	Attention: Priority classes are not supported by each driver, e.g. spontaneously communicating zenon drivers.

Option	Description
ОК	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.


UPDATE TIME FOR SPONTANEOUS DRIVERS

With spontaneous drivers, for **Set value**, **advising** of variables and **Requests**, a read cycle is triggered immediately - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. The update time is generally 100 ms.

Spontaneous drivers are ArchDrv, BiffiDCM, BrTcp32, DNP3, Esser32, FipDrv32, FpcDrv32, IEC850, IEC870, IEC870_103, Otis, RTK9000, S7DCOS, SAIA_Slave, STRATON32 and Trend32.



6.2.2 Com



Parameter	Description
Com	Selection Com port. Select from drop-down list: COM 1 to COM 64 Default: 1
Baud rate	Selection baud rate. Amend to PLC. Select from drop-down list: 110 to 256000 Default: 9600
Data bit	Number of data bits. Amend to PLC. Select from drop-down list: 5, 6, 7, 8 Default: 8
Stop bit	Selection stop bit. Amend to controller. Select from drop-down list: 1 1.5



Parameter	Description
) 2
	Default: 1
Parity	Selection of the parity. Amend to controller. Select from drop-down list:
	▶ No
	▶ Odd
	▶ Even
	Default: No
Protocol	Selection protocol. Amend to controller. Select from drop-down list:
	▶ No
	▶ Xon/Xoff
	▶ Rts/CTS
	► DTR/DSR
	Default: No

Option	Description
ОК	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.




The exact settings depend on the used PLCs. Take the valid values from the manual of your PLC.

6.2.3 Options

You configure the communication parameters in this tab.



Note: This dialog is only available in English.



DATA LINK

Parameter	Description
TCP/IP	▶ Active: Communication is via TCP/IP.
Network connection	Selection of the network connection that is used for communication. Entry in the field or selection from a drop-down list from: Name or Network connection or IP address. The names of the network connections available on the local computer are shown in the drop-down list. For remote Runtime computers, enter the name of the
Serial	network card or the IP address of the remote computer. Active: Communication is via the serial interface.
	Default: inactive



Parameter	Description
Receive frame timeout [ms]	Timeout in milliseconds for the receipt of a complete telegram. The start time is the first character of the telegram.
	Default: 1000
	Note: Only active if serial has been activated.
Send frame timeout [ms]	Timeout in milliseconds for the sending of a telegram. If the serial output buffer is filled for longer than this time period, this is considered a transmission error Default: 5000
	Note: Only active if serial has been activated.
Half duplex	 Active: A telegram is sent again if a response has been received for the telegram that was last sent on the interface.
	Default: inactive
	Note: Only active if serial has been activated.

APPLICATION

Parameter	Description
Double Point Mapping	Selection of Double Point Mapping to an integer value. Select from drop-down list:
	▶ SCADA default mapping
	▶ DNP3 binary mapping
	Custom legacy mapping
	Default: SCADA default mapping

PULSE DURATION

Setting of the pulse duration for **Norm**, **Trip** and **Close** for each connection. **Norm**, **Trip** and **Close** define which relay is switched

Parameter	Description
Norm	Corresponds to NUL :
	Pulse duration norm:



Parameter	Description
	 On time: Period of time, in milliseconds, in which the Output is ON Default: 1000
	 Off time: Period of time, in milliseconds, in which the output is OFF Default: 1000
Trip	Pulse duration trip:
	 On time: Period of time, in milliseconds, in which the output is ON Default: 1000
	 Off time: Period of time, in milliseconds, in which the output is OFF Default: 1000
Close	Pulse duration close:
	 On time: Period of time, in milliseconds, in which the output is ON Default: 1000
	 Off time: Period of time, in milliseconds, in which the output is OFF Default: 1000


Option	Description
ОК	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.



6.2.4 Connections

You configure the connection in this tab.

Note: This dialog is only available in English.



Parameter	Description
List of connections	Displays the configured connections.: Net address
	Network address of the outstation. This address must be unique and can only be issued once.
	 Description Description of the outstation. Corresponds to the Friendly name.
	ConnectionConnection port.
	With a TCP connection: TCP/IP address, TCP port
	 With a serial connection: Corresponds to the Com setting configured in the Com tab.
New	Opens the dialog for creating a new connection (on page 24).



Parameter	Description
Edit	Opens dialog for editing the selected connection.
Delete	Deletes the selected connection.

Option	Description
ОК	Applies all changes in all tabs and closes the dialog.
Cancel	Discards all changes in all tabs and closes the dialog.
Help	Opens online help.

CREATE NEW CONNECTION

- 1. Click on the **New** button.
- 2. Enter the connection details.
- 3. Click on **Save**.

EDIT CONNECTION

- 1. Select the connection in the connection list.
- 2. Click on the **Edit** button.
- 3. Change the connection parameters.
- 4. Close by clicking on the **Save** button.

DELETE CONNECTION


- 1. Select the connection in the connection list.
- 2. Click on the **Delete** button.
- 3. The connection will be removed from the list

6.2.4.1 Outstation

You configure connections in this dialog. The dialog is opened if you click, in the **Connections** tab, on the **New** or **Edit** button.



Note: This dialog is only available in English.



GENERAL

General settings.

Parameter	Description
Net address	Net address of the connection.
	Value between 0 and 255. Corresponds to the Net address property for the variable.
	The network address must be unique.
	Default: Last network address issued + 1
Friendly name	Name of connection. Freely selectable.
Connection (IP)	Selection of the TCP channel via which communication with this Outstation takes place.
	With virtual Outstations, it is possible that several stations



Parameter	Description
	share one channel.
	Select from drop-down list. Administration of the connection with the Add and Edit buttons.
	(Not available for serial communication.)
Add	Adds a new TCP link configuration (on page 30). The TCP links dialog is opened.
Edit	Opens the dialog to edit (on page 31) all existing TCP links.
Source address (local)	The driver's own address (KDNP1 Master).
	Default: 3
Dest. address (remote)	Link address of the PLC (KDNP1 Slave).
	Default: 4
Error wait time	Waiting time in the event of a communication error. After an error, the given time is waited before another attempt at establishing a connection is made.
	Default: 20 s
Reply timeout [ms]	Time in milliseconds that is waited for a response from the controller. If this time has expired, a repetition is sent.
	If a fragment of a multi-part response is received. The interval starts over with each fragment received.
	Default: 10000 ms
Retries	Number of communication retries after timeouts.
	Default: 3
Keepalive	If data is received or sent beyond the given time, a LINK_STATUS_REQUEST telegram is sent.
	Default: 120 s
Data link confirm	If the Data link confirm property is activated, Confirmed data link layer telegrams are used in communication.
	This check is configured in the DL timeout and DL Retries properties.



Parameter	Description
	Default: inactive
	Note: This property should only be activated if Confirmed data link layer is also activated on the outstation.
DL timeout	Time in milliseconds that is waited for a data link response from the controller . If this time has expired, a repetition is sent.
	In contrast to the Reply timeout [ms] that is applicable for an application layer telegram, the DL timeout is applicable for a data link layer telegram. An Application Layer telegram can consist of several Data link layer telegrams.
	Default: 1000 ms
	Maximum time: 99999 ms
	Only active if Data link confirm is active.
DL Retries	Maximum number of repeats for a connection check after a connection error on the Data link layer.
	Default: 3
	Only active if Data link confirm is active.

ADVANCED

Parameter	Description
Max. APDU size	Maximum size of a KDNP Application Layer Fragment.
	Minimum: 249
	► Maximum: 65535
	Default: 2048
Timesync LAN	► Active: Time synchronization via the LAN.
	Can only be configured for a TCP connection.
	Default: Activated If serial connection type (on page 19) is selected, the property in the driver dialog is automatically activated and grayed out.



Parameter	Description
	Note: Use variation 3 of the time object. This is not accepted by all stations.
No class poll on IIN1.1, IIN1.2, IIN1.3	Active: Driver ignores the InternalIndication Flags IIN1.1, IIN1.2 and IIN1.3. Compatibility setting: Ensure that polling for events is carried out regularly in order to avoid possible buffer overflows in the Outstation.
No time sync on IIN1.4	Active: The driver ignores the internal indication flag IIN1.4. Compatibility setting. Time synchronization required.
No integrity poll on IIN2.3	Active: Driver ignores the InternalIndication Flag IIN2.3 (BufferOverflow). Compatibility setting.
Delay Measurement (Timesync)	If active, the driver carries out a Delay Measurement when time synchronizing.
	Active if:
	► Connection type Serial
	▶ IP connection type (TCP/IP) and Timesync LAN not active.
	Note: With a serial connection, Timesync_LAN is active by default and grayed out, Delay Measurement (Timesync) can however be selected.

POLL PER OBJECT

In this area, you configure the query parameters to the outstation.

The following can be configured:

- ► Type of polling (query)
- Polled objects
- ▶ Time interval of the polling

Parameter	Description
Qualifier: All	If this property is active, all available data points for the respective object type of the outstation are read.
	The interval time of the query can be configured for the respective property.



Parameter	Description
	Default: activated
Qualifier: Range start/stop	If this property is active, only variables in the project can be polled for object types. This means: The driver determines the smallest and largest offset and uses this for the object poll. Default: Not activated
Binary Input	Polling interval for Binary Input object-type variables. Default: 10 s Note: Value 0 deactivates the polling for this object type.
Binary Output	Polling interval for Binary Output object-type variables. Default:20 s
	Note: Value <i>0</i> deactivates the polling for this object type.
Analog Input	Polling interval for Analog Input object-type variables. Default: 30 s
	Note: Value <i>0</i> deactivates the polling for this object type.
Device Indication	Polling interval for the Device Indication object type. This object type provides information on the status of the modules in the outstation: • 0 = ok
	▶ 1 = fault
	Default: 60 s
	Note: Value <i>0</i> deactivates the polling for this object type.




Option	Description
ОК	Applies settings and closes the dialog.
Cancel	Discards all changes and closes the dialog.

6.2.4.1.1 TCP/IP link configuration

Configuration of TCP links.

Note: This dialog is only available in English.



Parameter	Description
IP address (primary)	Entry of the primary IP address.
Port	Primary TCP port of the PLC.
	Default: 20000
IP address (secondary)	Backup address for redundant connection to the PLC.
Port 2	Port of the backup address.
	Default: 20000
TCP re-connect delay [s]	Minimum time period in seconds that must be between two TCP connection attempts.
	Default: 10 s



Parameter	Description
TCP disconnect delay [s]	If no data is sent or received over the given time period, the TCP connection is disconnected automatically.
	Default: 10 s
	Note: In this case, the Pollingintervals must be configured with a correspondingly low time period.
	If the time period set here = 0 the TCP connection is not separated.

NAVIGATION

ОК	Applies settings and closes the dialog.
Cancel	Discards all changes and closes the dialog.

ERROR DIALOG - ADDRESS ALREADY EXISTS

Only one outstation with a port number can be configured per IP address. If two outstations on the same IP address with different port numbers need to be addressed, use an additional driver.

If an IP address conflict occurs during the configuration of an outstation, this is visualized with a warning dialog.



Click on the Browse... button to return to the configuration dialog.


Note: This dialog is only available in English.

6.2.4.1.2TCP/UDP Links

Display and administration of all TCP links.



Note: This dialog is only available in English.



Parameters	Description
Links	Displays the configured TCP channels.
	The IP address and the TCP port is displayed:
	[IP address], TCP:[port number]
New	Opens the dialog to create a new (on page 30) TCP channel.
Edit	Opens the dialog to edit (on page 30) the selected TCP channel.
Delete	Deletes selected TCP link.
	The TCP link is deleted without requesting confirmation.

NAVIGATION

Parameters	Description
ОК	Applies settings and closes the dialog.
Cancel	Discards all changes and closes the dialog.



CREATE A NEW TCP CHANNEL

- Click on the **New** button.
 The TCP/IP link configuration (on page 30) dialog is opened.
- 2. Enter the connection details.
- 3. Click on the **OK** button.

 The dialog is closed. The configured TCP channel is displayed in the **Links** list.

EDIT A TCP CHANNEL

- 1. Select the desired Link in the list.
- 2. Click on the **Edit** button. The TCP/IP link configuration (on page 30) dialog is opened.
- 3. Change the link parameter.
- 4. Close it with **OK**. .

 The dialog is closed. The configured TCP channel is displayed in the **Links** list.

DELETE A TCP CHANNEL

- 1. Select the desired Link in the list.
- 2. Click on the **Delete** button.
- 3. The connection will be deleted from the list without requesting confirmation.

7 Creating variables

This is how you can create variables in the zenon Editor:

7.1 Creating variables in the Editor

Variables can be created:


- as simple variables
- in arrays
- as structure variables

VARIABLE DIALOG

To create a new variable, regardless of which type:



I. Select the **New variable** command in the **Variables** node in the context menu



The dialog for configuring variables is opened

- 2. Configure the variable
- 3. The settings that are possible depend on the type of variables



CREATE VARIABLE DIALOG



Property	Description
Name	Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.
	Maximum length: 128 characters
	Attention: the characters # and @ are not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the Finish button remains inactive. Note: Some drivers also allow addressing using the Symbolic address property.
Driver	Select the desired driver from the drop-down list.
	Note: If no driver has been opened in the project, the driver for internal variables (Intern.exe) is automatically loaded.
Driver Object Type	Select the appropriate driver object type from the drop-down list.
Data Type	Select the desired data type. Click on the button to open the selection dialog.
Array settings	Expanded settings for array variables. You can find details in the



Property	Description
	Arrays chapter.
Addressing options	Expanded settings for arrays and structure variables. You can find details in the respective section.
Automatic element activation	Expanded settings for arrays and structure variables. You can find details in the respective section.

SYMBOLIC ADDRESS

The **Symbolic address** property can be used for addressing as an alternative to the **Name** or **Identification** of the variables. Selection is made in the driver dialog; configuration is carried out in the variable property. When importing variables of supported drivers, the property is entered automatically.

Maximum length: 1024 characters.

The following drivers support the **Symbolic address**:

- ▶ 3S_V3
- AzureDrv
- BACnetNG
- ▶ IEC850
- KabaDPServer
- POPCUA32
- Phoenix32
- POZYTON
- RemoteRT
- ▶ S7TIA
- SEL
- SnmpNg32
- ▶ PA_Drv
- **EUROMAP63**

INHERITANCE FROM DATA TYPE

Measuring range, Signal range and Set value are always:

- derived from the datatype
- ▶ Automatically adapted if the data type is changed



Note for signal range: If a change is made to a data type that does not support the set **signal range**, the **signal range** is amended automatically. For example, for a change from **INT** to **SINT**, the **signal range** is changed to *127*. The amendment is also carried out if the **signal range** was not inherited from the data type. In this case, the **measuring range** must be adapted manually.

7.2 Addressing

The offset determines the KDNP Point Nummer. In combination with the driver object type, the KDNP object aroup is determined.

object group is determined					
Group/Property	Description				
General	General variable properties.				
Name	Freely definable name.				
	Attention: For every zenon project the name must be unambiguous.				
Identification	Freely definable identification. E.g. for Resources label, comments,				
Addressing	Properties of the variable addressing.				
Net address	Bus address or Net address of the variable.				
	This address refers to the station address in the connection configuration of the driver. This defines the PLC, on which the variable resides.				
	Attention: The DNP address of the Outstation is configured separately during the connection.				
Data block	not used for this driver				
Offset	For variables of all driver object types:				
	KDNP Point in the Outstation. To see always in combination with the driver object type.				
Alignment	not used for this driver				
Bit number	not used for this driver				
String length	Only available for String variables. Maximum number of characters that the variable can take.				
Driver connection	Driver-specific properties.				
Driver Object Type	Object type of the variables. Depending on the driver used, is selected when the variable is created and can be changed here.				



Group/Property	Description
Data Type	Data type of the variable. Is selected during the creation of the variable; the type can be changed here.
	Attention: If you change the data type later, all other properties of the variable must be checked and adjusted, if necessary.

7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

7.3.1 Driver objects

The following object types are available in this driver:

Driver object type	Channel type	Read	Write	Supported data types	Comment
Analog input	68	X		UDINT, DINT, REAL, LREAL, UINT, INT	
Analog output	69	X	X	UDINT, DINT, REAL, LREAL, UINT, INT	
Binary Input	64	X		BOOL	
Binary Output	65	X	X	BOOL, USINT	
Command	11	X	X	STRING	
Device indication	79	X		USINT	
Communication details	35	X	X	BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING	Variables for the static analysis of the communication; Values are transferred between driver and Runtime (not to the PLC). Note: The addressing



Driver object type	Channel type	Read	Write	Supported data types	Comment
					and the behavior is the same for most zenon drivers. You can find detailed
					information on this in the Communication details (Driver variables) (on page 51) chapter.

Key:

X: supported

--: not supported

CHANNEL TYPE

The term **Kanaltyp** is the internal numerical name of the driver object type. It is also used for the extended DBF import/export of the variables.

"Kanaltyp" is used for advanced CSV import/export of variables in the "HWObjectType" column.

7.3.2 Mapping of the data types

DRIVER OBJECT TYPES AND SUPPORTED IEC DATA TYPES FOR VARIABLES IN ZENON

Driver object types	Channe I type	Supported data types	Read	Write	Comment
		(DataType)			
Binary Input	64	BOOL	Χ		
Static object group 1					
Event object group 2					
Binary Output	65	BOOL		X	Value 1: LATCH_ON Value 0: LATCH_OFF



Driver object types	Channe I type	Supported data types (DataType)	Read	Write	Comment
Static object group 10					
Event object Group 11					
CROB object group 12					
Binary Output	65	USINT		X	Value 1: PULSE_ON
Static object group 10					Value 2: PULSE_OFF Value 3: LATCH_ON Value 4: LATCH_OFF
Event object group 11					Value 65: CLOSE
CROB object group 12					Value 129: TRIP
					Value 1 for PULSE_ON, LATCH_ON and CLOSE, value 0 for PULSE_OFF, LATCH_OFF and TRIP
Analog Input	68	INT, DINT, REAL,	X		
Static object group 30		LREAL			
Event object group 32					
Analog Output	69	INT, DINT, REAL,		X	written value is
Static object group 40		LREAL			mirrored as a response after successful writing
Event object group 42					
Analog Output Block object group 41					
Command	11	STRING	X	X	Initiates an explicit command



Driver object types	Channe I type	Supported data types	Read	Write	Comment
		(DataType)			
					For example, explicit reading,
Device indication	79	USINT	X		Provides information on the status of the modules in the outstation:
					▶ 0 = ok
					▶ 1 = fault

BINARY OUTPUTS

The writing of *Binary Outputs* is always carried out by means of a **CROB** (group 12), with a choice of *Direct Operate*, *Select Before Operate*, or *Direct Operate No Ack*. In doing so, the setting for the variable-specific property **Command Mode** (accessible via XML export/import and VBA **COMMAND_MODE**) is used. Direct writing to group *10* is not supported by the driver.

After successful writing, the variable receives the value 0 for *Binary Outputs* with *PULSE_OFF*, *LATCH_OFF* and *TRIP*, and value 1 for *PULSE_ON*, *LATCH_ON* and *CLOSE*. The value is also updated if a *Binary Output Status* (group 10) or *Binary Output Status Event* (group 11) object is received.

Command processing with Binary Output variables:

- Only dual command or switching commands can be used.
- The property **Select Before Operate** must be deactivated for the variable; the KDNP1 driver uses *Auto-SBO* if necessary.

Use of the **Qualifier of Command** is recommended for the Command Processing in order to determine the type:

Туре	QoC
PULSE OFF/PULSE ON	1
LATCH OFF/LATCH ON	0
TRIP/CLOSE	2

The **Qualifier of Command** option can be used with both *Binary Output* variables of the *BOOL* data type as well as the *USINT* data type.



ANALOG OUTPUTS

The writing of *Analog Outputs* is always with a group 41, with the choice of *Direct Operate*, *Select Before Operate* or *Direct Operate No Ack*. In doing so, the setting for the variable-specific property **Command Mode** (accessible via XML export/import and VBA **COMMAND_MODE**) is used.

After successful writing, the variable first receives the value written in Runtime. The value is also updated if an *Analog Output Status* (group 40) or *Analog Output Status* (group 42) object is received.

Use the *write set value* action text for *Analog Outputs*. According to the **Command Mode** option for the variable, for *Analog Outputs* either a *direct operate* or a *select before operate* is carried out. The **Select Before Operate** option must be deactivated for the variable. The **Qualifier of Command** option is not available for the *Write set value* action and has no influence with *Analog Outputs*.

For two-stage command processing, the command is only sent to the outstation at the second stage of the command, including **Select** with *Auto-SBO*.

EXPLICIT COMMAND

Command driver object type variables are used to instigate a certain action once. The action is initiated by the writing of a string value to the command variable. The result of the action is assigned to the variables.

Syntax:

A command consists of the command name and parameters. The command name and the individual parameters are separated by spaces.

Example: READ 11 Read all binary inputs for network address 1 (Object Group 1, Variation 0 (default variation))

Attention: It is possible, with the compilation of parameters for an explicit command, that there are combinations that do not correspond to a valid command in the meaning of the IEEE 1815 standard. Commands are sent to the outstation without further checking and can, under certain circumstances, trigger incorrect actions here.

EXPLICIT COMMAND

Command driver object type variables are used to instigate a certain action once. The action is initiated by the writing of a string value to the command variable. The result of the action is assigned to the variables.

Syntax: A command consists of the command name and parameters. The command name and the individual parameters are separated by spaces.

Example: READ_VAR 1 0 254 Read all device attributes for network address 1 (Object Group 0, Variation 254)

Example: READ 11 Read all binary inputs for network address 1 (Object Group 1, Variation 0 (default variation))



Attention: It is possible, with the compilation of parameters for an explicit command, that there are combinations that do not correspond to a valid command in the meaning of the IEEE 1815 standard. Commands are sent to the outstation without further checking and can, under certain circumstances, trigger incorrect actions here.

EXPLICIT READ, VARIATION 0

Command: READ

Read all points of a group: (Qualifier Code 06 - you can use this number of parameters for static Object Groups and Event Object Groups)

- Parameter 1: Net address
- Parameter 2: Group

Read n-points of a group: (Qualifier Code 07, 08, 09 - you can use this number of parameters for the Event Object Groups. The use of a number greater than 65535 (Qualifier Code 09) is not recommended))

- Parameter 1: Net address
- Parameter 2: Group
- Parameter 3: Number of the points to be read

Read certain points of a group: (Qualifier Code 00, 01 - you can use this number of parameters for static Object Groups, for example: Group 1 - Binary Input).

- Parameter 1: Net address
- Parameter 2: Group
- Parameter 3: Start index
- ▶ Parameter 4: Stop index

EXPLICIT READ

Command: READ_VAR

Read all points of a group: (Qualifier Code 06 - you can use this number of parameters for static Object Groups and Event Object Groups)

- Parameter 1: Net address
- Parameter 2: Group
- Parameter 3: Variation

Read n-points of a group: (Qualifier Code 07, 08, 09 - you can use this number of parameters for Event Object Groups. The use of a number greater than 65535 (Qualifier Code 09) is not recommended))



- Parameter 1: Net address
- ▶ Parameter 2: Group
- ▶ Parameter 3: Variation
- Parameter 4: Number of the points to be read

Read certain points of a group: (Qualifier Code 00, 01 - you can use this number of parameters for static Object Groups, for example: Group 1 - Binary Input).

- Parameter 1: Net address
- Parameter 2: Group
- ▶ Parameter 3: Variation
- Parameter 4: Start index
- ▶ Parameter 5: Stop index

ACTIVATE/DEACTIVATE OBJECT POLL

Command: CYCLIC_POLL

Parameter 1: Net address

The command is rejected if an invalid network address is entered.

- ▶ Parameter 2: Polling:
 - 0 deactivated
 - ▶ 1 activated

COMMAND STATUS CODES

Status code	Description
16	Syntax error.
17	Unknown command.
18	Net address Not existing.
3	Command has been sent.
4	Command completed successfully.
5	Command could not be processed.
6	Command received a negative response.
7	Error when executing the command (Timeout.
8	Execution of the command was interrupted.



7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver

Information

You can find details on the import and export of variables in the Import-Export manual in the Variables section.

7.4.1 XML import

During XML import of variables or data types, these are first assigned to a driver and then analyzed. Before import, the user decides whether and how the respective element (variable or data type) is to be imported:

- Import:
 - The element is imported as a new element.
- Overwrite:
 - The element is imported and overwrites a pre-existing element.
- Do not import:
 - The element is not imported.

Note: The actions and their durations are shown in a progress bar during import. The import of variables is described in the following documentation. Data types are imported along the same lines.

REQUIREMENTS

The following conditions are applicable during import:

Backward compatibility

At the XML import/export there is no backward compatibility. Data from older zenon versions can be taken over. The handover of data from newer to older versions is not supported.

Consistency

The XML file to be imported has to be consistent. There is no plausibility check on importing the file. If there are errors in the import file, this can lead to undesirable effects in the project.

Particular attention must be paid to this, primarily if not all properties exist in the XML file and these are then filled with default values. E.g.: A binary variable has a limit value of 300.



Structure data types

Structure data types must have the same number of structure elements. Example: A structure data type in the project has 3 structure elements. A data type with the same name in the XML file has 4 structure elements. Then none of the variables based on this data type in the file are imported into the project.

You can find further information on XML import in the **Import - Export** manual, in the **XML import** chapter.

7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.

Information

Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.

IMPORT DBF FILE

To start the import:

- 1. right-click on the variable list.
- 2. In the drop-down list of Extended export/import... select the Import dBase command.
- 3. Follow the instructions of the import assistant.

The format of the file is described in the chapter File structure.

Information

Note:

- Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

EXPORT DBF FILE

To start the export:



- 1. right-click on the variable list.
- 2. In the drop-down list of Extended export/import... select the Export dBase... command.
- 3. Follow the instructions of the import assistant.

AAttention

DBF files:

- must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- must not have dots (.) in the path name.
 e.g. the path C:\users\John.Smith\test.dbf is invalid.
 Valid: C:\users\JohnSmith\test.dbf
- must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.

Information

dBase does not support structures or arrays (complex variables) at export.

FILE STRUCTURE OF THE DBASE EXPORT FILE

The dBaseIV file must have the following structure and contents for variable import and export:

▲Attention

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- conform with their name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- Be stored close to the root directory (Root)

STRUCTURE

Identi	fication	Typ e	Field size	Comment
KANA	LNAME	Cha	128	Variable name.
		r		The length can be limited using the MAX_LAENGE entry in the project.ini file.



Identification	Typ e	Field size	Comment
KANAL_R	С	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (variable name) (field/column must be entered manually). The length can be limited using the MAX_LAENGE entry in the project.ini file.
KANAL_D	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
TAGNR	С	128	Identification. The length can be limited using the MAX_LAENGE entry in the project.ini file.
EINHEIT	С	11	Technical unit
DATENART	С	3	Data type (e.g. bit, byte, word,) corresponds to the data type.
KANALTYP	С	3	Memory area in the PLC (e.g. marker area, data area,) corresponds to the driver object type.
HWKANAL	Nu m	3	Net address
BAUSTEIN	N	3	Datablock address (only for variables from the data area of the PLC)
ADRESSE	N	5	Offset
BITADR	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
ARRAYSIZE	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipegroup Manager
LES_SCHR	L	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
MIT_ZEIT	R	1	time stamp in zenon (only if supported by the driver)



Identification	Typ e	Field size	Comment
ОВЈЕКТ	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJEKTTYP and DATENTYP
SIGMIN	Floa t	16	Non-linearized signal - minimum (signal resolution)
SIGMAX	F	16	Non-linearized signal - maximum (signal resolution)
ANZMIN	F	16	Technical value - minimum (measuring range)
ANZMAX	F	16	Technical value - maximum (measuring range)
ANZKOMMA	N	1	Number of decimal places for the display of the values (measuring range)
UPDATERATE	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
MEMTIEFE	N	7	Only for compatibility reasons
HDRATE	F	19	HD update rate for historical values (in sec, one decimal possible)
HDTIEFE	N	7	HD entry depth for historical values (number)
NACHSORT	R	1	HD data as postsorted values
DRRATE	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
HYST_PLUS	F	16	Positive hysteresis, from measuring range
HYST_MINUS	F	16	Negative hysteresis, from measuring range
PRIOR	N	16	Priority of the variable
REAMATRIZE	С	32	Allocated reaction matrix
ERSATZWERT	F	16	Substitute value, from measuring range
SOLLMIN	F	16	Minimum for set value actions, from measuring range
SOLLMAX	F	16	Maximum for set value actions, from measuring range
VOMSTANDBY	R	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks



Identification	Typ e	Field size	Comment
RESOURCE	С	128	Resources label. Free string for export and display in lists. The length can be limited using the MAX_LAENGE entry in project.ini.
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: Non-linear value adaption is not used
ADJZENON	С	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	С	128	ed VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

AAttention

When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.

LIMIT VALUE DEFINITION

Limit definition for limit values 1 to 4, or status 1 to 4:

Identification	Туре	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	technical value or ID number of a linked variable for a dynamic limit value (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit value
HYSTERESE1	F	14	Is not used
BLINKEN1	R	1	Set blink attribute



Identification	Туре	Field size	Comment
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Functions linking
ASK_FUNC1	R	1	Execution via Alarm Message List
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/Event Group
A_KLASSE1	N	10	Alarm/Event Class
MIN_MAX1	С	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	С	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.

7.5 Communication details (Driver variables)

The driver kit implements a number of driver variables. This variables are part of the driver object type *Communication details*. These are divided into:

- Information
- Configuration
- Statistics and



Error message

The definitions of the variables implemented in the driver kit are available in the import file **DRVVAR.DBF** and can be imported from there.

Path to file: %ProgramData%\COPA-DATA\zenon<Versionsnummer>\PredefinedVariables

Note: Variable names must be unique in zenon. If driver variables of the driver object type *Communication details* are to be imported from **DRVVAR.DBF** again, the variables that were imported beforehand must be renamed.

Information

Not every driver supports all driver variables of the driver object type *Communication details*.

For example:

- Variables for modem information are only supported by modem-compatible drivers.
- Driver variables for the polling cycle are only available for pure polling drivers.
- ▶ Connection-related information such as **ErrorMSG** is only supported for drivers that only edit one connection at a a time.

INFORMATION

Name from import	Туре	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon Service Pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized



Name from import	Туре	Offset	Description
LineStateDialing	BOOL	24.4	Dialing active
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfe r	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped
			For <i>driver stop</i> , the variable has the value <i>TRUE</i> and an OFF bit. After the driver has started, the variable has the value <i>FALSE</i> and no OFF bit.
SimulRTState	UDINT	60	Informs the state of Runtime for driver simulation.
ConnectionStates	STRING	61	Internal connection status of the driver to the PLC.
			Connection statuses:
			• 0: Connection OK
			• 1: Connection failure
			2: Connection simulated
			Formating:
			<net address="">:<connection status="">;;</connection></net>



Name from import	Туре	Offset	Description
			A connection is only known after a variable has first signed in. In order for a connection to be contained in a string, a variable of this connection must be signed in once. The status of a connection is only updated if a variable of the connection is signed in. Otherwise there is no communication with the corresponding controller.

CONFIGURATION

Name from import	Туре	Offset	Description
ReconnectInRead	BOOL	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	BOOL	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	BOOL	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings PhoneNumberSet and ModemHwAdrSet .
PhoneNumberSet	STRING	38	Telephone number, that should be used
ModemHwAdrSet	DINT	39	Hardware address for the telephone number
GlobalUpdate	UDINT	3	Update time in milliseconds (ms).
BGlobalUpdaten	BOOL	4	TRUE, if update time is global
TreiberSimul	BOOL	5	TRUE, if driver in sin simulation mode
TreiberProzab	BOOL	6	TRUE, if the variables update list should be kept in the memory
ModemActive	BOOL	7	TRUE, if the modem is active for the driver



Name from import	Туре	Offset	Description
Device	STRING	8	Name of the serial interface or name of the modem
ComPort	UINT	9	Number of the serial interface.
Baudrate	UDINT	10	Baud rate of the serial interface.
Parity	SINT	11	Parity of the serial interface
ByteSize	USINT	14	Number of bits per character of the serial interface
			Value = 0 if the driver cannot establish any serial connection.
StopBit	USINT	13	Number of stop bits of the serial interface.
Autoconnect	BOOL	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	STRING	17	Current telephone number
ModemHwAdr	DINT	21	Hardware address of current telephone number
RxIdleTime	UINT	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	UDINT	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	UDINT	20	Number of ringing tones before a call is accepted
ReCallIdleTime	UINT	53	Waiting time between calls in seconds (s).
ConnectTimeout	UINT	54	Time in seconds (s) to establish a connection.

STATISTICS

Name from import	Туре	Offset	Description
MaxWriteTime	UDINT	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	UDINT	32	The shortest time in milliseconds (ms) that is required for writing.



Name from import	Туре	Offset	Description
MaxBlkReadTime	UDINT	40	Longest time in milliseconds (ms) that is required to read a data block.
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNor mal	UDINT	56	Time since the last update of the priority group Normal in milliseconds (ms).
MaxUpdateTimeHigh er	UDINT	57	Time since the last update of the priority group Higher in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group High in milliseconds (ms).
MaxUpdateTimeHigh est	UDINT	59	Time since the last update of the priority group Highest in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

ERROR MESSAGE

Name from import	Туре	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.



Name from import	Туре	Offset	Description
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.
RdErrBlockCount	UINT	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	DINT	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	UDINT	46	Block number when the last reading error occurred.
RdErrMarkerNo	UDINT	47	Marker number when the last reading error occurred.
RdErrSize	UDINT	48	Block size when the last reading error occurred.
DrvError	USINT	25	Error message as number
DrvErrorMsg	STRING	30	Error message as text
ErrorFile	STRING	15	Name of error log file

8 Driver-specific functions

The driver supports the following functions:

Function	Description
Blockwrite	Not supported.
Redundancy	If the Outstation supports several Masters.
RDA	Not supported.
Real time stamping	If the Variation is configured accordingly in the Outstation.
Browsen	Not supported.
	Polling for objects, in configurable cycles or controlled manually.
Spontaneous	Not supported.
Number of PLCs	One driver can connect to any number of Outstations. For serial communications, several Outstations can be configured



Function	Description
	for a serial interface (bus). Mixed operation <i>serial/TCP</i> is also possible with a driver.

ERROR FILE

The driver supports central logging on the diagnosis server (on page 64).

DRIVER VARIABLES

Communication monitoring is possible using the **INVALID** status bit.

KDNP1 OBJECT FLAGS MAPPING

The DNP object flags **ONLINE** and **COMM_LOST** are evaluated by the KDNP1 driver. With **ONLINE** = false or **COMM_LOST** = true, the INVALID bit for the variable is set in Runtime.

Note that the variation configured in the outstation determines whether objects are sent with or without flags for an object group.

In addition, the following flags/IIN bits listed are transferred to the variable status bits:

KDNP1 Flag / IIN	Status bit
Restart	<i>NT</i> Bit
Remote forced	SB Bit
Local forced	SB Bit
Rollover	OV Bit
IIN.1.4 Need time	Time-inval Bit

TIME SYNCHRONIZATION

The driver supports time synchronization of Outstations with the time of the Master station. If the Outstation reports a need for time synchronization by means of an **Internal Indication** flag 1.4 an, the driver sends the current system time in accordance with the options for UTC/local time and the LAN time synchronization.

Ensure that the Outstation gets the time from a different source in this case (such as a GPS receiver) and as a result may possibly not send any requirement for time synchronization to the Master. In this case, ensure that the Runtime computer with the KDNP1 Master station is synchronized with the same time source.



HYSTERESIS

The driver supports hysteresis for spontaneous values (unsolicited responses). Hysteresis is not taken into account by:

- Values that are received as a response to a read request for an event class
- Variables that are explicitly read as classless variables

If an identical value, however with a more recent time stamp is received, then this value is sent by the driver as a new value in Runtime.

9 Driver command function

The zenon **Driver commands** function is to influence drivers using zenon. You can do the following with a driver command:

- Start
- Stop
- Shift a certain driver mode
- Instigate certain actions

Note: This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

▲Attention

The zenon **Driver commands** function is not identical to driver commands that can be executed in the Runtime with Energy drivers!


CONFIGURATION OF THE FUNCTION

Configuration is carried out using the **Driver commands** function. To configure the function:

1. Create a new function in the zenon Editor.




The dialog for selecting a function is opened



- 2. Navigate to the node Variable.
- 3. Select the **Driver commands** entry.




The dialog for configuration is opened



- 4. Select the desired driver and the required command.
- 5. Close the dialog by clicking on **OK** and ensure that the function is executed in the Runtime. Heed the notices in the **Driver command function in the network** section.

DRIVER COMMAND DIALOG





Option	Description
Driver	Selection of the driver from the drop-down list. It contains all drivers loaded in the project.
Current condition	Fixed entry that is set by the system. no function in the current version.
Driver command	no function in the current version.
	For details on the configurable driver commands, see the available driver commands section.
Driver-specific command	Entry of a command specific to the selected driver.
	Note: Only available if, for the driver command option, the <i>driver-specific command</i> has been selected.
Show this dialog in the Runtime	Configuration of whether the configuration can be changed in the Runtime:
	 Active: This dialog is opened in the Runtime before executing the function. The configuration can thus still be changed in the Runtime before execution.
	 Inactive: The Editor configuration is applied in the Runtime when executing the function.
	Default: inactive

CLOSE DIALOG

Options	Description
ОК	Applies settings and closes the dialog.
Cancel	Discards all changes and closes the dialog.
Help	Opens online help.

AVAILABLE DRIVER COMMANDS

These driver commands are available - depending on the selected driver:

Driver command	Description
No command	No command is sent. A command that already exists can thus be removed from a configured function.



Driver command	Description
Start driver (online mode)	Driver is reinitialized and started. Note: If the driver has already been started, it must be stopped. Only then can the driver be re-initialized and started.
Stop driver (offline mode)	Driver is stopped. No new data is accepted.
	Note: If the driver is in offline mode, all variables that were created for this driver receive the status <i>switched off</i> (<i>OFF</i> ; Bit <i>20</i>).
Driver in simulation mode	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver in hardware mode	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system,) are displayed.
Driver-specific command	Entry of a driver-specific command. Opens input field in order to enter a command.
Driver - activate set setpoint value	Write set value to a driver is possible.
Driver - deactivate set setpoint value	Write set value to a driver is prohibited.
Establish connecton with modem	Establish connection (for modem drivers)
	Opens the input fields for the hardware address and for the telephone number.
Disconnect from modem	Terminate connection (for modem drivers)
Driver in counting simulation mode	Driver is set into counting simulation mode. All values are initialized with θ and incremented in the set update time by θ each time up to the maximum value and then start at θ again.
Driver in static simulation mode	No communication to the controller is established. All values are initialized with 0.
Driver in programmed simulation mode	The values are calculated by a freely-programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in the zenon Logic Runtime.



DRIVER COMMAND FUNCTION IN THE NETWORK

If the computer on which the **Driver commands** function is executed is part of the zenon network, further actions are also carried out:

- A special network command is sent from the computer to the project server. It then executes the desired action on its driver.
- In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

10 Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer program that was also installed with zenon. You can find it under **Start/All programs/zenon/Tools 8.20 -> Diagviewer.**

zenon driver log all errors in the LOG files.LOG files are text files with a special structure. The default folder for the LOG files is subfolder **LOG** in the folder **ProgramData**. For example:

%ProgramData%\COPA-DATA\LOG.

Attention: With the default settings, a driver only logs error information. With the Diagnosis Viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- Follow newly-created entries in real time
- customize the logging settings
- change the folder in which the LOG files are saved

Note:

1. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.



- 2. The Diagnosis Viewer does not display all columns of a LOG file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
- 3. If you only use **Error-Logging**, the problem description is in the column **Error text**. For other diagnosis level the description is in the column **General text**.
- 4. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** or **Error code** or **Driver error parameter** (1 and 2). Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
- 5. At the end of your test set back the diagnosis level from **Debug** or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.

AAttention

In Windows CE errors are not logged per default due to performance reasons.

You can find further information on the Diagnosis Viewer in the Diagnose Viewer manual.

10.2 Driver monitoring

Runtime monitors the availability of the driver by means of a watchdog. If a driver is no longer available, the *INVALID* status bit is also set for all checked-in variables.

Possible causes for a triggering of the watchdog:

- ▶ The driver process is no longer running.Check whether the driver EXE file is still running in the Task Manager.
- Operating system is busy with processes that have a higher priority.

Check the configuration of your system to see whether there is sufficient memory and CPU power. In this case, the driver only resets the *INVALID* status bit if there is a value change on the connected party. Static values retain the *INVALID* status bit until the next time the Runtime or the driver is started.

CONFIGURATION OF WATCHDOG

For the monitoring of communication in the Runtime, the connection to the driver is checked in a fixed, prescribed time period of 60 seconds. This process is repeated several times. If, within 5 attempts (= within 5 minutes), no valid connection to the driver is detected, the *INVALID* bit is set for the checked-in (*advised*) variables. In addition, the *INVALID* bit is also set when new variables are advised. The *INVALID* bit will no longer be reset.



Corresponding LOG entries are created for this.

LOG ENTRY

An error message is logged in the LOG when the watchdog is triggered:

Parameter	Description
Communication with driver: <drvexe>/<drvdesc>(id:<drvid>) timed out. No communication for <time> ms.</time></drvid></drvdesc></drvexe>	No communication with driver within the given time. • <time>: Time (in milliseconds) • <drvdesc>: Driver name • <drvexe>: Driver EXE name • <drvid>: Driver ID in the zenon project</drvid></drvexe></drvdesc></time>
Communication with %s timed out. Invalid-Bit will be set.	Communication to the %s driver could not be established after 5 attempts within 60 seconds. The INVALID bit is set for the variable.
Communication with %s timed out. Timeout happened %d times	Communication to the %s driver could not be established after %d times within 60 seconds.

10.3 Check list

Questions and hints for fault isolation:

GENERAL TROUBLESHOOTING

- Is the PLC connected to the power supply?
- Analysis with the **Diagnosis Viewer** (on page 64):
 - -> Which messages are displayed?
- Are the participants available in the **TCP/IP** network?
- Can the PLC be reached via the *Ping* command?

Ping: Open command line -> ping <IP address > (e.g.: ping 192.168.0.100) -> Press the Enter key.

Do you receive an answer with a time or a timeout?

Can the PLC be reached at the respective port via *TELNET*?

Telnet: Command line: enter: telent <IP address port number> (e. g. telnet 192,168,0,100 20000) -> press the enter key.



If the monitor turns black and the cursor blinks, a connection could be established.

- Analysis by using a network monitoring program (Sniffer, e.g. Wireshark, Microsoft Network Monitor / Microsoft Message Analyzer)
- Are you using the correct cable which is recommended by the manufacturer for the connection between the PLC and the PC?
- ▶ Did you select the right COM port?
- ▶ Do the communication parameters match (Baud rate, parity, start/stop bits,...)?
- Is the COM port blocked by another application?
- Did you configure the Net address in the address properties of the variable correctly?
 - ▶ Does the addressing match with the configuration in the driver dialog?
 - ▶ Does the net address match the address of the target station?
- Did you use the right object type for the variable

Example: Driver variables are purely statistics variables. They do not communicate with the PLC. (See chapter Driver variable (on page 51).)

▶ Does the offset addressing of the variable match the one in the PLC?

SOME VARIABLES REPORT INVALID.

- ▶ INVALID bits always refer to a net address.
- At least one variable of the net address is faulty.

VALUES ARE NOT DISPLAYED, NUMERIC VALUES REMAIN EMPTY

Under circumstances, no answer can be received from the PLC for a reading-request.

Driver is not working. Check the:

- Installation of zenon
- the driver installation
- ▶ The installation of all components
 - -> Pay attention to error messages during the start of the Runtime.

VARIABLES ARE DISPLAYED WITH A BLUE DOT

The communication in the network is faulty:

With a network project:
Is the network project also running on the server?



With a stand-alone project or a network project which is also running on the server: Deactivate the property Only read from Standby Server in node Driver connection/Addressing.

VALUES ARE DISPLAYED INCORRECTLY

Check the information for the calculation in node Value calculation of the variable properties.

Check the configuration of the Outstation, if the desired variation is sent (p. e.: **Float** with decimal places).

VALUES ARE NOT DISPLAYED PROMPTLY

Check in the Outstation, if events are generated for the selected values. Also check in which class they are generated. Check the polling of this event class in the driver configuration.

Check the configuration of **unsolicited responses** in the outstation.

THE TIME STAMP OF THE VARIABLE IS INCORRECT.

Check the configuration of the Outstation, to see whether the KDNP1 objects are actually sent with a time stamp. (corresponding variation selected with time stamp.)

Check to see if the Outstation uses local time or UTC and set the option in the driver configuration accordingly,

Check the time of the local computer and the time of the Outstation, including settings for the time zone.

DRIVER FAILS OCCASIONALLY

Analysis with the **Diagnosis Viewer** (on page 64):

-> Which messages are displayed?

Check the timeout of the response time in the driver configuration, especially with outstations with many data points and a slow connection.

With Secure Authentication, check whether the **pre-shared Update Key** in the driver and in the Outstation is identical.