



**zenon**  
by COPA-DATA

# zenon driver manual ISPIP

v.8.20



© 2020 Ing. Punzenberger COPA-DATA GmbH

All rights reserved.

Distribution and/or reproduction of this document or parts thereof in any form are permitted solely with the written permission of the company COPA-DATA. Technical data is only used for product description and are not guaranteed properties in the legal sense. Subject to change, technical or otherwise.

# Contents

<b>1</b>	<b>Welcome to COPA-DATA help</b>	<b>5</b>
<b>2</b>	<b>ISPIP</b>	<b>5</b>
<b>3</b>	<b>ISPIP - data sheet</b>	<b>6</b>
<b>4</b>	<b>Driver history</b>	<b>8</b>
<b>5</b>	<b>Requirements</b>	<b>8</b>
5.1	PC	8
5.2	PLC	8
<b>6</b>	<b>Configuration</b>	<b>8</b>
6.1	Creating a driver	9
6.2	Settings in the driver dialog	12
6.2.1	General	13
6.2.2	Connections	17
<b>7</b>	<b>Creating variables</b>	<b>18</b>
7.1	Creating variables in the Editor	18
7.2	Addressing	22
7.3	Driver objects and datatypes	23
7.3.1	Driver objects	23
7.3.2	Mapping of the data types	25
7.4	Creating variables by importing	26
7.4.1	XML import	27
7.4.2	DBF Import/Export	28
7.5	Communication details (Driver variables)	33
<b>8</b>	<b>Driver-specific functions</b>	<b>39</b>
8.1	Status messages	39
8.2	Analog value	40
8.3	Commands	40
8.3.1	Set value for commands	41
8.3.2	Supported commands	41
8.3.3	Driver-specific functions	49

<b>9 Driver command function</b> .....	<b>49</b>
<b>10 Error analysis</b> .....	<b>55</b>
10.1 Analysis tool.....	55
10.2 Driver monitoring .....	56
10.3 Check list.....	57

# 1 Welcome to COPA-DATA help

## ZENON VIDEO TUTORIALS

You can find practical examples for project configuration with zenon in our YouTube channel ([https://www.copadata.com/tutorial\\_menu](https://www.copadata.com/tutorial_menu)). The tutorials are grouped according to topics and give an initial insight into working with different zenon modules. All tutorials are available in English.

## GENERAL HELP

If you cannot find any information you require in this help chapter or can think of anything that you would like added, please send an email to [documentation@copadata.com](mailto:documentation@copadata.com).

## PROJECT SUPPORT

You can receive support for any real project you may have from our customer service team, which you can contact via email at [support@copadata.com](mailto:support@copadata.com).

## LICENSES AND MODULES

If you find that you need other modules or licenses, our staff will be happy to help you. Email [sales@copadata.com](mailto:sales@copadata.com).

# 2 ISPIP

The **ISPIP driver** communicates with **Hekatron BMZ-Integral (ClientIdentifierClass 0x80)** fire notifications via the ISP-IP protocol. In doing so, communication with main control centers and subordinate control centers is supported.

Functionality:

- ▶ Manual creation and addressing of variables.
- ▶ Status messages in accordance with CAMP are supported in read direction.
- ▶ Analog messages in accordance with AVP are supported in read direction.

- ▶ Commands for status changes are supported.
- ▶ The internal time stamping is used. External time stamps are not requested.
- ▶ Time synchronization is not supported.

Procedure:

- ▶ When starting communication, the driver sends a general query for the status messages. In addition, the driver activates the transfer of analog values.
- ▶ For spontaneous communication of the status messages, the controller only sends messages for detectors that are in normal status. For detectors that are in normal status, no message is received for a general query.
- ▶ For addressed variables, the value *Idle (0)* is assumed with the status *SPONT* if no differing status is received from a general query.
- ▶ The connection is checked with a watchdog timer.
- ▶ A third-party control system must be configured in the equipment for each item of equipment. Two third-party control systems must therefore be configured for redundant operation.

### 3 ISPIP - data sheet

General:	
Driver file name	ISPIP.exe
Driver name	ISPIP Hekatron BMZ
PLC types	Integral fire system control center from Hekatron. Connection to the main control centers or the subordinate control center.
PLC manufacturer	Hekatron

Driver supports:	
Protocol	unknown
Addressing: Address-based	Address based
Addressing: Name-based	--
Spontaneous	X

<b>Driver supports:</b>	
communication	
Polling communication	--
Online browsing	--
Offline browsing	--
Real-time capable	--
Blockwrite	--
Modem capable	--
RDA numerical	--
RDA String	--
Hysteresis	--
extended API	X
Supports status bit	--
<b>WR-SUC</b>	
alternative IP address	--

<b>Requirements:</b>	
Hardware PC	Standard network card
Software PC	-
Hardware PLC	-
Software PLC	An external system with user name and password must be configured for access. Two external systems must be configured for redundant operation with a Server / Standby Server.
Requires v-dll	X

<b>Platforms:</b>	
Operating systems	Windows 10; Windows 7; Windows 8; Windows 8.1; Windows Server 2008 R2; Windows Server 2012; Windows Server 2012 R2; Windows Server 2016

## 4 Driver history

Date	Build number	Change
22.06.18	48508	Created driver documentation

## 5 Requirements

This chapter contains information on the requirements that are necessary for use of this driver.

### 5.1 PC

The following requirements must be met on the computer for driver communication:

- ▶ The driver establishes an outgoing TCP/IP connection to the PLC via a standard network card.
- ▶ User name and password (identification) for access to the controller must be known and configured in the driver configuration.

### 5.2 PLC

The following requirements must be met on the PLC for driver communication:

- ▶ The PLC must be configured with the corresponding user name and password for external access to a third-party system.
- ▶ The PLC must be contactable via TCP/IP.

## 6 Configuration

In this chapter you will learn how to use the driver in a project and which settings you can change.




### Information

Find out more about further settings for zenon variables in the chapter Variables

of the online manual.

## 6.1 Creating a driver

In the **Create driver** dialog, you create a list of the new drivers that you want to create.



Parameter	Description
<p><b>Available drivers</b></p>	<p>List of all available drivers.</p> <p>The display is in a tree structure:                      [+] expands the folder structure and shows the drivers contained therein.                      [-] reduces the folder structure</p> <p>Default: <i>No selection</i></p>

Parameter	Description
<b>Driver name</b>	<p>Unique <b>Identification</b> of the driver.</p> <p>Default: <i>empty</i></p> <p>The input field is pre-filled with the pre-defined <b>Identification</b> after selecting a driver from the list of available drivers.</p>
<b>Driver information</b>	<p>Further information on the selected driver.</p> <p>Default: <i>empty</i></p> <p>The information on the selected driver is shown in this area after selecting a driver.</p>

### CLOSE DIALOG

Option	Description
<b>OK</b>	Accepts all settings and opens the driver configuration dialog of the selected driver.
<b>Cancel</b>	Discards all changes and closes the dialog.
<b>Help</b>	Opens online help.



### Information

The content of this dialog is saved in the file called Treiber\_[Language].xml. You can find this file in the following folder:  
*C:\ProgramData\COPA-DATA\zenon[version number].*

### CREATE NEW DRIVER


In order to create a new driver:

1. Right-click on **Driver** in the Project Manager and select **New driver** in the context menu.

Optional: Select the **New driver** button from the toolbar of the detail view of the **Variables**. The Create driver dialog is opened.

The **Create simple data type** dialog is opened.

- The dialog offers a list of all available drivers.




- Select the desired driver and name it in the **Driver name** input field. This input field corresponds to the **Identification** property. The name of the selected driver is automatically inserted into this input field by default. The following is applicable for the **Driver name**:
  - ▶ The **Driver name** must be unique. If a driver is used more than once in a project, a new name has to be given each time. This is evaluated by clicking on the **OK** button. If the driver is already present in the project, this is shown with a warning dialog.
  - ▶ The **Driver name** is part of the file name. Therefore it may only contain characters which are supported by the operating system. Invalid characters are replaced by an underscore (\_).
  - ▶ **Attention:** This name cannot be changed later on.
- Confirm the dialog by clicking on the **OK** button. The configuration dialog for the selected driver is opened.

**Note:** The language of driver names cannot be switched. They are always shown in the language in which they have been created, regardless of the language of the Editor. This also applies to driver object types.

### DRIVER NAME DIALOG ALREADY EXISTS

If there is already a driver in the project, this is shown in a dialog. The warning dialog is closed by clicking on the **OK** button. The driver can be named correctly.



### ZENON PROJECT

The following drivers are created automatically for newly-created projects:

- ▶ **Intern**
- ▶ **MathDr32**
- ▶ **SysDrv**

#### **Information**


Only the required drivers need to be present in a zenon project. Drivers can be added at a later time if required.

## 6.2 Settings in the driver dialog

You can change the following settings of the driver:

## 6.2.1 General

The configuration dialog is opened when a driver is created. In order to be able to open the dialog later for editing, double click on the driver in the list or click on the **Configuration** property.



Option	Description
<p><b>Mode</b></p>	<p>Allows to switch between hardware mode and simulation mode</p> <ul style="list-style-type: none"> <li>▶ <i>Hardware:</i> A connection to the control is established.</li> <li>▶ <i>Simulation - static:</i> No communication between to the control is established, the values are simulated by the driver. In this modus the values remain constant or the variables keep the values which were set by zenon Logic. Each variable has its own memory area. E.g. two variables of the type marker with offset 79 can have different values in the Runtime and do not influence each other. Exception: The simulator driver.</li> <li>▶ <i>Simulation - counting:</i> No communication between to the control is established, the values are simulated by the driver. In this modus the driver increments the values within a value range automatically.</li> <li>▶ <i>Simulation - programmed:</i> No communication is established to the PLC. The</li> </ul>

Option	Description
	<p>values are calculated by a freely programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in a zenon Logic Runtime which is integrated in the driver.</p> <p>For details see chapter Driver simulation.</p>
<p><b>Keep update list in the memory</b></p>	<p>Variables which were requested once are still requested from the control even if they are currently not needed. This has the advantage that e.g. multiple screen switches after the screen was opened for the first time are executed faster because the variables need not be requested again. The disadvantage is a higher load for the communication to the control.</p>
<p><b>Output can be written</b></p>	<ul style="list-style-type: none"> <li>▶ <i>Active:</i> Outputs can be written.</li> <li>▶ <i>Inactive:</i> Writing of outputs is prevented.</li> </ul> <p><b>Note:</b> Not available for every driver.</p>
<p><b>Variable image remanent</b></p>	<p>This option saves and restores the current value, time stamp and the states of a data point.</p> <p>Fundamental requirement: The variable must have a valid value and time stamp.</p> <p>The variable image is saved in hardware mode if one of these statuses is active:</p> <ul style="list-style-type: none"> <li>▶ User status <i>M1 (0) to M8 (7)</i></li> <li>▶ <i>REVISION(9)</i></li> <li>▶ <i>AUS(20)</i></li> <li>▶ <i>ERSATZWERT(27)</i></li> </ul> <p>The variable image is always saved if:</p> <ul style="list-style-type: none"> <li>▶ the variable is of the <b>Communication details</b> object type</li> <li>▶ the driver runs in simulation mode. (not programmed simulation)</li> </ul> <p>The following states are not restored at the start of the Runtime:</p>

Option	Description
	<ul style="list-style-type: none"> <li>▶ <i>SELECT(8)</i></li> <li>▶ <i>WR-ACK(40)</i></li> <li>▶ <i>WR-SUC(41)</i></li> </ul> <p>The mode <b>Simulation - programmed</b> at the driver start is not a criterion in order to restore the remanent variable image.</p>
<p><b>Stop on Standby Server</b></p>	<p>Setting for redundancy at drivers which allow only one communication connection. For this the driver is stopped at the Standby Server and only started at the upgrade.</p> <p><b>Attention:</b> If this option is active, the gapless archiving is no longer guaranteed.</p> <ul style="list-style-type: none"> <li>▶ <i>Active:</i> Sets the driver at the not-process-leading Server automatically in a stop-like state. In contrast to stopping via driver command, the variable does not receive status <b>switched off</b> but an empty value. This prevents that at the upgrade to the Server irrelevant values are created in the AML, CEL and Historian.</li> </ul> <p>Default: <i>inactive</i></p> <p><b>Note:</b> Not available if the CE terminal serves as a data server. You can find further information in the zenon Operator manual in the CE terminal as a data server chapter.</p>
<p><b>Global Update time</b></p>	<p>Setting for the global update times in milliseconds:</p> <ul style="list-style-type: none"> <li>▶ <i>Active:</i> The set <b>Global update time</b> is used for all variables in the project. The priority set at the variables is not used.</li> <li>▶ <i>Inactive:</i> The set priorities are used for the individual variables.</li> </ul> <p><b>Exceptions:</b> Spontaneous drivers ignore this option. They generally use the shortest possible update time. For details, see the <b>Spontaneous driver update time</b> section.</p>

Option	Description
<b>Priority</b>	<p>The polling times for the individual priority classes are set here. All variables with the according priority are polled in the set time.</p> <p>The variables are allocated separately in the settings of the variable properties.</p> <p>The communication of the individual variables can be graded according to importance or required topicality using the priority classes. Thus the communication load is distributed better.</p> <p><b>Attention:</b> Priority classes are not supported by each driver, e.g. spontaneously communicating zenon drivers.</p>

#### CLOSE DIALOG


Option	Description
<b>OK</b>	Applies all changes in all tabs and closes the dialog.
<b>Cancel</b>	Discards all changes in all tabs and closes the dialog.
<b>Help</b>	Opens online help.

#### UPDATE TIME FOR SPONTANEOUS DRIVERS

With spontaneous drivers, for **Set value, advising** of variables and **Requests**, a read cycle is triggered immediately - regardless of the set update time. This ensures that the value is immediately available for visualization after writing. The update time is generally 100 ms.

Spontaneous drivers are **ArchDrv**, **BiffiDCM**, **BrTcp32**, **DNP3**, **Esser32**, **FipDrv32**, **FpcDrv32**, **IEC850**, **IEC870**, **IEC870\_103**, **Otis**, **RTK9000**, **S7DCOS**, **SAIA\_Slave**, **STRATON32** and **Trend32**.

## 6.2.2 Connections



Parameter	Description
<b>Connection name</b>	Freely-configurable name for the controller
<b>New</b>	Creates a new connection with default settings. The properties of the connection are unlocked for project configuration.
<b>Edit</b>	Opens the selected connection for editing. The properties of the connection are unlocked for the project configuration.
<b>Delete</b>	The selected connection is deleted without requesting confirmation.
<b>Net address</b>	<p>Unique address of the PLC in the network.</p> <p>The net address identifies the connection. Each connection requires a unique net address. The net address configured here must also be configured accordingly for the variables that want to use this connection. This net address is not required for communication with the PLC.</p>
<b>IP adress</b>	IPv4 address of the controller.
<b>Port Number</b>	Number of the TCP port of the PLC.

Parameter	Description
	Default: 11113
<b>User name</b>	User name for the user who has been configured in the controller for access to the third-party system.  <b>Note:</b> Capitalization of letters must be taken into account during project configuration.
<b>Password</b>	Password for the user who has been configured in the controller for access to the third-party system.  Capitalization must be taken into account.
<b>Directly Connected Network</b>	The address of the headquarters to which the connection is established.
<b>Save</b>	Saves a new or edited connection.
<b>Cancel</b>	Ends the editing of the connection properties. Amended project configurations of the connection to be processed are not saved.

#### CLOSE DIALOG

Option	Description
<b>OK</b>	Applies all changes in all tabs and closes the dialog.
<b>Cancel</b>	Discards all changes in all tabs and closes the dialog.
<b>Help</b>	Opens online help.

## 7 Creating variables

This is how you can create variables in the zenon Editor:

### 7.1 Creating variables in the Editor

Variables can be created:


- ▶ as simple variables

- ▶ in arrays
- ▶ as structure variables

### VARIABLE DIALOG

To create a new variable, regardless of which type:


1. Select the **New variable** command in the **Variables** node in the context menu



The dialog for configuring variables is opened

2. Configure the variable
3. The settings that are possible depend on the type of variables

## CREATE VARIABLE DIALOG



Property	Description
<b>Name</b>	<p>Distinct name of the variable. If a variable with the same name already exists in the project, no additional variable can be created with this name.</p> <p>Maximum length: 128 characters</p> <p><b>Attention:</b> the characters # and @ are not permitted in variable names. If non-permitted characters are used, creation of variables cannot be completed and the <b>Finish</b> button remains inactive.</p> <p><b>Note:</b> Some drivers also allow addressing using the <b>Symbolic address</b> property.</p>
<b>Driver</b>	<p>Select the desired driver from the drop-down list.</p> <p><b>Note:</b> If no driver has been opened in the project, the driver for internal variables (<b>Intern.exe</b>) is automatically loaded.</p>
<b>Driver Object Type</b>	<p>Select the appropriate driver object type from the drop-down list.</p>
<b>Data Type</b>	<p>Select the desired data type. Click on the ... button to open the selection dialog.</p>
<b>Array settings</b>	<p>Expanded settings for array variables. You can find details in the</p>

Property	Description
	Arrays chapter.
<b>Addressing options</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.
<b>Automatic element activation</b>	Expanded settings for arrays and structure variables. You can find details in the respective section.

## SYMBOLIC ADDRESS

The **Symbolic address** property can be used for addressing as an alternative to the **Name** or **Identification** of the variables. Selection is made in the driver dialog; configuration is carried out in the variable property. When importing variables of supported drivers, the property is entered automatically.

Maximum length: 1024 characters.

The following drivers support the **Symbolic address**:

- ▶ 3S\_V3
- ▶ AzureDrv
- ▶ BACnetNG
- ▶ IEC850
- ▶ KabaDPSTServer
- ▶ OPCUA32
- ▶ Phoenix32
- ▶ POZYTON
- ▶ RemoteRT
- ▶ S7TIA
- ▶ SEL
- ▶ SnmpNg32
- ▶ PA\_Drv
- ▶ EUROMAP63

## INHERITANCE FROM DATA TYPE

**Measuring range**, **Signal range** and **Set value** are always:

- ▶ derived from the datatype
- ▶ Automatically adapted if the data type is changed

**Note for signal range:** If a change is made to a data type that does not support the set **signal range**, the **signal range** is amended automatically. For example, for a change from **INT** to **SINT**, the **signal range** is changed to 127. The amendment is also carried out if the **signal range** was not inherited from the data type. In this case, the **measuring range** must be adapted manually.

## 7.2 Addressing

Variables for the **ISPIP driver** must be created and addressed manually.

Group/Property	Description
<b>General</b>	
<b>Name</b>	Freely definable name. Attention: For every zenon project the name must be unambiguous.
<b>Identification</b>	Freely assignable identification, e.g. for resources label, comment ...
<b>Addressing</b>	
<b>Net address</b>	Bus address or net address of the variable.  This address refers to the bus address in the connection configuration of the driver. This defines the PLC, on which the variable resides.
<b>Data block</b>	not used for this driver
<b>Offset</b>	not used for this driver
<b>Alignment</b>	not used for this driver
<b>Bit number</b>	not used for this driver
<b>String length</b>	not used for this driver
<b>Driver connection/Driver Object Type</b>	Object type of the variables. Depending on the driver used, is selected when the variable is created and can be changed here.
<b>Driver connection/Data Type</b>	Data type of the variable. Is selected during the creation of the variable; the type can be changed here.  <b>Attention:</b> If the data type is subsequently changed, all other properties of the variable must be checked and adjusted.
<b>ISIPNetworkNumber</b>	The number of the main control center or area control center.
<b>ISPIPElementType</b>	Selection of the main element type. Select from drop-down list.

Group/Property	Description
<b>ISPIPElementSubType_ST</b>	Selection of the subelement type from a drop-down list. For variables of the <i>state</i> driver object type. The selection via a drop-down list depends on the selected main element type
<b>ISPIPElementNumber</b>	The element number in the network.
<b>ISPIPElementSubNumber</b>	The subelement number of the element.
<b>ISPIPElementSubType_AV</b>	For <i>analog value</i> driver object type variables. Selection of the analog value from a drop-down list.  Note: Not all detectors support all analog values. The main element type ( <b>ISPIPElementType_AV</b> variable property) is fixed to "Zone" (detector group).
<b>ISPIPElementSubType_CMD</b>	For variables of the <i>command</i> driver object type.  Note: Not all elements support all command types.

## 7.3 Driver objects and datatypes

Driver objects are areas available in the PLC, such as markers, data blocks etc. Here you can find out which driver objects are provided by the driver and which IEC data types can be assigned to the respective driver objects.

### 7.3.1 Driver objects

The following object types are available in this driver:

Driver Object Type	Channel type	Read	Write	Supported data types	Description
<b>Status</b>	66	X	--	WORD	Driver object type for status values.  ▶ The higher 8 bits constitute the main

Driver Object Type	Channel type	Read	Write	Supported data types	Description
					<p>status of the element.</p> <ul style="list-style-type: none"> <li>▶ The lower 8 bits constitute the substatus of the element.</li> </ul> <p>The value is initialized in runtime with the value 0 and the status SPONT. The driver only receives communication from the PLC (BMZ-integral) in the response to a sum query, only the status values that differ from the normal status.</p>
<b>Analog Value</b>	65	X	--	<i>SINT</i>	<p>Driver object type for analog values.</p> <p>The transfer of analog values is spontaneous. The transfer is activated by analog values after the driver is started.</p>
<b>Command</b>	67	X	X	<i>WORD</i>	<p>Driver object type for commands.</p> <p>The successful execution of the BMZ-Integral is confirmed depending on the type of command:</p> <ul style="list-style-type: none"> <li>▶ By a response to the command or</li> <li>▶ by means of a status change of the element</li> </ul> <p>The command is executed after successful communication of</p>

Driver Object Type	Channel type	Read	Write	Supported data types	Description
					this status change.
<i>Communication details</i>	35	X	X	<i>BOOL, SINT, USINT, INT, UINT, DINT, UDINT, REAL, STRING</i>	<p>Variables for the static analysis of the communication; is transferred between driver and Runtime (not to the PLC).</p> <p><b>Note:</b> The addressing and the behavior is the same for most zenon drivers.</p> <p>You can find detailed information on this in the Communication details (Driver variables) (on page 33) chapter.</p>

**Key:**

X: supported

--: not supported

**CHANNEL TYPE**

The term **Kanaltyp** is the internal numerical name of the driver object type. It is also used for the extended DBF import/export of the variables.

"**Kanaltyp**" is used for advanced CSV import/export of variables in the "**HWOBJECTTYPE**" column.

**7.3.2 Mapping of the data types**

All variables in zenon are derived from IEC data types. The following table compares the IEC datatypes with the datatypes of the PLC.

PLC	zenon	Data type
-	BOOL	8
-	USINT	9

PLC	zenon	Data type
Analog value	SINT	10
-	UINT	2
-	INT	1
-	UDINT	4
-	DINT	3
-	ULINT	27
-	LINT	26
-	REAL	5
-	LREAL	6
-	STRING	12
-	WSTRING	21
-	DATE	18
-	TIME	17
-	DATE_AND_TIME	20
-	TOD (Time of Day)	19
Status messages, commands	WORD	23

## DATA TYPE

The term **data type** is the internal numerical identification of the data type. It is also used for the extended DBF import/export of the variables.

## 7.4 Creating variables by importing

Variables can also be imported by importing them. The XML and DBF import is available for every driver.



## Information

You can find details on the import and export of variables in the Import-Export manual in the Variables section.

### 7.4.1 XML import

During XML import of variables or data types, these are first assigned to a driver and then analyzed. Before import, the user decides whether and how the respective element (variable or data type) is to be imported:

- ▶ *Import:*  
The element is imported as a new element.
- ▶ *Overwrite:*  
The element is imported and overwrites a pre-existing element.
- ▶ *Do not import:*  
The element is not imported.

**Note:** The actions and their durations are shown in a progress bar during import. The import of variables is described in the following documentation. Data types are imported along the same lines.

## REQUIREMENTS

The following conditions are applicable during import:

- ▶ **Backward compatibility**  
At the XML import/export there is no backward compatibility. Data from older zenon versions can be taken over. The handover of data from newer to older versions is not supported.
- ▶ **Consistency**  
The XML file to be imported has to be consistent. There is no plausibility check on importing the file. If there are errors in the import file, this can lead to undesirable effects in the project.  
Particular attention must be paid to this, primarily if not all properties exist in the XML file and these are then filled with default values. E.g.: A binary variable has a limit value of 300.
- ▶ **Structure data types**  
Structure data types must have the same number of structure elements.  
Example: A structure data type in the project has 3 structure elements. A data type with the same name in the XML file has 4 structure elements. Then none of the variables based on this data type in the file are imported into the project.

 **Hint**

You can find further information on XML import in the **Import - Export** manual, in the **XML import** chapter.

## 7.4.2 DBF Import/Export

Data can be exported to and imported from dBase.

 **Information**

Import and Export via CSV or dBase supported; no driver specific variable settings, such as formulas. Use export/import via XML for this.

### IMPORT DBF FILE

To start the import:

1. right-click on the variable list.
2. In the drop-down list of **Extended export/import...** select the **Import dBase** command.
3. Follow the instructions of the import assistant.

The format of the file is described in the chapter File structure.

 **Information**

Note:

- ▶ Driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.
- ▶ dBase does not support structures or arrays (complex variables) at import.

### EXPORT DBF FILE

To start the export:

1. right-click on the variable list.
2. In the drop-down list of **Extended export/import...** select the **Export dBase...** command .
3. Follow the instructions of the import assistant.

**⚠ Attention**

DBF files:

- ▶ must correspond to the 8.3 DOS format for filenames (8 alphanumeric characters for name, 3 character suffix, no spaces)
- ▶ must not have dots (.) in the path name.  
e.g. the path `C:\users\John.Smith\test.dbf` is invalid.  
Valid: `C:\users\JohnSmith\test.dbf`
- ▶ must be stored close to the root directory in order to fulfill the limit for file name length including path: maximum 255 characters

The format of the file is described in the chapter File structure.

**💡 Information**

dBase does not support structures or arrays (complex variables) at export.

## FILE STRUCTURE OF THE DBASE EXPORT FILE

The dBaseIV file must have the following structure and contents for variable import and export:

**⚠ Attention**

dBase does not support structures or arrays (complex variables) at export.

DBF files must:

- ▶ conform with their name to the 8.3 DOS format (8 alphanumeric characters for name, 3 characters for extension, no space)
- ▶ Be stored close to the root directory (Root)

## STRUCTURE

Identification	Type	Field size	Comment
KANALNAME	Character	128	Variable name. The length can be limited using the <b>MAX_LAENGE</b> entry in the <b>project.ini</b> file.
KANAL_R	C	128	The original name of a variable that is to be replaced by the new name entered under "VARIABLENNAME" (variable name) (field/column must be entered

Identification	Type	Field size	Comment
			manually). The length can be limited using the <b>MAX_LAENGE</b> entry in the <b>project.ini</b> file.
<b>KANAL_D</b>	Log	1	The variable is deleted with the 1 entry (field/column has to be created by hand).
<b>TAGNR</b>	C	128	Identification. The length can be limited using the <b>MAX_LAENGE</b> entry in the <b>project.ini</b> file.
<b>EINHEIT</b>	C	11	Technical unit
<b>DATENART</b>	C	3	Data type (e.g. bit, byte, word, ...) corresponds to the data type.
<b>KANALTYP</b>	C	3	Memory area in the PLC (e.g. marker area, data area, ...) corresponds to the driver object type.
<b>HWKANAL</b>	Num	3	Net address
<b>BAUSTEIN</b>	N	3	Datablock address (only for variables from the data area of the PLC)
<b>ADRESSE</b>	N	5	Offset
<b>BITADR</b>	N	2	For bit variables: bit address For byte variables: 0=lower, 8=higher byte For string variables: Length of string (max. 63 characters)
<b>ARRAYSIZE</b>	N	16	Number of variables in the array for index variables ATTENTION: Only the first variable is fully available. All others are only available for VBA or the Recipegroup Manager
<b>LES_SCHR</b>	L	1	Write-Read-Authorization 0: Not allowed to set value. 1: Allowed to set value.
<b>MIT_ZEIT</b>	R	1	time stamp in zenon (only if supported by the driver)
<b>OBJEKT</b>	N	2	Driver-specific ID number of the primitive object comprises TREIBER-OBJEKTYP and DATENTYP

Identification	Type	Field size	Comment
<b>SIGMIN</b>	Float	16	Non-linearized signal - minimum (signal resolution)
<b>SIGMAX</b>	F	16	Non-linearized signal - maximum (signal resolution)
<b>ANZMIN</b>	F	16	Technical value - minimum (measuring range)
<b>ANZMAX</b>	F	16	Technical value - maximum (measuring range)
<b>ANZKOMMA</b>	N	1	Number of decimal places for the display of the values (measuring range)
<b>UPDATERATE</b>	F	19	Update rate for mathematics variables (in sec, one decimal possible) not used for all other variables
<b>MEMTIEFE</b>	N	7	Only for compatibility reasons
<b>HDRATE</b>	F	19	HD update rate for historical values (in sec, one decimal possible)
<b>HDTIEFE</b>	N	7	HD entry depth for historical values (number)
<b>NACHSORT</b>	R	1	HD data as postsorted values
<b>DRRATE</b>	F	19	Updating to the output (for zenon DDE server, in [s], one decimal possible)
<b>HYST_PLUS</b>	F	16	Positive hysteresis, from measuring range
<b>HYST_MINUS</b>	F	16	Negative hysteresis, from measuring range
<b>PRIOR</b>	N	16	Priority of the variable
<b>REAMATRIZE</b>	C	32	Allocated reaction matrix
<b>ERSATZWERT</b>	F	16	Substitute value, from measuring range
<b>SOLLMIN</b>	F	16	Minimum for set value actions, from measuring range
<b>SOLLMAX</b>	F	16	Maximum for set value actions, from measuring range
<b>VOMSTANDBY</b>	R	1	Get value from standby server; the value of the variable is not requested from the server but from the Standby Server in redundant networks
<b>RESOURCE</b>	C	128	Resources label. Free string for export and display in lists.

Identification	Type	Field size	Comment
			The length can be limited using the MAX_LAENGE entry in <b>project.ini</b> .
ADJWVBA	R	1	Non-linear value adaption: 0: Non-linear value adaption is used 1: Non-linear value adaption is not used
ADJZENON	C	128	Linked VBA macro for reading the variable value for non-linear value adjustment.
ADJWVBA	C	128	ed VBA macro for writing the variable value for non-linear value adjustment.
ZWREMA	N	16	Linked counter REMA.
MAXGRAD	N	16	Gradient overflow for counter REMA.

### Attention

When importing, the driver object type and data type must be amended to the target driver in the DBF file in order for variables to be imported.

## LIMIT VALUE DEFINITION

Limit definition for limit values 1 to 4, or status 1 to 4:

Identification	Type	Field size	Comment
AKTIV1	R	1	Limit value active (per limit value available)
GRENZWERT1	F	20	technical value or ID number of a linked variable for a dynamic limit value (see VARIABLEx) (if VARIABLEx is 1 and here it is -1, the existing variable linkage is not overwritten)
SCHWWERT1	F	16	Threshold value for limit value
HYSTERESE1	F	14	Is not used
BLINKEN1	R	1	Set blink attribute
BTB1	R	1	Logging in CEL
ALARM1	R	1	Alarm

Identification	Type	Field size	Comment
DRUCKEN1	R	1	Printer output (for CEL or Alarm)
QUITTIER1	R	1	Must be acknowledged
LOESCHE1	R	1	Must be deleted
VARIABLE1	R	1	Dyn. limit value linking the limit is defined by an absolute value (see field GRENZWERTx).
FUNC1	R	1	Functions linking
ASK_FUNC1	R	1	Execution via Alarm Message List
FUNC_NR1	N	10	ID number of the linked function (if "-1" is entered here, the existing function is not overwritten during import)
A_GRUPPE1	N	10	Alarm/Event Group
A_KLASSE1	N	10	Alarm/Event Class
MIN_MAX1	C	3	Minimum, Maximum
FARBE1	N	10	Color as Windows coding
GRENZTXT1	C	66	Limit value text
A_DELAY1	N	10	Time delay
INVISIBLE1	R	1	Invisible

Expressions in the column "Comment" refer to the expressions used in the dialog boxes for the definition of variables. For more information, see chapter Variable definition.

## 7.5 Communication details (Driver variables)

The driver kit implements a number of driver variables. These variables are part of the driver object type *Communication details*. These are divided into:

- ▶ Information
- ▶ Configuration
- ▶ Statistics and
- ▶ Error message

The definitions of the variables implemented in the driver kit are available in the import file **DRVVAR.DBF** and can be imported from there.

Path to file: %ProgramData%\COPA-DATA\zenon<Versionsnummer>\PredefinedVariables

**Note:** Variable names must be unique in zenon. If driver variables of the driver object type *Communication details* are to be imported from **DRVVAR.DBF** again, the variables that were imported beforehand must be renamed.

 **Information**

Not every driver supports all driver variables of the driver object type *Communication details*.

For example:

- ▶ Variables for modem information are only supported by modem-compatible drivers.
- ▶ Driver variables for the polling cycle are only available for pure polling drivers.
- ▶ Connection-related information such as **ErrorMSG** is only supported for drivers that only edit one connection at a time.

**INFORMATION**

Name from import	Type	Offset	Description
MainVersion	UINT	0	Main version number of the driver.
SubVersion	UINT	1	Sub version number of the driver.
BuildVersion	UINT	29	Build version number of the driver.
RTMajor	UINT	49	zenon main version number
RTMinor	UINT	50	zenon sub version number
RTSp	UINT	51	zenon Service Pack number
RTBuild	UINT	52	zenon build number
LineStateIdle	BOOL	24.0	TRUE, if the modem connection is idle
LineStateOffering	BOOL	24.1	TRUE, if a call is received
LineStateAccepted	BOOL	24.2	The call is accepted
LineStateDialtone	BOOL	24.3	Dialtone recognized
LineStateDialing	BOOL	24.4	Dialing active

Name from import	Type	Offset	Description
LineStateRingBack	BOOL	24.5	While establishing the connection
LineStateBusy	BOOL	24.6	Target station is busy
LineStateSpecialInfo	BOOL	24.7	Special status information received
LineStateConnected	BOOL	24.8	Connection established
LineStateProceeding	BOOL	24.9	Dialing completed
LineStateOnHold	BOOL	24.10	Connection in hold
LineStateConferenced	BOOL	24.11	Connection in conference mode.
LineStateOnHoldPendConf	BOOL	24.12	Connection in hold for conference
LineStateOnHoldPendTransfer	BOOL	24.13	Connection in hold for transfer
LineStateDisconnected	BOOL	24.14	Connection terminated.
LineStateUnknow	BOOL	24.15	Connection status unknown
ModemStatus	UDINT	24	Current modem status
TreiberStop	BOOL	28	Driver stopped  For <i>driver stop</i> , the variable has the value <i>TRUE</i> and an <b>OFF</b> bit. After the driver has started, the variable has the value <i>FALSE</i> and no <b>OFF</b> bit.
SimulRTState	UDINT	60	Informs the state of Runtime for driver simulation.
ConnectionStates	STRING	61	Internal connection status of the driver to the PLC.  Connection statuses: <ul style="list-style-type: none"> <li>▶ 0: Connection OK</li> <li>▶ 1: Connection failure</li> <li>▶ 2: Connection simulated</li> </ul> Formatting: <Net address>:<Connection status>;...;...; A connection is only known after a variable

Name from import	Type	Offset	Description
			<p>has first signed in. In order for a connection to be contained in a string, a variable of this connection must be signed in once.</p> <p>The status of a connection is only updated if a variable of the connection is signed in. Otherwise there is no communication with the corresponding controller.</p>

## CONFIGURATION

Name from import	Type	Offset	Description
ReconnectInRead	<i>BOOL</i>	27	If TRUE, the modem is automatically reconnected for reading
ApplyCom	<i>BOOL</i>	36	Apply changes in the settings of the serial interface. Writing to this variable immediately results in the method SrvDrvVarApplyCom being called (which currently has no further function).
ApplyModem	<i>BOOL</i>	37	Apply changes in the settings of the modem. Writing this variable immediately calls the method SrvDrvVarApplyModem. This closes the current connection and opens a new one according to the settings <b>PhoneNumberSet</b> and <b>ModemHwAdrSet</b> .
PhoneNumberSet	<i>STRING</i>	38	Telephone number, that should be used
ModemHwAdrSet	<i>DINT</i>	39	Hardware address for the telephone number
GlobalUpdate	<i>UDINT</i>	3	Update time in milliseconds (ms).
BGlobalUpdaten	<i>BOOL</i>	4	TRUE, if update time is global
TreiberSimul	<i>BOOL</i>	5	TRUE, if driver in sin simulation mode
TreiberProzab	<i>BOOL</i>	6	TRUE, if the variables update list should be kept in the memory
ModemActive	<i>BOOL</i>	7	TRUE, if the modem is active for the driver
Device	<i>STRING</i>	8	Name of the serial interface or name of the modem

Name from import	Type	Offset	Description
ComPort	<i>UINT</i>	9	Number of the serial interface.
Baudrate	<i>UDINT</i>	10	Baud rate of the serial interface.
Parity	<i>SINT</i>	11	Parity of the serial interface
ByteSize	<i>USINT</i>	14	Number of bits per character of the serial interface  Value = 0 if the driver cannot establish any serial connection.
StopBit	<i>USINT</i>	13	Number of stop bits of the serial interface.
Autoconnect	<i>BOOL</i>	16	TRUE, if the modem connection should be established automatically for reading/writing
PhoneNumber	<i>STRING</i>	17	Current telephone number
ModemHwAdr	<i>DINT</i>	21	Hardware address of current telephone number
RxIdleTime	<i>UINT</i>	18	Modem is disconnected, if no data transfer occurs for this time in seconds (s)
WriteTimeout	<i>UDINT</i>	19	Maximum write duration for a modem connection in milliseconds (ms).
RingCountSet	<i>UDINT</i>	20	Number of ringing tones before a call is accepted
ReCallIdleTime	<i>UINT</i>	53	Waiting time between calls in seconds (s).
ConnectTimeout	<i>UINT</i>	54	Time in seconds (s) to establish a connection.

## STATISTICS

Name from import	Type	Offset	Description
MaxWriteTime	<i>UDINT</i>	31	The longest time in milliseconds (ms) that is required for writing.
MinWriteTime	<i>UDINT</i>	32	The shortest time in milliseconds (ms) that is required for writing.
MaxBlkReadTime	<i>UDINT</i>	40	Longest time in milliseconds (ms) that is required to read a data block.

Name from import	Type	Offset	Description
MinBlkReadTime	UDINT	41	Shortest time in milliseconds (ms) that is required to read a data block.
WriteErrorCount	UDINT	33	Number of writing errors
ReadSucceedCount	UDINT	35	Number of successful reading attempts
MaxCycleTime	UDINT	22	Longest time in milliseconds (ms) required to read all requested data.
MinCycleTime	UDINT	23	Shortest time in milliseconds (ms) required to read all requested data.
WriteCount	UDINT	26	Number of writing attempts
ReadErrorCount	UDINT	34	Number of reading errors
MaxUpdateTimeNormal	UDINT	56	Time since the last update of the priority group <b>Normal</b> in milliseconds (ms).
MaxUpdateTimeHigher	UDINT	57	Time since the last update of the priority group <b>Higher</b> in milliseconds (ms).
MaxUpdateTimeHigh	UDINT	58	Time since the last update of the priority group <b>High</b> in milliseconds (ms).
MaxUpdateTimeHighest	UDINT	59	Time since the last update of the priority group <b>Highest</b> in milliseconds (ms).
PokeFinish	BOOL	55	Goes to 1 for a query, if all current pokes were executed

## ERROR MESSAGE

Name from import	Type	Offset	Description
ErrorTimeDW	UDINT	2	Time (in seconds since 1.1.1970), when the last error occurred.
ErrorTimeS	STRING	2	Time (in seconds since 1.1.1970), when the last error occurred.
RdErrPrimObj	UDINT	42	Number of the PrimObject, when the last reading error occurred.
RdErrStationsName	STRING	43	Name of the station, when the last reading error occurred.

Name from import	Type	Offset	Description
RdErrBlockCount	<i>UINT</i>	44	Number of blocks to read when the last reading error occurred.
RdErrHwAdresse	<i>DINT</i>	45	Hardware address when the last reading error occurred.
RdErrDatablockNo	<i>UDINT</i>	46	Block number when the last reading error occurred.
RdErrMarkerNo	<i>UDINT</i>	47	Marker number when the last reading error occurred.
RdErrSize	<i>UDINT</i>	48	Block size when the last reading error occurred.
DrvError	<i>USINT</i>	25	Error message as number
DrvErrorMsg	<i>STRING</i>	30	Error message as text
ErrorFile	<i>STRING</i>	15	Name of error log file

## 8 Driver-specific functions

Status messages and analog values constitute driver-specific functions.

You can find detailed information about this in the corresponding chapter.

### 8.1 Status messages

Status messages are communicated via **ISP-IP CAMP** protocol.

- ▶ After communication to the PLC has been established successfully, the driver sends a sum query to the control center that communicates with the driver. This query is applicable for all elements and all connected control centers.
- ▶ In the response, the driver receives all status messages that differ from the normal status.
- ▶ *Status* driver object variables for which no different status has been received are initialized with the main status 0 and sub-status 0 (**IDLE**). This corresponds to the variable value 0. The variable status is set to *SPONT* in the process. The driver implements a shadow image. If a different value is received when communication is started, this value is saved in the shadow image. The first time the variable is used in Runtime, it gets a different value from the shadow image.
- ▶ Status messages are bit-orientated:
  - ▶ The higher 8 bits constitute the main status.

- ▶ The lower 8 bits constitute the substatus.

The general activation of an output is thus displayed as the decimal value 3072. This corresponds to the value 0x0C 00 in hexadecimal.

Main status activation output: *decimal 12*

Substatus of general activation output: *decimal 0*

## 8.2 Analog value

Analog values are communicated using the ISP-IP AVP protocol.

- ▶ After communication has been established, the driver activates the spontaneous transfer of analog values. This is applicable for all elements of all connected control centers.
- ▶ The analog values are received consecutively by the driver and are saved in the shadow image.
- ▶ The first time the variable is used in Runtime, it gets the value from the shadow image.
- ▶ The analog values that can be sent depend on the element type. Not all element type support, for example, a value for CO.

## 8.3 Commands

The following is applicable for commands:

- ▶ Commands are communicated using the **ISP-IP CAMP** protocol.
- ▶ To send a command to an element, a command variable with the corresponding addressing must be created in the zenon project.
- ▶ In zenon Runtime, a command variable with an idle value of 0xFFFF is initialized.
- ▶ The command is initiated by writing the command value to the variable.
- ▶ At protocol level, a successful command can be acknowledged either with a response or with the status change of the element.
- ▶ If there is no response to a command and there is no status change of the element, this leads to a time overrun (= **Timeout**).
- ▶ To show the result of a command, the status of the command variable itself is shown.

A command to a sub center element is already filtered by the central control, if there is no authorization. In this case, there is no negative response from the central control, the command execution times out.

If a command does not lead to a state change or there is no (negative) command acknowledgment, it should be checked whether the element supports the corresponding command and whether the authorization for the process control system is available in the authorization macro in the main control. For the sub-control center, the authorization macro for the main control must contain the corresponding authorization.

### 8.3.1 Set value for commands

A set value for a command comprises the command number and the command value (*Validity*). In doing so, the command number occupies the higher bytes. The command value (*Validity*) occupies the lower bytes. Not all command combinations are valid.

You can find the possible combinations of commands numbers and the attendant command values in the Supported Commands (on page 41) chapter. Not all commands are supported by all elements.

#### EXAMPLE 1

*ElementTypeClass Output, FunctionType Self, Off, General*

*Set value for the command variable: 0x0000*

**CommandNumber:** *Off (0)*

**Validity:** *Switch off (0)*

#### EXAMPLE 2

*ElementTypeClass Output, FunctionType Self, On, Acoustic*

*Set value for the command variable: 0x0101*

**CommandNumber:** *On (1)*

**Validity:** *Turn on acoustics (1)*

### 8.3.2 Supported commands

The **ISPIP driver** supports command combinations in accordance with the **N3 CAMP** specification. Note that not all element types support all commands.

You can find information on the respective **ElementTypeClass** in the corresponding table. The actual command number and validity number are included in the table.

Note that the Validity**Acoustic** has a different value, depending on the command number.

Command value for Zone, **FunctionType Self, Off, General** 0x0000 (decimal 0)

Command value for Zone, **FunctionType Self, On, Emergency** 0x0103 (decimal 259)

**ZONE**

FunctionType	CommandNumber	Validity	
Self	Off (0)	General (0) Emergency (3) Limited (5)	
	On (1)	General (0) Emergency (3) AtTime (5)	
	Reset (3)	General (0) Alarm (1)	
	Revision (4)	General (0)	
	Check (5)	General (0)	
	SimulateAlarm (6)	General (0)	
	SimulateFault (7)	General (0)	
	OffInternal (9)	General (0)	
	SilentRevision (17)	General (0)	
	RevisionCheck (18)	General (0)	
	Pollution	Reset (3)	General (0)

**INPUT**

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
	On (1)	General (0)
	Reset (3)	General (0)
	Revision (4)	General (0)
	SimulateFault (7)	General (0)

FunctionType	CommandNumber	Validity
	<b>SimulateActive (8)</b>	<i>General (0)</i>
	<b>SimulatePreActive (16)</b>	<i>General (0)</i>
	<b>SilentRevision (17)</b>	<i>General (0)</i>

**OUTPUT**

FunctionType	CommandNumber	Validity
<b>Self</b>	<b>Off (0)</b>	<i>General (0)</i> <i>Acoustic (1)</i> <i>FireProtectionEquipment (2)</i>
	<b>On (1)</b>	<i>General (0)</i> <i>Acoustic (1)</i> <i>FireProtectionEquipment (2)</i>
	<b>Set (2)</b>	<i>General (0)</i> <i>Critical (1)</i>
	<b>Reset (3)</b>	<i>General (0)</i> <i>Acoustic (2)</i>
	<b>Revision (4)</b>	<i>General (0)</i>
	<b>SimulateFault (7)</b>	<i>General (0)</i>
	<b>Reactivate (10)</b>	<i>General (0)</i> <i>Acoustic (1)</i>
<b>Acknowledge</b>	-	-

**EXTERNAL**

FunctionType	CommandNumber	Validity
<b>Self</b>	<b>Off (0)</b>	<i>General (0)</i> <i>Emergency (3)</i>
	<b>On (1)</b>	<i>General (0)</i>

FunctionType	CommandNumber	Validity
		<i>Emergency (3)</i>
	<b>Set (2)</b>	<i>General (0)</i>
	<b>Reset (3)</b>	<i>General (0)</i> <i>Alarm (1)</i>
	<b>Revision (4)</b>	<i>General (0)</i>
	<b>SimulateAlarm (6)</b>	<i>General (0)</i>
	<b>SimulateFault (7)</b>	<i>General (0)</i>

**PRINTER**

FunctionType	CommandNumber	Validity
<b>Self</b>	<b>Off (0)</b>	<i>General (0)</i> <i>PaperFeed (4)</i>
	<b>On (1)</b>	<i>General (0)</i> <i>PaperFeed (4)</i>
	<b>Reset (3)</b>	<i>General (0)</i> <i>PageNumber (3)</i> <i>MessageNumber (4)</i>
	<b>Check (5)</b>	<i>General (0)</i>
	<b>Init (11)</b>	<i>General (0)</i>
	<b>TopOfPage (12)</b>	<i>General (0)</i>
<b>RangeFilter</b>	<b>Off (0)</b>	<i>General (0)</i>
	<b>On (1)</b>	<i>General (0)</i>
<b>MessageFilter</b>	<b>Off (0)</b>	<i>General (0)</i>
	<b>Level (13)</b>	<i>0-3</i>

CI

FunctionType	CommandNumber	Validity
Self	-	-
RangeFilter	-	-
Operation	-	-
Acoustic	Reset (3)	General (0)

BATTERY

FunctionType	CommandNumber	Validity
Self	Reset (3)	General (0)
	Check (5)	General (0)

NET

FunctionType	CommandNumber	Validity
Self	Reset (3)	General (0)

MODULEACTIVE

FunctionType	CommandNumber	Validity
Self	-	-

MODULEPASSIVE

FunctionType	CommandNumber	Validity
Self	-	-

DELAYLAYER

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
	On (1)	General (0)
Automatic	Off (0)	General (0)
	On (1)	General (0)

**FBP**

FunctionType	CommandNumber	Validity
Self	-	-
Acoustic	Reset (3)	General (0)

**SCU**

FunctionType	CommandNumber	Validity
Self	-	-

**INTERVENTION**

FunctionType	CommandNumber	Validity
Self	Reset (3)	General (0)

**CONNECTION**

FunctionType	CommandNumber	Validity
Self	-	-

**MASTERSYSTEM**

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
	On (1)	General (0)
	Reset (3)	General (0)
Operation	-	-
LocalOperation	-	-

**LOOP**

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
	On (1)	General (0)
	Reset (3)	General (0)

FunctionType	CommandNumber	Validity
	Revision (4)	General (0)
	Check (5)	General (0)
	StartupStop (15)	General (0)
Logic	Mapping (14)	General (0)

FLOODINGZONE

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
	On (1)	General (0)
	Reset (3)	General (0) Acoustic (1)
Automatic	Off (0)	General (0)
	On (1)	General (0)
RevisionOperation	Set (2)	General (0)
	Reset (3)	General (0)

REMOTEACCESS

FunctionType	CommandNumber	Validity
Self	Set (2)	General (0)

ALARMAREA

FunctionType	CommandNumber	Validity
Self	Off (0)	General (0)
		Acoustic (1)
	On (1)	General (0)
		Acoustic (1)
	Set (2)	General (0)

FunctionType	CommandNumber	Validity
	<b>Reset (3)</b>	<i>General (0)</i> <i>Acoustic (2)</i>
	<b>Revision (4)</b>	<i>General (0)</i>
	<b>SimulateFault (7)</b>	<i>General (0)</i>
	<b>Reactivate (10)</b>	<i>General (0)</i> <i>Acoustic (1)</i>

**SUPERORDINATEDCONTROLUNIT**

FunctionType	CommandNumber	Validity
Self	-	-

**SUBORDINATEDCONTROLUNIT**

FunctionType	CommandNumber	Validity
Self	-	-

**NETWORK**

FunctionType	CommandNumber	Validity
Self	-	-

**EXTERNALSYSTEM**

FunctionType	CommandNumber	Validity
Self	<b>Off (0)</b>	<i>General (0)</i>
	<b>On (1)</b>	<i>General (0)</i>
	<b>Reset (3)</b>	<i>General (0)</i>
	<b>Check (5)</b>	<i>General (0)</i>
LocalOperation	-	-

### 8.3.3 Driver-specific functions

#### RETURN VALUES AFTER EXECUTION OF COMMAND

Variable value	Description
0xFFFF	Idle
0xFFFE	Timeout after execution.
0xFFFD	Command sent.
0xFFFB	Command could not be sent successfully.
0xFFF9	Negative response to the command. The command should be executed using SetCritical.
0xFFF8	Negative response to the command: the main control center sends a negative response to the subordinate control center.
0xFFF7	Negative response to battery test. Execute the battery test again.
0xFFF6	Negative response to the command. The element is not currently available (hardware module failure).
0xFFF5	Negative response to the query: the element does not support an individual query.
0xFFF4	Negative response: the addressed element does not exist.
0xFFF3	Negative response: the command is not possible or not permitted for a subelement.
0xFFF2	Negative response: inappropriate command for the element status.
0xFFF1	Negative response: incorrect authorization
0xFF00	Positive acknowledgment of the command

## 9 Driver command function

The zenon **Driver commands** function is to influence drivers using zenon. You can do the following with a driver command:

- ▶ Start

- ▶ Stop
- ▶ Shift a certain driver mode
- ▶ Instigate certain actions

**Note:** This chapter describes standard functions that are valid for most zenon drivers. Not all functions described here are available for every driver. For example, a driver that does not, according to the data sheet, support a modem connection also does not have any modem functions.

### Attention


The zenon **Driver commands** function is not identical to driver commands that can be executed in the Runtime with Energy drivers!

## CONFIGURATION OF THE FUNCTION

Configuration is carried out using the **Driver commands** function.  
To configure the function:


1. Create a new function in the zenon Editor.

The dialog for selecting a function is opened




2. Navigate to the node **Variable**.
3. Select the **Driver commands** entry.

The dialog for configuration is opened



4. Select the desired driver and the required command.
5. Close the dialog by clicking on **OK** and ensure that the function is executed in the Runtime. Heed the notices in the **Driver command function in the network** section.

### DRIVER COMMAND DIALOG



Option	Description
<b>Driver</b>	Selection of the driver from the drop-down list. It contains all drivers loaded in the project.
<b>Current condition</b>	Fixed entry that is set by the system. no function in the current version.
<b>Driver command</b>	no function in the current version.  For details on the configurable driver commands, see the <b>available driver commands</b> section.
<b>Driver-specific command</b>	Entry of a command specific to the selected driver.  <b>Note:</b> Only available if, for the <b>driver command</b> option, the <i>driver-specific command</i> has been selected.
<b>Show this dialog in the Runtime</b>	Configuration of whether the configuration can be changed in the Runtime: <ul style="list-style-type: none"> <li>▶ <i>Active:</i> This dialog is opened in the Runtime before executing the function. The configuration can thus still be changed in the Runtime before execution.</li> <li>▶ <i>Inactive:</i> The Editor configuration is applied in the Runtime when executing the function.</li> </ul> <p>Default: <i>inactive</i></p>

#### CLOSE DIALOG

Options	Description
<b>OK</b>	Applies settings and closes the dialog.
<b>Cancel</b>	Discards all changes and closes the dialog.
<b>Help</b>	Opens online help.

#### AVAILABLE DRIVER COMMANDS

These driver commands are available - depending on the selected driver:

Driver command	Description
<i>No command</i>	No command is sent. A command that already exists can thus be removed from a configured function.

Driver command	Description
<i>Start driver (online mode)</i>	Driver is reinitialized and started. <b>Note:</b> If the driver has already been started, it must be stopped. Only then can the driver be re-initialized and started.
<i>Stop driver (offline mode)</i>	Driver is stopped. No new data is accepted. <b>Note:</b> If the driver is in offline mode, all variables that were created for this driver receive the status <i>switched off</i> (OFF; Bit 20).
<i>Driver in simulation mode</i>	Driver is set into simulation mode. The values of all variables of the driver are simulated by the driver. No values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
<i>Driver in hardware mode</i>	Driver is set into hardware mode. For the variables of the driver the values from the connected hardware (e.g. PLC, bus system, ...) are displayed.
<i>Driver-specific command</i>	Entry of a driver-specific command. Opens input field in order to enter a command.
<i>Driver - activate set setpoint value</i>	Write set value to a driver is possible.
<i>Driver - deactivate set setpoint value</i>	Write set value to a driver is prohibited.
<i>Establish connecton with modem</i>	Establish connection (for modem drivers)  Opens the input fields for the hardware address and for the telephone number.
<i>Disconnect from modem</i>	Terminate connection (for modem drivers)
<i>Driver in counting simulation mode</i>	Driver is set into counting simulation mode. All values are initialized with 0 and incremented in the set update time by 1 each time up to the maximum value and then start at 0 again.
<i>Driver in static simulation mode</i>	No communication to the controller is established. All values are initialized with 0.
<i>Driver in programmed simulation mode</i>	The values are calculated by a freely-programmable simulation project. The simulation project is created with the help of the zenon Logic Workbench and runs in the zenon Logic Runtime.

## DRIVER COMMAND FUNCTION IN THE NETWORK

If the computer on which the **Driver commands** function is executed is part of the zenon network, further actions are also carried out:

- ▶ A special network command is sent from the computer to the project server. It then executes the desired action on its driver.
- ▶ In addition, the Server sends the same driver command to the project standby. The standby also carries out the action on its driver.

This makes sure that Server and Standby are synchronized. This only works if the Server and the Standby both have a working and independent connection to the hardware.

## 10 Error analysis

Should there be communication problems, this chapter will assist you in finding out the error.

### 10.1 Analysis tool

All zenon modules such as Editor, Runtime, drivers, etc. write messages to a joint log file. To display them correctly and clearly, use the Diagnosis Viewer program that was also installed with zenon. You can find it under **Start/All programs/zenon/Tools 8.20 -> Diagviewer**.

zenon driver log all errors in the LOG files. LOG files are text files with a special structure. The default folder for the LOG files is subfolder **LOG** in the folder **ProgramData**. For example:

**%ProgramData%\COPA-DATA\LOG.**

**Attention:** With the default settings, a driver only logs error information. With the Diagnosis Viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events.

In the Diagnosis Viewer you can also:

- ▶ Follow newly-created entries in real time
- ▶ customize the logging settings
- ▶ change the folder in which the LOG files are saved

#### Note:

1. The Diagnosis Viewer displays all entries in UTC (coordinated world time) and not in local time.

2. The Diagnosis Viewer does not display all columns of a LOG file per default. To display more columns activate property **Add all columns with entry** in the context menu of the column header.
3. If you only use **Error-Logging**, the problem description is in the column **Error text**. For other diagnosis level the description is in the column **General text**.
4. For communication problems many drivers also log error numbers which the PLC assigns to them. They are displayed in **Error text** or **Error code** or **Driver error parameter (1 and 2)**. Hints on the meaning of error codes can be found in the driver documentation and the protocol/PLC description.
5. At the end of your test set back the diagnosis level from **Debug** or **Deep Debug**. At **Debug** and **Deep Debug** there are a great deal of data for logging which are saved to the hard drive and which can influence your system performance. They are still logged even after you close the Diagnosis Viewer.

### Attention

In Windows CE errors are not logged per default due to performance reasons.

You can find further information on the Diagnosis Viewer in the Diagnose Viewer manual.

## 10.2 Driver monitoring

Runtime monitors the availability of the driver by means of a watchdog. If a driver is no longer available, the *INVALID* status bit is also set for all checked-in variables.

Possible causes for a triggering of the watchdog:

- ▶ The driver process is no longer running.

Check whether the driver EXE file is still running in the Task Manager.

- ▶ Operating system is busy with processes that have a higher priority.

Check the configuration of your system to see whether there is sufficient memory and CPU power. In this case, the driver only resets the *INVALID* status bit if there is a value change on the connected party. Static values retain the *INVALID* status bit until the next time the Runtime or the driver is started.

### CONFIGURATION OF WATCHDOG

For the monitoring of communication in the Runtime, the connection to the driver is checked in a fixed, prescribed time period of 60 seconds. This process is repeated several times. If, within 5 attempts (= within 5 minutes), no valid connection to the driver is detected, the *INVALID* bit is set for the checked-in (*advised*) variables. In addition, the *INVALID* bit is also set when new variables are advised. The *INVALID* bit will no longer be reset.

Corresponding LOG entries are created for this.

## LOG ENTRY

An error message is logged in the LOG when the watchdog is triggered:

Parameter	Description
<i>Communication with driver:&lt;drvExe&gt;/&lt;drvDesc&gt;(id:&lt;drvId&gt;) timed out. No communication for &lt;time&gt; ms.</i>	No communication with driver within the given time. <ul style="list-style-type: none"> <li>▶ &lt;time&gt;: Time (in milliseconds)</li> <li>▶ &lt;drvDesc&gt;: Driver name</li> <li>▶ &lt;drvExe&gt;: Driver EXE name</li> <li>▶ &lt;drvId&gt;: Driver ID in the zenon project</li> </ul>
<i>Communication with %s timed out. Invalid-Bit will be set.</i>	Communication to the %s driver could not be established after 5 attempts within 60 seconds. The <i>INVALID</i> bit is set for the variable.
<i>Communication with %s timed out. Timeout happened %d times</i>	Communication to the %s driver could not be established after %d times within 60 seconds.

## 10.3 Check list

### GENERAL TROUBLESHOOTING

Check the following in the event of errors:

- ▶ Is the PLC connected to the power supply?
- ▶ Analysis with the **Diagnosis Viewer** (on page 55):  
-> Which messages are displayed?
- ▶ Are the participants available in the **TCP/IP** network?
- ▶ Can the PLC be reached via the *Ping* command?

Ping: **Open command line -> ping < IP address> (e.g. ping 192.168.0.100) -> press Enter.**

Do you receive an answer with a time or a timeout?

- ▶ Can the PLC be reached at the respective port via *TELNET*?

Telnet: **Command line: enter: telnet <IP address port number> (e.g. for Modbus: telnet 192.168.0.100 502) -> Press Return key**

If the monitor display turns black, a connection could be established.

- ▶ Did you configure the Net address in the address properties of the variable correctly?
  - ▶ Does the addressing match with the configuration in the driver dialog?
  - ▶ Does the net address match the address of the target station?
- ▶ Did you use the right object type for the variable

**Example:** Driver variables are purely statistics variables. They do not communicate with the PLC. (See chapter Driver variable (on page 33).)

- ▶ Does the offset addressing of the variable match the one in the controller?
- ▶ Has a third-party control system been configured in the equipment accordingly?
  - ▶ Two third-party control systems must be configured for redundant operation in the equipment. Once for the server and once for the standby server.
- ▶ Does the user name and password match that of the configuration in the equipment?

zenon driver log all errors in the LOG files. LOG files are text files with a special structure. The default folder for the LOG files is subfolder **LOG** in the folder **ProgramData**. For example:

**%ProgramData%\COPA-DATA\LOG.**

**Attention:** With the default settings, a driver only logs error information. With the Diagnosis Viewer you can enhance the diagnosis level for most of the drivers to "Debug" and "Deep Debug". With this the driver also logs all other important tasks and events. You can find more information on the Diagnosis Viewer in the Diagnosis Viewer manual.

The following is required for further analysis of errors:

- ▶ The project backup
- ▶ LOG files

Send these to your support person after agreement with the customer service department.

#### **SOME VARIABLES REPORT INVALID.**

- ▶ INVALID bits always refer to a net address.
- ▶ There is no INVALID status bit with incorrect addressing for state variables

#### **VALUES ARE NOT DISPLAYED, NUMERIC VALUES REMAIN EMPTY**

Driver is not working. Check the:

- ▶ Installation of zenon
- ▶ the driver installation

- ▶ The installation of all components  
-> Pay attention to error messages during the start of the Runtime.

### VARIABLES ARE DISPLAYED WITH A BLUE DOT

The communication in the network is faulty:

- ▶ With a network project:  
Is the network project also running on the server?
- ▶ With a stand-alone project or a network project which is also running on the server:  
Deactivate the property **Read from Standby Server only** in node **Driver connection/Addressing**.

### VALUES ARE DISPLAYED INCORRECTLY

Check the information for the calculation in node **Value calculation** of the variable properties.

### DRIVER FAILS OCCASIONALLY

Analysis with the **Diagnosis Viewer** (on page 55):  
-> Which messages are displayed?